GILES CHEMICAL CORPORATION								
COMPANY PROCEDURE								
Standard	Operating Procedure		Page	:	1 of 1	Revision Date	:	10/26/2007
Author:	Patrick Owen	Title: (00)Pressure Washer						

### **Personnel responsible:**

1. Lead Operator, Material Handler, Assistant Operator

### Safety:

Acid suit, face shield, gloves, safety shoes, and safety glasses are required when using the pressure washer. The gloves should be long enough to cover the wrist area and go over the acid suit cuff.

## **Summary:**

The line pressure washer is a handy tool for cleaning Calcium Sulfate and other residues from the inside of lines. Running it requires two people.

# A. Operation

- 1. Obtain a piece of electrical tape and wrap it around the pressure washer hose approximately 1 foot from the nozzle.
- 2. Ensure the hose valve is closed.
- 3. Start the pressure washer by pressing the green button on the pressure washer control box.
- 4. Insert the hose into the pipe **beyond** the electrical tape marker.
- 5. Have a coworker slowly open the hose valve.
- 6. Clean the pipe with a back and forth motion.
- 7. When finished, signal to the coworker to shut off the hose valve.
- 8. Wait 15 seconds for the water pressure to dissipate before pulling the hose all the way out of the line.
- 9. Repeat steps 4 through 8 until all lines being cleaned are clean.
- 10. Press the red stop button on the pressure washer control panel.
- 11. Roll the hose up and store it on its rack.
- 12. Clean up the line debris and put lines back together.

Warning: Never pull the hose out beyond the electrical tape marker when in use, the pressure washer can cut you.

GILES CHEMICAL CORPORATION								
COMPANY PROCEDURE								
Standard	Operating Procedure		Page	:	2 of 1	Revision Date	:	10/26/2007
Author:	Patrick Owen	Title: (00)Pressure Washer						

# TRAINING DOCUMENTATION

	EMPLOYEE	TITLE	SIGNATURE	DATE
1				
2				
3				
4				
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				