

GILES CHEMICAL ~ PREMIER MAGNESIA

Company Form

Title: Filter Press Start Up Number: G18-PR-200-003

Owner: Joe Phillips Revision: 00

Effective Date: 02/28/18 Page: 1 of 2



1.0 Purpose

This procedure is intended to be a step by step instructional guide to starting up the filter press.

2.0 Scope

This procedure applies to the following equipment:

- Filter Press
- Brine Pump
- Mud Pump

3.0 Responsibility

Lead Operator, Material Handler, Assistant Operator

4.0 Safety Considerations

Safety glasses and steel-toed shoes.

Safety is a condition of employment. Employees are not authorized to work in an unsafe manner and are prohibited from harming the environment of the facility or community.

5.0 Materials/Equipment

The following equipment will be required before starting up the filter press

- A 50lb bag of Filter Flow
- Hydrometer
- Graduated cylinder

6.0 Procedure

- 1) Close Filter press. Press plates should be lined up and in line with the inlet/outlet valves on press frame. Leave the switch in the close position, the press will regulate its own internal pressure.
- 2) Hook up a line from the water supply valve to the filter press outlet valve.
- 3) Hook up a line from the filter press inlet valve and run the other end into the floor drain.

Controlled Document



GILES CHEMICAL ~ PREMIER MAGNESIA

Company Form

Title: Filter Press Start Up Number: G18-PR-200-003

Owner: Joe Phillips Revision: 00

Effective Date: 02/28/18 Page: 2 of 2



- 4) Open the water supply valve ½ way and backflush the system until water runs steadily into the drain from the filter press inlet valve.
- 5) Close water supply valve and unhook hose at valve.
- 6) Hook up hose from product box to water supply valve.
- 7) Create a loop from product box to brine pump inlet (this line should always be hooked up). Hook up a line from brine pump outlet to filter press inlet valve.
- 8) Start brine pump. Open all spigots on press frames and close outlet valve on press. You may add water from the water supply valve if necessary.
- 9) Unhook hose on filter press outlet valve and hook it to the product valve on the mud tank.
- 10) Add 50lbs of filter flow to product box. Add a small amount of water to the product box to aid in mixing the filter flow.

11)

- 12) Allow filter flow to circulate for 4-5 minutes.
- 13) Move the long trough away from spigots and allow product box to drain.
- 14) Once the line at the product box begins to suck air, stop the brine pump.
- 15) Unhook hose from brine pump outlet.
- 16) Hook up a hose from the brine pump outlet to the desired tank line.
- 17) Hook up the mud line to the mud pump inlet.
- 18) Hook up a line from the mud pump outlet to the filter press inlet.
- 19) Open the product valve at mud tank.
- 20) Open filter press inlet valve ½ way open.
- 21) Turn on mud pump and run product into the floor for two minutes and return long trough to the spigots on press frames.
- 22) Fill product box ½ way before starting brine pump.
- 23) Maintain the level in the product box by using the valve at tank line. Add water to product box if necessary to reach desired percentage.

7.0 Reference Documents

N/A

8.0 Change Information New Document

Controlled Document