GILES CHEMICAL								
	COMPANY PROCEDURE							
Standard Operating Procedure			Page	:	1 of 4	Revision Date	:07/01/2008 :05/01/2007	
Author: Patrick Owen Title: Changing a pH Meter Box								

# Personnel responsible:

1. Technical

#### **Safety equipment:**

Safety glasses and safety shoes. Sulfuric acid is in use in the Digesters; take necessary precautions to prevent contact.

## **Summary:**

Sometimes the cable for the pH Meter Box may need to be replaced. This procedure informs you how to do it.

#### **Procedure:**

### Removing the Old Meter and mounting the New Meter

- 1. Inform the Lead Operator of what you are doing.
- 2. Stop the Digester (see the procedure for this)
- 3. Unplug the pH Meter.
- 4. Using a screwdriver, unscrew the 4 screws on the pH meter readout.
- 5. Using a screwdriver, remove the black plastic "ESD Shield"
- 6. Using a small screwdriver, loosen all cable connections.
- 7. Gently pull all of the wires loose from the readout.
- 8. Using a small screwdriver, push the hinge pin out of the hinge until you can pull it out with your hand.
- 9. The meter box is now loose, remove it.
- 10. Align the new meter box on the holder and insert the hinge pin.
- 11. Push the pin completely in place with a small screwdriver.
- 12. Remove the "ESD Shield" with a screwdriver.

#### **Making Electrical Connections**

- 13. The panel is labeled for the wires, so the following convention matches the panel.
- 14. Connect the electric cable white wire to terminal 19.
- 15. Connect the electric cable black wire to terminal 20.
- 16. Connect the large Green and Yellow wire to "shield".
- 17. Connect the small Green wire to "RTD D". The letter D will be in a box.
- 18. Connect the small White wire to "RTD E". The letter E will be in a box.
- 19. Connect the large Black wire to terminal 1, "meas el."
- 20. Connect the small Red wire to terminal 2, "ref el."
- 21. Connect the small Blue wire to terminal 3, "aux. el."
- 22. Tighten all connections.
- 23. Clip the small gray wire and tape the end.
- 24. Gently squeeze the wires to the side and replace the "ESD Shield"

GILES CHEMICAL							
COMPANY PROCEDURE							
Standard Operating Procedure			Page :		: 2 of 4	Revision	:07/01/2008
Standard Operating Procedure				•		Date	:05/01/2007
Author: Patrick Owen Title: Changing a pH Meter Box							

- Closing up the Box 25. Be very careful about bending the probe cable too sharply because it is very weak at this end.
- 26. Close the box and tighten the screws on the face of the panel.
  27. Plug in the pH Meter
- 28. Calibrate the meter..
- 29. Start the Digester.

GILES CHEMICAL							
COMPANY PROCEDURE							
Standard Operating Procedure		Page	:	3 of 4	Revision Date	:07/01/2008 :05/01/2007	
Author: Patrick Owen Title: Changing a pH Meter Box							

# TRAINING DOCUMENTATION

	EMPLOYEE	TITLE	SIGNATURE	DATE
1				
2				
3				
4				
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				

GILES CHEMICAL								
	COMPANY PROCEDURE							
Standard Operating Procedure			Page	:	4 of 4	Revision Date	:07/01/2008 :05/01/2007	
Author: Patrick Owen Title: Changing a pH Meter Box								

# **REVISION HISTORY**

Revision Date	Revision Number	Revision Description
2007	01	- Revision not recorded
07/01/2008	02	-Added Blue wire to
		Cable connection for
		disposable probes.