

GILES CHEMICAL						
COMPANY POLICY / PROCEDURE						
Unloading Acid Trucks	Page	:	1 of 4	Revision Date	:	10/22/2008

Author: Mike Wyatt Job Specific

Personnel responsible: Material Handler

Safety:

The Material Handler and truck driver must both be present during the entire unloading process. All PPE pertaining to handling sulfuric acid must be worn.

Purpose or Objective:

To ensure that all sulfuric acid coming to plant in tankers is handled safely and correctly.

Procedure:

- 1. Trucks can only be unloaded between the hours of 7 AM 5 PM.
- 2. Upon arrival, the truck driver will contact the Lead Operator working the shift.
- 3. The Lead Operator will get the key for the lock on the intake valve from the Maintenance Office and give it to the Material Handler.
- 4. The Material Handler will remove the lock from the intake valve.
- 5. The intake valve determining where the acid is to go must be set correctly.
 - If the acid is to go to the storage tanks it should be in the horizontal position.
- 6. Check the levels in the storage tanks to determine which tank is to be filled.
- 7. At the top of the platform, the middle feeder line determines which tank to feed into.
- 8. If you are feeding into #1 Acid Storage Tank, the 1st valve must be horizontal (inline) and the 2nd valve upright (closed).
- 9. If you are feeding into #2 Acid Storage Tank, the 1st valve must be upright (closed) and the 2nd valve must be horizontal (inline).
- 10. Request that the truck driver give you a sample of the acid before he begins to unload.
- 11. The truck driver, (in full personal protective equipment) will then hook up to intake valve and begin the unloading process.



GILES CHEMICAL							
COMPANY POLICY / PROCEDURE							
	Unloading Acid Trucks	Page :	2 of 4	Revision Date	:	10/22/2008	
Author:	Mike Wyatt	Job Spe	ecific				

- 12. When the unloading is complete, the truck driver will drain the remaining acid from his hose into a designated bucket.
- 13. The Material Handler will then empty the bucket into a specially designated area. The area will be a metal container filled with the proper amount of lime to neutralize the acid.
- 14. The Material Handler will then close the intake valve, re-secure the lock and return the key to the Maintenance Office.
- 15. When enough time has elapsed, the non-reactive waste product will then be taken to the "mud" pile and dumped.



	GILES CHEMICAL
COMF	PANY POLICY / PROCEDURE

Unloading Acid Trucks

Page : 3 of 4

Revision Date

Mike Wyatt Author:

Job Specific

TRAINING DOCUMENTATION

	EMPLOYEE	TITLE	SIGNATURE	DATE
1				
2				
3				
4				
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				-
16				
17				
18				



GILES CHEMICAL COMPANY POLICY / PROCEDURE

Unloading Acid Trucks

Page :

4 of 4

Revision Date

10/22/2008

Author: Mike Wyatt

Job Specific

Revision Number	Revision Date	Revision Author	Revision Description
00	10/22/2008	MW	New Document
<u> </u>			