

GILES CHEMICAL COMPANY POLICY / PROCEDURE

Unloading Acid Trucks

Page :

1 of 4

Revision : 11/26/2008 Date : 10/22/2008

Author: Mike Wyatt

Job Specific

Personnel responsible: Material Handler

Safety:

The Material Handler and truck driver must both be present during the entire unloading process. All PPE pertaining to handling sulfuric acid must be worn.

Purpose or Objective:

To ensure that all sulfuric acid coming to plant in tankers is handled safely and correctly.

Procedure:

- 1. Trucks can only be unloaded between the hours of 7 AM 5 PM.
- 2. Upon arrival, the truck driver will contact the Lead Operator working the shift.
- 3. The Lead Operator will get the key for the lock on the #2 intake valve from the Maintenance Office and give it to the Material Handler.
- 4. Close #2 Intake Valve.
- 5. The #1 intake valve determining where the acid is to go must be set correctly.
 - a. If the acid is to go to the storage tanks it should be in the horizontal position
- 6. The Material Handler will then remove the lock from the #2 intake valve.
- 7. Check the levels in the storage tanks to determine which tank is to be filled.
- 8. At the top of the platform, the middle feeder line determines which tank to feed into.
- 9. If you are feeding into #1 Acid Storage Tank, the 1st valve must be horizontal (inline) and the 2nd valve upright (closed).
- 10. If you are feeding into #2 Acid Storage Tank, the 1st valve must be upright (closed) and the 2nd valve must be horizontal (inline).
- 11. Request that the truck driver give you a sample of the acid before he begins to unload.
- 12. The truck driver, (in full personal protective equipment) will then hook up to intake valve and begin the unloading process.



GILES CHEMICAL							
COMPANY POLICY / PROCEDURE							
	Unloading Acid Trucks	Page	:	2 of 4	Revision Date	:	11/26/2008 10/22/2008
Author:	Mike Wyatt	Job S	Spe	ecific			

- 13. When the unloading is complete, the truck driver will drain the remaining acid from his hose into a designated bucket.
- 14. The Material Handler will then empty the bucket into a specially designated area. The area will be a metal container filled with the proper amount of lime to neutralize the acid.
- 15. The Material Handler will then close the intake valve, re-secure the lock and return the key to the Maintenance Office.
- 16. When enough time has elapsed, the non-reactive waste product will then be taken to the "mud" pile and dumped.



GILES CHEMICAL
COMPANY POLICY / PROCEDUR

Unloading Acid Trucks

Page :

3 of 4

Revision Date 11/26/2008 10/22/2008

Author: Mike Wyatt

Job Specific

TRAINING DOCUMENTATION

	EMPLOYEE	TITLE	SIGNATURE	DATE
1				
2				
3				
4				
5				
6				
7				
8				=
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				



GILES CHEMICAL COMPANY POLICY / PROCEDURE

Unloading Acid Trucks

Page :

4 of 4

Revision : 11/26/2008 Date : 10/22/2008

Author: Mike Wyatt

Job Specific

Revision Number	Revision Date	Revision Author	Revision Description
00	10/22/2008	MW	New Document
01	11/26/2008	MW	- Added to open #1 Intake Valve going to storage tanks before removing lock on #2 Intake Valve.