GILES CHEMICAL CORPORATION						
COMPANY PROCEDURE						
	AMS CONTROLS	Page	:	1 of 1	Date : Revision :	10/2/06
Author:	Clark Williams					

Objective

Provide guidelines to setup and adjust the AMS controls

Scope

AMS feeder controls on Liquipak 800 Machine's #1 and #2

Responsibility

Machine Operator, Lead Operator, and Maintenance

Definitions

Initial Setup – Follow when the AMS control has just been powered on. Adjustments – Follow when the AMS control has already been through the initial setup.

Procedure

Initial Setup

- 1. Flip the Power switch to the "On" position.
- 2. Flip the Fill switch to the "On" position.
- 3. Flip the Agitation switch to the "W/Fill" position.
- 4. Make sure the Manual Fill Switch is in the up position.
- 5. Press **PRG** until the screen displays "PSet"
- 6. Press ►.
- 7. Change each number to the desired setting by pressing ▼. Scroll over to different number places using ▶.
- 8. Press **PRG** once the correct number is entered. *Adjustments*
- 9. Press ▶.
- 10. Change each number to the desired setting by pressing ▼. Scroll over to different number places using ▶.
- 11. Press **PRG** once the correct number is entered.