GILES CHEMICAL									
COMPANY PROCEDURE									
Standard Operating Procedure			Page		1 of 3			7/15/2008	
Standard	operating Procedure		rage .	•	1 01 3	Date	:	12/01/2005	
Author:	Patrick Owen	Title: (01) Starting and Stopping the Digesters							

### **Personnel responsible:**

1. Lead Operator, Material Handler

### **Safety equipment:**

Safety glasses and safety shoes. Sulfuric acid is in use, take necessary precautions to prevent contact.

#### **Summary:**

Starting and Stopping the Digesters is a routine occurrence. However, starting the Digesters can cause problems if MgO is started before the Digesters are acid. The MgO can form "rocks" of oxysulfate cement which can cause the circulation loop to stop.

Warning – the acid will not run if the circulation loop is flowing less than 60 gallons per minute. Make sure the circulation loop is running properly before starting the digester.

#### **Procedure:**

#### 1) STARTING A DIGESTER

- a) Check that the circulating line is operating, the pH meter is reading properly, and the agitator is on.
- b) Open the Mix Pot Water Supply valve. Check for water going into the mix pot.
- c) Open the Acid Control Shutoff valve.
- d) Wait until the pH in the primary digester goes below 5.00 before starting the MgO.
- e) On the #2 Side, Start the Short MgO Screw and the Long MgO Screw.
- f) Turn the MgO Feed Drive switch on and adjust the dial as needed
- g) Check to see that the MgO is flowing into the mix pot.
- h) Open the Density Control Shutoff valve.
- i) Slightly open the Mother Liquor Feeder valve.
- j) Close the Mother Liquor Recirculation valve and adjust flow with the Mother Liquor Feeder valve to about half of the TOTAL feed to the Crystallizer (15-20 gpm).

#### 2) SHUTTING DOWN A DIGESTER

- a) Open the Mother Liquor Recirculation valve.
- b) Close the Mother Liquor Feeder valve.
- c) Stop the MgO Feed Drive.
- d) On #2 Side, stop the Short MgO Screw and the Long MgO Screw.
- e) Close the Acid Control Shutoff valve.
- f) Allow the liquid in the mix pot to clear up.
- g) Close the Mix Pot Water Supply valve.
- h) Close the Density Control Shutoff valve.

GILES CHEMICAL									
COMPANY PROCEDURE									
Standard Operating Procedure		Page	:	2 of 3			7/15/2008 12/01/2005		
Author:	Patrick Owen	Title: (01) Starting and Stopping the Digesters							

# TRAINING DOCUMENTATION

	EMPLOYEE	TITLE	SIGNATURE	DATE
1				
2				
3				
4				
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				

GILES CHEMICAL									
COMPANY PROCEDURE									
Standard Operating Procedure		Page		3 of 3			7/15/2008		
Standard	operating recedure		rage .	•	3 01 3	Date	:	12/01/2005	
Author:	Patrick Owen	Title: (01) Starting and Stopping the Digesters							

## **REVISION HISTORY**

Revision Date 07/15/2008

Revision Number 01

**Revision Description** 

-Add warning about acid Stopping if circulation

Loop is slow
-Added wording for
Monitoring System -Changed heading for Giles Chemical -Added revision pg.