

# GILES CHEMICAL ~ PREMIER MAGNESIA

**Company Procedure** 

Title: PM Autopoucher Line #4 Number: M15-PR-200-054

Owner: Thomas Evans Revision: 01

Effective Date: 05/1/2018 Page: 1 of 2



### 1.0 Purpose

This procedure establishes the requirements for monthly preventive maintenance for Autopoucher Line #4.

## 2.0 Scope

This procedure applies to Autopoucher Line #4 at the Repackaging Facility. This procedure shall be performed monthly at a minimum or as necessary.

### 3.0 Responsibility

Maintenance will lead PM of machines with assistance of assigned production employees.

# 4.0 Safety Considerations

All Contractors/Service Personnel are expected to observe all safety rules and regulations while on Giles Chemical property.

Safety is a condition of employment. Employees are not authorized to work in an unsafe manner and are prohibited from harming the environment of the facility or community.

# 5.0 Materials/Equipment

- Tools necessary for PM of autopouchers
- Tools necessary for PM of conveyor
- Tools necessary for PM of tapers

#### 6.0 Procedure

## **Auto Poucher #4 Machine**

- 1. Clean gripper jaws.
- 2. Check springs on gripper arms for proper tension and attachment.
- 3. Clean bushings on gripper arms (both big hole and small).
- 4. Check black nylon bushings for wear and replace as necessary.
- 5. Check vacuum cups for wear and replace as necessary.
- 6. Check vacuum lines for dust and blow out any trash or dust that is noticeable.
- 7. Change all vacuum filters (quantity of three).
- 8. Grease all fittings on moving parts and wipe off any excess grease.
- 9. Change Teflon tape on seal bars and cooling bars.

#### Controlled Document



# GILES CHEMICAL ~ PREMIER MAGNESIA

**Company Procedure** 

Title: PM Autopoucher Line #4 Number: M15-PR-200-054

Owner: Thomas Evans Revision: 01

Effective Date: 05/1/2018 Page: 2 of 2



- 10. Check bag.
- 11. Check leakage on scale (above platform toward machine).

### Conveyor

- 1. Check belt connector wires for proper connection and repair and/or replace if necessary.
- 2. Clean salt and trash from around end roller.
- 3. Check drive chain and grease/oil as required for proper operation.

## **Combi Case Erector and Case Sealer**

- 1. Clean salt dust and corrugate dust from inside case erector and sealer.
- 2. Check all filter regulators for correct labeled psi air pressure and drain water if needed.
- 3. Check vacuum cups for visible wear and tears. Replace if cracked or worn.
- 4. Check for loose belts on belt drives. Tighten if needed. Tensioning procedure in Combi Operating Manual if needed.
- 5. Clean salt and trash from around end rollers on white plastic product conveyor belt and black packing conveyor belt.
- 6. Check all air lines for cracks, leaks, or kinks. Replace if needed.
- 7. Clean all photo eyes and reflectors. Do not use solvent based cleaners.
- 8. Clean all threaded adjustment rods with mild cleaning solution.
- 9. Lube all grease fittings (erector belt drives, sealer belt drives, product conveyor, box conveyor, carriage roller bearings)
- 10. Check all bolts and fasteners for looseness. Tighten as needed.
- 11. Clean and wipe down all doors and components.
- 12. Check tape knives and clean.
- 13. Oil pads that knives stop on.
- 14. Check all springs to see if they are in proper operating condition and operating properly.

#### 7.0 Reference Documents

PM Autopoucher Line #4 form (M15-PR-200-F054)

## 8.0 Change Information

Revised Procedure to include Combi Pack Station