

GILES CHEMICAL ~ PREMIER MAGNESIA

Company Procedure

Title: Air Compressor PM - Repackaging Number: M12-PR-200-017

Owner: Robert Willis Revision: 02
Effective Date: 05/20/13 Page: 1 of 1



1.0 Purpose

The purpose of this procedure is to describe the maintenance requirements for the air compressor on a weekly schedule.

2.0 Scope

Schedule: Weekly based on production availability

3.0 Responsibility

Maintenance

4.0 Safety Considerations

Safety is a condition of employment. Employees are not authorized to work in an unsafe manner and are prohibited from harming the environment of the facility or community.

5.0 Materials/Equipment

- water hose
- air compressor

6.0 Procedure

CLEANING OF THE AIR COMPRESSOR (PM)

- 1. Check air intake filter-inside cabinet; replace if required
- 2. Check oil level; fill to appropriate level if needed
- 3. Clean radiator filter with water
- 4. Blow out radiator with compressed air to remove all dust accumulation

7.0 Reference Documents

N/A

8.0 Change Information

Document review- updated format using new template and numbering system.