

GILES CHEMICAL ~ PREMIER MAGNESIA

Company Procedure

Title: PM Autopoucher Line #5 Number: M16-PR-200-059

Owner: Thomas Evans Revision: 01

Effective Date: 05/1/2018 Page: 1 of 2



1.0 Purpose

This procedure establishes the requirements for monthly preventive maintenance for Autopoucher Line #5.

2.0 Scope

This procedure applies to Autopoucher Line #5 at the Repackaging Facility. This procedure shall be performed monthly at a minimum or as necessary.

3.0 Responsibility

Maintenance will lead PM of machines with assistance of assigned production employees.

4.0 Safety Considerations

All Contractors/Service Personnel are expected to observe all safety rules and regulations while on Giles Chemical property.

Safety is a condition of employment. Employees are not authorized to work in an unsafe manner and are prohibited from harming the environment of the facility or community.

5.0 Materials/Equipment

- Tools necessary for PM of autopouchers
- Tools necessary for PM of conveyor
- Tools necessary for PM of tapers

6.0 Procedure

Auto Poucher #5 Machine

- 1. Clean gripper jaws.
- 2. Check springs on gripper arms for proper tension and attachment.
- 3. Clean bushings on gripper arms (both big hole and small).
- 4. Check black nylon bushings for wear and replace as necessary.
- 5. Check vacuum cups for wear and replace as necessary.
- 6. Check vacuum lines for dust and blow out any trash or dust that is noticeable.
- 7. Change all vacuum filters (quantity of three).
- 8. Grease all fittings on moving parts and wipe off any excess grease.
- 9. Change Teflon tape on seal bars and cooling bars.

Controlled Document



GILES CHEMICAL ~ PREMIER MAGNESIA

Company Procedure

Title: PM Autopoucher Line #5 Number: M16-PR-200-059

Owner: Thomas Evans Revision: 01

Effective Date: 05/1/2018 Page: 2 of 2



- 10. Check bag.
- 11. Check leakage on scale (above platform toward machine).

Conveyor

- 1. Check belt connector wires for proper connection and repair and/or replace if necessary.
- 2. Clean salt and trash from around end roller.
- 3. Check drive chain and grease/oil as required for proper operation.

Combi Case Erector and Case Sealer

- 1. Clean salt dust and corrugate dust from inside case erector and sealer.
- 2. Check all filter regulators for correct labeled psi air pressure and drain water if needed.
- 3. Check vacuum cups for visible wear and tears. Replace if cracked or worn.
- 4. Check for loose belts on belt drives. Tighten if needed. Tensioning procedure in Combi Operating Manual if needed.
- 5. Clean salt and trash from around end rollers on white plastic product conveyor belt and black packing conveyor belt.
- 6. Check all air lines for cracks, leaks, or kinks. Replace if needed.
- 7. Clean all photo eyes and reflectors. Do not use solvent based cleaners.
- 8. Clean all threaded adjustment rods with mild cleaning solution.
- 9. Lube all grease fittings (erector belt drives, sealer belt drives, product conveyor, box conveyor, carriage roller bearings)
- 10. Check all bolts and fasteners for looseness. Tighten as needed.
- 11. Clean and wipe down all doors and components.
- 12. Check tape knives and clean.
- 13. Oil pads that knives stop on.
- 14. Check all springs to see if they are in proper operating condition and operating properly.

7.0 Reference Documents

PM Autopoucher Line #5 form (M16-PR-200-F059)

8.0 Change Information

Revised Procedure to include Combi Pack Station