GILES CHEMICAL CORPORATION							
COMPANY PROCEDURE							
Standard Operating Procedure			Page	:	1 of 2	Revision : Date :	8/18/2006
Author:	Patrick Owen	Title: (00)Crystallizer Shutdown (Temporary)					

Personnel responsible:

1. Lead Operator, Material Handler

Safety:

Safety shoes and safety glasses are required when working in, on, or around the crystallizers.

Summary:

A crystallizer may need to be shut down for whatever reason. If the shutdown last less than 6 hours, this is the procedure to follow.

A. Shut Down of a Crystallizer:

- 1. At the centrifuge, open the sample valve and close the feed valve.
- 2. Close the Crystallizer discharge valve.
- 3. Stop the discharge pump and wash out the line with water.
- 4. Close the brine tank valve.
- 5. Connect a water hose the brine pump valve and wash the brine feed line into the crystallizer.
- 6. Close the crystallizer brine feed valve and open the sample valve.
- 7. Stop the brine feed pump.
- 8. Close the mother liquor pump valve and uncouple the mother liquor feed pump hose.
- 9. Wash the mother liquor line through to the crystallizer.
- 10. Stop the mother liquor feed pump.
- 11. Shut the mother liquor feed valve off, and open the sample valve.
- 12. Ensure that the Vacuum Isolator Valve (the manual valve near the vacuum control valve) is open to allow some air into the crystallizer.
- 13. On the Monitoring System, go to the Crystallizers screen.
- 14. Change the set point on the Vacuum Control Valve to 2.00.
- 15. Shut the steam off of the fine salt loop heat exchanger.
- 16. Keep watch on the level, temperature, and density.
- 17. Make proper intervention if necessary

GILES CHEMICAL CORPORATION							
COMPANY PROCEDURE							
Standard Operating Procedure			Page	:	2 of 2	Revision : Date :	8/18/2006
Author:	Patrick Owen	Title: (00)Crystallizer Shutdown (Temporary)					

- B. Restart from shutdown (assuming centrifuge and dryers are ready)
 - 1. At the centrifuge, close the solids sample valve and open the feed valve.
 - 2. On the Monitoring System Crystallizers screen, reduce the Vacuum Control Valve set point to 0.85 and allow the Crystallizer to cool to 30 C.
 - 3. Start discharge pump to resume flow to centrifuge.
 - 4. Begin feed of brine by opening the manual valve to get 15 gpm, and then starting the brine feed pump.
 - 5. Close the mother liquor sample valve.
 - 6. Connect the mother liquor hose, open the pump valve, and start the pump.
 - 7. Open the mother liquor feed valve and adjust flow with the pump valve.
 - 8. Open the steam valve to put steam on the Fine Salt Loop.
 - 9. Resume normal operation.

TRAINING DOCUMENTATION

l				
	EMPLOYEE	TITLE	SIGNATURE	DATE

GILES CHEMICAL CORPORATION								
COMPANY PROCEDURE								
Standard Operating Procedure			Page	:	3 of 2	Revision : Date :	8/18/2006	
Author:	Patrick Owen	Title: (00)Crystallizer Shutdown (Temporary)						

1		
2		
3		
4		
5		
6		
7		
8		
9		
10		
11		
12		
13		
14		
15		
16		
17		
18		
19		
20		