

GILES CHEMICAL COMPANY PROCEDURE

Electrical Outage Recovery

Page : 1 of 3

Revision : Date : 10/

10/13/2010

Author: Patrick Owen

Work Instruction

Personnel responsible:

Lead Operator, Material Handler, Assistant Operator

Safety:

Safety glasses and safety shoes required. Be very careful, it is easy to injure yourself when running around and trying to recover from a power outage. Plan ahead and take your time.

Summary:

After a power outage, many processes in the plant must be restarted before normal operations can resume. This checklist is not all-inclusive, but can be upgraded as we find other things to put on it.

Check Off List:

- Elbow pumps for Crystallizers (Priority #1)
- o Circulation Pumps for Digesters
- o MgO Feed for Digesters
- o Agitators on Salt Side, Liquid Side
- Mud Tank Agitators
- Filter Press (clear alarm and continue from hold)
- o Boilers
- Air Compressor
- Creek Pumps
- Dust Collectors
- Dryer Fans
- o Dryers
- o Screw Under Centrifuge
- o Centrifuge
- o Dryer Screws (Top and Bottom)
- o OmniLift
- o Screener (if in use)
- o Bucket Elevators (if in Use)
- o Water Recovery System
- Vacuum Pumps
- o Brine Transfer Pump

- Condenser Pumps (40Hz Minimum)
- o Small Condenser Pump
- o Mass Flow Pumps
- o Fine Salt Pumps
- o Brine Feed Pumps
- o Mother Liquor Pump
- o Mother Liquor Feed Pumps to Crystallizers
- o Mud Pump
- Liquid Load Pump (if in use)
- Liquid Load System (stop it and check load)
- Liquid Load Feed (stop manual water)
- Vibrators for Mix Pots
- o Liquor Pot Pump
- o Palletizer
- Conveyor
- o Bagger
- Super Sack Machine
- o MgO Blower (if in use)
- Acid unloading pump and Compressor (if in use)
- Log onto Monitoring System Screen (mon1, mon1- see procedure)

Notes:

- 1) These are somewhat in order of importance.
- 2) If the power blips again while you are starting up throw this checklist away and print a new one.



GILES	CHEMICAL
COMPAN	Y PROCEDURE

Electrical Outage Recovery

Page : 2 of 3

Revision Date 03 10/13/2010

Author: Patrick Owen

Work Instruction

TRAINING DOCUMENTATION

	EMPLOYEE	TITLE	SIGNATURE	DATE
1				
2				
3				
4				
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				



GILES CHEMICAL COMPANY PROCEDURE

Electrical Outage Recovery

Page : 3 of 3

Revision : 03 Date : 10/13/2010

Author: Patrick Owen Work Instruction

Revision Number	Revision Date	Revision Author	Revision Description
00	05/26/2006	PLO	Original Document
01	05/30/2008	PLO	Added Check Dryer Fans, Removed Document Number, Changed Header
02	03/23/2009	PLO	Added Acid Unloading Pump, Added Water Recovery
03	10/13/2010	PLO	Updated Format, Added Liquid Load details, Added Minimum Hz for Condenser Pumps