Nezha 4P4C plug tails, rev A — copper side up, plug end at the top (1 mm grid)





Pad order is as seen from the plug contacts with the nose away. The servo order G/V/S assumes the servo port is wired GND, V, SIG, unused: check before use.