Timothy Osifchin

TXID: 2V21281408052032P
tosifchin3@gmail.com

Assignment 23

* Find Reference tool bar
* Make Planes offset from origin planes to define prism side lengths
* Tools, Options/Parameters → Parameters + Relations On
* Part infrastructure → show references, confirm when select link
* Bring part with planes into Product file
* Make publication out of planes
* Tools, publication,
* Make new part
* Draw rectangle in new part
* Constraint it to the planes
* Pad → Up to Plane → select top plane
* Change plane definition
* Select Product
* Update Product

Osifchin Timothy
TXID: 2V2128140805202032P
tosifchin3@gmail.com

Assignment #: O2 LP06 ZZ