Osifchin, Timothy

TXID: 2V2128I408052032P

tosifchin3@gmail.com

Drill Index Assignment

* New Part
* Sketch on horizontal plane
* Draw rectangle with Filleted corners
* Dimension rectangle and corner radii
* Pad with thickness 0.0625"
* Pattern pad down 0.75"
* Pattern pad down 1.0"
* New sketch on Top plate
* Circle for column
* Pad up to last
* Back into first sketch
* Create reference dimensions
* Pattern column
* Spacing is reference dimensions
* Make Hole Up to bottom Plate
* Pattern Hole according to instruction pdf

O. Chin, Timothy

TXID: 2V21281408052032P
tosifchin3@gmail.com