SECTION 23 63 13 - AIR-COOLED REFRIGERANT CONDENSERS

PART 1 - GENERAL

1.1 RELATED DOCUMENTS

A. Drawings and general provisions of the Contract, including General and Supplementary Conditions and Division 01 Specification Sections, apply to this Section.

1.2 SUMMARY

A. This Section includes packaged, air-cooled condensers for outdoor installation.

1.3 SUBMITTALS

- A. Product Data: For each air-cooled condenser, include rated capacities, operating characteristics, furnished specialties, and accessories. Include equipment dimensions, weights and structural loads, required clearances, method of field assembly, components, and location and size of each field connection.
- B. Shop Drawings: Signed and sealed by a qualified professional engineer.
 - 1. Design Calculations: Calculate requirements for selecting vibration isolators and for designing vibration isolation bases.
 - 2. Vibration Isolation Base Details: Detail fabrication including anchorages and attachments to structure and to supported equipment. Include auxiliary motor slides and rails and equipment mounting frames.
 - 3. Wiring Diagrams: Power, signal, and control wiring.
- C. Coordination Drawings: Schematic drawing, on which the following items are shown and coordinated with each other, based on input from installers of the items involved:
 - 1. Structural members to which air-cooled condensers will be attached.
 - 2. Liquid and vapor pipe sizes.
 - 3. Refrigerant specialties.
 - 4. Piping including connections, oil traps, and double risers.
 - 5. Compressors.
 - 6. Evaporators.
- D. Field quality-control test reports.
- E. Operation and Maintenance Data: For air-cooled condensers to include in emergency, operation, and maintenance manuals.

1.4 QUALITY ASSURANCE

- A. Product Options: Drawings indicate size, profiles, and dimensional requirements of air-cooled condensers and are based on the specific system indicated. Refer to Division 01 Section "Product Requirements."
- B. Electrical Components, Devices, and Accessories: Listed and labeled as defined in NFPA 70, Article 100, by a testing agency acceptable to authorities having jurisdiction, and marked for intended use.
- C. Fabricate and label refrigeration system according to ASHRAE 15, "Safety Code for Mechanical Refrigeration."

1.5 COORDINATION

- A. Coordinate size and location of concrete bases. Cast anchor-bolt inserts into bases. Concrete, reinforcement, and formwork requirements are specified in Division 03.
- B. Coordinate installation of roof curbs, equipment supports, and roof penetrations. These items are specified in Division 07 Section "Roof Accessories."
- C. Coordinate location of refrigerant piping and electrical roughins.

PART 2 - PRODUCTS

2.1 MANUFACTURERS

- A. Available Manufacturers: Subject to compliance with requirements, manufacturers offering products that may be incorporated into the Work include, but are not limited to, the following:
- B. Manufacturers: Subject to compliance with requirements, provide products by one of the following:
 - 1. Bohn Refrigeration Products; Heatcraft, Inc.
 - 2. Carrier Corporation; Carrier Air Conditioning Div.
 - 3. Colmac Coil Manufacturing, Inc.
 - 4. Coolenheat Inc.
 - 5. Dunham-Bush, Inc.
 - 6. Engineered Air.
 - 7. McQuay International.
 - 8. Trane Co. (The); Worldwide Applied Systems Group.
 - 9. York International Corp.
 - 10. USA Coil & Air Inc.

2.2 MANUFACTURED UNITS

A. Description: Factory assembled and tested; consisting of casing, condenser coils, condenser fans and motors, and unit controls.

- B. Condenser Coil: Seamless copper-tube, finned coil; factory tested at 425 psig (2930 kPa).
 - 1. Coil Fin: Aluminum.
 - 2. Coil Coating: Epoxy
 - 3. Circuit: To match compressors with liquid subcooling coil.
 - 4. Refrigerant Accessories: Provide receiver, pressure control, and solenoid valve for each circuit.
- C. Condenser Fans and Drives: Propeller fans with **aluminum or galvanized-steel** fan blades, for **vertical** air discharge; directly driven with permanently lubricated ballbearing motors with integral current- and thermal-overload protection.
- D. Operating and Safety Controls: Include condenser fan motor thermal and overload cutouts; 115-V control transformer, if required; magnetic contactors for condenser fan motors and a nonfused factory-mounted and -wired disconnect switch for single external electrical power connection.
- E. Unit Casings: Galvanized or zinc-coated steel treated and finished with manufacturer's standard paint coating, designed for outdoor installation with weather protection for components and controls, and with the following:
 - 1. Removable panels for access to controls, condenser fans, motors, and drives.
 - 2. **Plated**-steel fan guards.
 - 3. Lifting eyes.
 - 4. Removable legs.

2.3 MOTORS

- A. General requirements for motors are specified in Division 23 Section "Common Motor Requirements for HVAC Equipment."
 - 1. Motor Sizes: Minimum size as indicated. If not indicated, large enough so driven load will not require motor to operate in service factor range above 1.0.
 - 2. Controllers, Electrical Devices, and Wiring: Electrical devices and connections are specified in Division 26 Sections.

2.4 SOURCE QUALITY CONTROL

- Verification of Performance: Rate air-cooled condensers according to ARI 340/360.
- B. Testing Requirements: Factory test sound-power-level ratings according to ARI 270.

PART 3 - EXECUTION

3.1 EXAMINATION

- A. Examine substrates, areas, and conditions, with Installer present, for compliance with requirements for installation tolerances and other conditions affecting performance of air-cooled condensers.
- B. Examine roughing-in for refrigerant piping systems to verify actual locations of piping connections before equipment installation.
- C. Examine walls, floors, and roofs for suitable conditions where air-cooled condensers will be installed.
- D. Proceed with installation only after unsatisfactory conditions have been corrected.

3.2 INSTALLATION

- A. Install units level and plumb, firmly anchored in locations indicated; maintain manufacturer's recommended clearances.
- B. Install air-cooled condensers on concrete base. Concrete base is specified in Division 23 Section "Common Work Results for HVAC," and concrete materials and installation requirements are specified in Division 03.

C. Concrete Bases:

- 1. Install dowel rods to connect concrete base to concrete slab. Unless otherwise indicated, install dowel rods on 18-inch (450-mm) centers around full perimeter of the base.
- 2. For equipment supported on structural slab, install epoxy-coated anchor bolts that extend through concrete base and anchor into structural concrete floor.
- 3. Place and secure anchorage devices. Use setting drawings, templates, diagrams, instructions, and directions furnished with items to be embedded.
- 4. Install anchor bolts to elevations required for proper attachment to supported equipment.
- 5. Install anchor bolts according to anchor-bolt manufacturer's written instructions.
- D. Install roof-mounting units on equipment supports specified in Division 07.
- E. Vibration Isolation: Mount air-cooled condensers on rubber pads with a minimum deflection of **1/4 inch (6.35 mm)**. Vibration isolation devices and installation requirements are specified in Division 23 Section "Vibration and Seismic Controls for HVAC Piping and Equipment."
- F. Vibration Isolation: Mount air-cooled condensers on restrained spring isolators with a minimum deflection of 1/4 inch. Vibration isolation devices and installation requirements are specified in Division 23 Section "Vibration and Seismic Controls for HVAC Piping and Equipment."
- G. Maintain manufacturer's recommended clearances for service and maintenance.
- H. Loose Components: Install electrical components, devices, and accessories that are not factory mounted.

3.3 CONNECTIONS

- A. Piping installation requirements are specified in other Division 23 Sections. Drawings indicate general arrangement of piping, fittings, and specialties.
- B. Install piping adjacent to machine to allow service and maintenance.
- C. Refrigerant Piping: Connect piping to unit with pressure relief, service valve, filter-dryer, and moisture indicator on each refrigerant-circuit liquid line. Refrigerant piping and specialties are specified in Division 23 Section "Refrigerant Piping."
- D. Ground equipment according to Division 26 Section "Grounding and Bonding for Electrical Systems."
- E. Connect wiring according to Division 26 Section "Low-Voltage Electrical Power Conductors and Cables."

3.4 FIELD QUALITY CONTROL

- A. Perform the following field tests and inspections and prepare test reports:
 - 1. Perform electrical test and visual and mechanical inspection.
 - 2. Leak Test: After installation, charge system and test for leaks. Repair leaks and retest until no leaks exist.
 - 3. Operational Test: After electrical circuitry has been energized, start units to confirm proper motor rotation and unit operation. Complete manufacturer's starting checklist.
 - 4. Test and adjust controls and safeties. Replace damaged and malfunctioning controls and equipment.
 - 5. Verify proper airflow over coils.
- B. Verify that vibration isolation and flexible connections properly dampen vibration transmission to structure.
- C. Remove and replace malfunctioning air-cooled condensers and retest as specified above.

3.5 STARTUP SERVICE

- A. Complete installation and startup checks according to manufacturer's written instructions and perform the following:
 - 1. Inspect for physical damage to unit casing.
 - 2. Verify that access doors move freely and are weathertight.
 - 3. Clean units and inspect for construction debris.
 - 4. Verify that all bolts and screws are tight.
 - 5. Adjust vibration isolation and flexible connections.
 - 6. Verify that controls are connected and operational.
- B. Lubricate bearings on fans.
- C. Verify that fan wheel is rotating in the correct direction and is not vibrating or binding.

- D. Start unit according to manufacturer's written instructions and complete manufacturer's startup checklist.
- E. Measure and record airflow over coils.
- F. Verify proper operation of capacity control device.
- G. Verify that vibration isolation and flexible connections properly dampen vibration transmission to structure.
- H. After startup and performance test, lubricate bearings.

3.6 DEMONSTRATION

A. Engage a factory-authorized service representative to train Owner's maintenance personnel to adjust, operate, and maintain air-cooled condensers. Refer to Division 01 Section "Demonstration and Training."

END OF SECTION