### PART 1 - GENERAL

#### 1.1 GENERAL

This Section covers the requirements for the construction, maintenance, and removal of a Haul Road required for the Project.

#### 1.2 RELATED DOCUMENTS

The Plans and General Provisions of the Contract, apply to the Work of this Section.

#### 1.3 DESCRIPTION

- A. The Contractor shall perform all Work required to complete the Project as indicated by the Contract Documents and furnish all items necessary for the completion of all work specified in this Section.
- B. The Contractor shall complete all the Work included in this Section including furnishing all labor, tools, materials and incidentals required for installation, maintenance, and removal of a temporary all-weather Haul Road including the restoration of the area to its original condition at the completion of the Project.

#### 1.4 SUBMITTALS

The proposed plans and specifications for the all-weather Haul Road and Contractor's Stormwater Pollution Prevention Plans (SWPPP) shall be submitted for review and acceptance by the OAR.

#### PART 2 - PRODUCTS

Not Used.

#### **PART 3 - EXECUTION**

#### 3.1 NEW HAUL ROAD

- A. The temporary all-weather Haul Road shall be constructed as shown on the Plans including construction entrances at egresses to public access roads and the Air Operation Area (AOA), curb cuts at egresses onto public access roads, ditches, and erosion control measures along the Haul Road.
- B. The Contractor shall reconstruct the curbs at the curb-cuts when the Haul Road is removed.

## 3.2 EXISTING HAUL ROAD

- A. If an existing Haul Road(s) will be used as a part of the Project, prior to the start of the Work, the Contractor shall take photo or video documentation of the existing Haul Road.
- B. The Contractor shall maintain the existing Haul Road(s) throughout the Project and shall return the existing Haul Road(s) to the condition prior to the Contractor's use of such road(s).
- C. The restoration of the existing Haul Road shall be performed at the end of use by the Contractor or when directed by the Owner's Authorized Representative (OAR).

HAUL ROAD Section: 01 52 16

# **PART 4 – MEASUREMENT AND PAYMENT**

Not Used.

- END OF SECTION -