SECTION 21 34 00 - PRESSURE-MAINTENANCE PUMPS

PART 1 - GENERAL

1.1 RELATED DOCUMENTS

A. Drawings and general provisions of the Contract, including General and Supplementary Conditions and Division 01 Specification Sections, apply to this Section.

1.2 SUMMARY

- A. Section Includes:
 - 1. Vertical, multistage, pressure-maintenance pumps.
- B. Related Requirements:
 - 1. Section 21 39 00 "Controllers for Fire-Pump Drivers" for pressure-maintenance-pump controllers.

1.3 ACTION SUBMITTALS

- A. Product Data: For each type of product. Include rated capacities, operating characteristics, performance curves, electrical characteristics, and furnished specialties and accessories.
- B. Shop Drawings: For pumps, accessories, and specialties.
 - 1. Include plans, elevations, sections, and attachment details.
 - Include details of equipment assemblies. Indicate dimensions, weights, loads, required clearances, method of field assembly, components, and location and size of each field connection
 - 3. Include diagrams for power, signal, and control wiring.

1.4 CLOSEOUT SUBMITTALS

A. Operation and Maintenance Data: For pumps to include in operation and maintenance manuals.

PART 2 - PRODUCTS

2.1 VERTICAL, MULTISTAGE, PRESSURE-MAINTENANCE PUMPS

- A. Manufacturers: Subject to compliance with requirements, provide products by one of the following: A-C Fire Pump; a Xylem brand.
 - 2. Aquarius Fluid Products, Inc.
 - 3. Grundfos Management A/S.
 - 4. Pentair Pumps

- B. Description: Factory-assembled and -tested, multistage, barrel-type vertical pump as defined in HI 2.1-2.2 and HI 2.3; designed for surface installation with pump and motor direct coupled and mounted vertically.
- C. Pump Construction:
 - 1. Barrel: Stainless steel.
 - 2. Suction and Discharge Chamber: Cast iron with flanged inlet and outlet.
 - 3. Pump Head/Motor Mount: Cast iron.
 - 4. Impellers: Stainless steel, balanced, and keyed to shaft.
 - 5. Pump Shaft: Stainless steel.
 - 6. Seal: Mechanical type with carbon rotating face and silicon-carbide stationary seat.
 - 7. Wear Rings: Teflon.
 - 8. Intermediate Chamber Bearings: Aluminum-oxide ceramic or bronze.
 - 9. Chamber-Base Bearing: Tungsten carbide.
 - 10. O-Rings: EPDM.
- D. Electrical Components, Devices, and Accessories: Listed and labeled as defined in NFPA 70, by a qualified testing agency, and marked for intended location and application.
- E. Motor: Single speed with permanently lubricated ball bearings and rigidly mounted to pump head. Comply with requirements in Section 210513 "Common Motor Requirements for Fire Suppression Equipment."
- F. Power Cord: Factory-connected to motor for field connection to controller and at least 10 feet long.
- G. Nameplate: Permanently attached to pump and indicating capacity and characteristics.
- H. Capacities and Characteristics: Refer to drawings.

2.2 MOTORS

- A. Comply with NEMA designation, temperature rating, service factor, enclosure type, and efficiency requirements for motors specified in Section 210513 "Common Motor Requirements for Fire Suppression Equipment."
 - 1. Motor Sizes: Minimum size as indicated; if not indicated, large enough so driven load will not require motor to operate in service factor range above 1.0.

PART 3 - EXECUTION

3.1 EQUIPMENT INSTALLATION

- A. NFPA Standard: Comply with NFPA 20 for installation of pressure-maintenance pumps.
- B. Equipment Mounting:
 - 1. Install multistage, pressure-maintenance pumps according to HI 1.4.
 - 2. Install base-mounted pumps on cast-in-place concrete equipment base(s). Comply with requirements for equipment bases and foundations specified in Section 033000 "Cast-in-Place Concrete."

- a. For supported equipment, install epoxy-coated anchor bolts that extend through concrete base and anchor into structural concrete floor.
- b. Place and secure anchorage devices. Use setting drawings, templates, diagrams, instructions, and directions furnished with items to be embedded.
- c. Install anchor bolts to elevations required for proper attachment to supported equipment.
- d. Attach pumps to equipment base using anchor bolts.
- e. Shim pumps as needed to make them level.
- 3. Install isolation valves in both inlet and outlet pipes near the pump. Comply with requirements for valves specified in Section 211313 "Wet-Pipe Sprinkler Systems."

3.2 FIELD QUALITY CONTROL

- A. Manufacturer's Field Service: Engage a factory-authorized service representative to test and inspect components, assemblies, and equipment installations, including connections.
- B. Perform the following tests and inspections with the assistance of a factory-authorized service representative:
 - 1. Operational Test: After electrical circuitry has been energized, start units to confirm proper motor rotation and unit operation.
 - Test and adjust controls and safeties. Replace damaged and malfunctioning controls and equipment.
 - 3. Pressure-maintenance pumps will be considered defective if they do not pass tests and inspections.
- C. Prepare test and inspection reports.

3.3 ADJUSTING

- A. Lubricate pumps as recommended by manufacturer.
- B. Set field-adjustable pressure-switch ranges as indicated.

END OF SECTION