



说明:该文档以添加ffe0服务为例,客户如果需要添加其他类型的服务可以参考说明进行添加。

- 1. 准备FFE0文件夹, FFE0文件夹下包含api:ffe0s.h、ffe0s_task.h和src:ffe0s.c、ffe0s task.c。将FFE0文件夹复制到\sdk\ble stack\com\profiles目录下。
- 2. 准备app_ffe0 .c、app_ffe0 .h文件,将两个文件复制到\projects\ble_app_gatt\app目录下。
- 3. 将ffe0s.c、ffe0s_task.c、app_ffe0.c文件添加到工程目录profile和app文件夹下,如下图。



4. 将ffeOs.h、ffeOs_task.h文件添加到工程,添加方式参考下图。





52:<u>-#if (1)</u>

#end1f

54:

53: #define CFG PRF ffe0

5. 在rwprf_config.h文件夹下添加服务的宏定义#define CFG_PRF_ffe0和

#define BLE_ffe0_SERVER 1 , 宏名称客户需要根据自己添加的服务进行修改。
app_gatt\app) | arch_main.c (projects\ble_app_gatt\app) | rwprf_config.h (projects\...\config) × | uart.

46: #define CFG_PRF_FFE0

47: #endif
48:
49: // <e> CFG_PRF_ffe0
50: // <i> ffe0 profile Locator Role
51: // </e>

6. 在rwip_task.h文件的enum TASK_API_ID枚举下添加TASK_ID_ffe0S = 70,枚 举成员,如下图。

```
rwip_task.h (sdk\ble_stack\com\rwip\api) × rwprf_config.h (projects\...\confi
ble_app_gatt\app)
                                           // FFE0 Profile Server Task
           TASK_ID_FFE0S
                                  = 70,
                                  = 71,
 128:
           TASK_ID_OADS
                                           // OADS Profile Server Task
                                  = 72,
 129:
           TASK ID WECHAT
                                           //WECHAT profile Server Task
 130:
           TASK ID ANCSC
                                  = 73,
                                           //Ancs Client
 131:
           TASK ID FCC0S
                                  = 74,
                                           //FFC0 PROFILE SERVICE TASK
           TASK TD FFF0S
                                    75
 132:
                                            //FFF0 PROFTLE SERVICE TASK
 133:
           TASK ID ffe0S
                                    76,
                                              ffe0 Profile Server Task
 134:
 135:
           /* 240 -> 241 reserved for Audio Mode 0 */
 136:
           TASK ID AM0
                                  = 240, // BLE Audio Mode 0 Task
```

7. 在prf.c文件的prf_itf_get函数下添加prf_cbs = ffe0s_prf_itf_get()函数和在prf.c文件 外部声明ffe0s_prf_itf_get()函数。



8. 在app_task.c文件的appm_msg_handler函数下添加 msg_pol = appm_get_handler(&app_ffe0_table_handler, msgid, param, src_id);

9. 在app.c文件的enum appm_svc_list的枚举类型添加APPM_SVC_ffe0枚举成员和在 appm_add_svc_func_list[]数组里面添加(appm_add_svc_func_t)app_ffe0_add_ffe0s,

```
74: /// List of service to add in the database
 75:<sub>□</sub>enum appm_svc_list
76: {
         APPM SVC FFF0
        APPM SVC ffe0.
         APPM SVC DIS,
         APPM_SVC_BATT,
         APPM_SVC_OADS
         APPM_SVC_LIST_STOP ,
83: \ };
84:
94: /// List of functions used to create the database
95: static const appm_add_svc_func_t appm_add_svc_func_list[APPM_SVC_LIST_STOP] =
96: {
97:
         (appm add svc func t)app fff0 add fff0s
         (appm_add_svc_func_t)app_ffe0_add_ffe0s,
         (appm_add_svc_tunc_t)app_dis_add_dis,
         (appm_add_svc_func_t)app_batt_add_bas,
         (appm add svc func t)app oad add oads,
102: };
```

10. 在app.c文件和app_task.c文件下添加头文件

```
app.c (projects\ble_app_gatt\app) × app_ff80.c (projects\ble_app_gatt\app) app_task.c (projects\ble_app_gatt\app)
      38: #include <mark>"co_math.h</mark>
                                                         // Common Maths Definition
      39: #include "ke_timer.h"
          #include "ann fff0 h"
     40 #include app_ffe0.h"
                                                          // Application security Definition
                                                          // Application security Definition
                                                          // Application security Definition
                       арр_ттой.п
      43: #include "app_dis.h"
                                                         // Device Information Service Application Defi
     44: #include "app_batt.h"
45: #include "app oads.h"
                                                         // Battery Application Definitions
                                                          // Application oads Definition
c (projects\ble_app_gatt\app) | app_ff80.c (projects\ble_app_gatt\app) | app_task.c (projects\ble_app_gatt\app) ×
     #include "ke_timer.h"
#include "app_fff0 h"
                                               // Kernel timer
                                                // fff0 Module Definition
     #include "app_ffe0.h"
                                                // ffe0 Module Definition
                  app_ff80.h
                                                // ffe0 Module Definition
      #Include
      #include "fff0s_task.h"
     #include "ffe0s_task.h"
#include #180s_task.n
 37: #include <mark>"app_dis.h"</mark>
38: #include <mark>"diss_task.h"</mark>
                                               // Device Information Module Definition
 39: #include "app_batt.h"
                                               // Battery Module Definition
```