

- Connect the ZigBee module application asks for permission to access ACCEPT it.
- > Then Application will automatically open.
- > Go to setting tab and enter admin password.
- ➤ In Connection setting, Select Serial Port Connection.
- ➤ When connected to machine. Application automatically goes to the Stirrer Casting Machine tab.