

- Connect to WIFI network in your place.
- > Get IP address of WIFI module in the machine.
- > Go to setting tab and enter admin password.
- ➤ In Connection setting, Select Via WIFI Connection.
- ➤ Application asks for IP Address to connect to machine. Enter the IP Address get from the machine.
- ➤ When connected to machine. Application automatically goes to the Stirrer Casting Machine tab.