

User Manual

Android Car Stereo Radio Function Manual



User Manual

User Manual

FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

User Manual

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. In order to avoid the possibility of exceeding the FCC radio frequency exposure limits, Human proximity to the antenna shall not be less than 20cm(8 inches)during normal operation. That changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

User Manual

Table of Contents

- FCC STATEMENT** 1
- Table of Contents** 3
- Preface** 8
- Safety Precautions 9
 - 1) Safety Precautions 9
 - 2) Prioritize Traffic Safety 9
 - 3) Operate the System Only When Parked 9
 - 4) Keep the Device Out of Children’s Reach 10
 - 5) Follow Traffic Rules When Using Navigation 10
 - 6) Do Not Attempt Self-Maintenance or Installation 10
 - 7) Avoid Exposure to Direct Sunlight or Harmful Environments 10
 - 8) Handle the Display with Care 11
- 1. Basic Operations** 11
 - (1) System Reset 12
 - (2) Power On/Off the Device 12
 - (3) Volume Adjustment 12
 - (4) Power Button Functions 12
- 2. Home Launcher UI View** 13
 - 2.1. Status Bar Area 14
 - 2.2. Navigation Bar Area 14
 - 2.3. UI Model Area 14

User Manual

2.4. Music and Compass Widgets	14
2.5. Shortcut Function Area	15
2.6. System Control Area	15
2.7. Important Notes	15
3. App page	16
4. App Store	17
5. AUX	18
6. Bluetooth	19
6.1 Bluetooth Phone Interface	19
6.2 Bluetooth Contacts	20
6.3 Bluetooth Call History	21
6.4 Bluetooth Music	22
6.5 Bluetooth Devices	23
6.6 Bluetooth Settings	24
7. Car link 2.0	25
7.1 What Are Android Auto and Apple CarPlay?	25
7.2 How CarLink 2.0 Works	25
7.3 Operation	26
A. Wired Connection:	26
B. Wireless Connection:	26
7.4 Wireless CarLink 2.0 Working Principle	28
8. Chrome	29
9. Gallery	29
10. Operation Guide	29
11. Equalizer	30
11.1 DSP EQ – 15-Band Adjustment	31

Version V2.3.1 —January 2026

User Manual

11.2 ASP – Preset Sound Modes	31
11.3 Field – Sound Position Adjustment	31
12. Google Map	32
13. File Manager	33
14. Music Player	34
15. Video Playback	35
16. Phonelink	36
17. Radio	37
17.1. Radio Operation Guide	38
17.2 radio settings	39
18. Settings	40
18.1 Settings-WLAN	40
18.2 Settings-Device	41
18.2.1 sound settings	42
18.2.2 GPS	43
18.2.3 USB Video Out Settings	44
18.3 settings-General	45
Settings – General Detailed Functionality	46
18.4 Factory Settings	49
18.4.1 Factory-Original Car Agreement	50
18.4.2 Factory-Car Model	53
18.4.3 Boot Screen Logo	54
18.4.4 Set Screen	55
18.4.5 Touch Screen Calibration	56
18.4.6 Panel Key Learning	57
18.4.7 Sleep Mode Setting	57

User Manual

18.4.8 Front View	58
18.4.9 Cancel the Reverse into the Front View	58
18.4.10 Local Reverse switch	59
18.4.11 Door lock interference	61
18.4.12 Plug-in Serial Device Setting	62
18.4.13 Volume Balance Settings	62
18.4.14 MCU upgrade	62
18.4.15 Backlight current adjustment	63
18.4.16 usb protocol selection	64
18.4.17 A key to export	64
18.4.18 HD Reversing Video Format	64
18.5 Factory-User	66
18.6 Factory-System	67
19. Diagram of Pinout Definitions on the Back of the Head Unit	68
19.1 Power Socket Pinout	68
19.2 20-Pin RCA Audio Socket Pinout	69
19.3 8-Pin CAN Bus Connector Pinout	70
19.4 4-Pin USB Port Pinout	71
19.5 6-Pin USB Port Pinout	72
19.6 10-Pin Rear Camera Port Pinout	73
20. Car Android Head Unit – Frequently Asked Questions (FAQ)	74
1. Device Won't Turn On	74
2. No Sound from the Device	75
3. Reverse Camera Not Displaying / Black Screen	75
4. WiFi Won't Connect	77
5. Bluetooth Won't Connect to Phone	77

User Manual

- 6. Touchscreen Unresponsive / Inaccurate 78
- 7. Device is Slow or Freezes 79
- 8. USB Device Not Recognized 80
- 9. GPS Navigation Not Working 81
- 10. Cannot Play Video / Format Not Supported 82
- 11. Steering Wheel Controls Not Working 82
- 12. Device Won't Enter Sleep Mode 83
- 13. Remote Key Cannot Unlock Car Doors 84
- 14. System Time Is Incorrect 84
- 15. Boot Logo Does Not Display 85
- 16. Reverse Guidelines Cannot Be Adjusted 86
- 17. Device Boots into Recovery Mode Automatically 86
- 18. Device Restarts Randomly 87
- 19. No Radio Signal 87
- 20. Screen Goes Black / System Crashes When Reversing 88
- 21. Specifications 89

User Manual

Preface

Welcome to your Android Car Navigation System.

- This device combines navigation, multimedia entertainment, communication, and vehicle information display, providing a convenient and intelligent in-car experience.
- Please read this manual carefully before use to ensure safe operation and optimal performance.
- For any questions or technical support, please contact our customer service team.
- Thank you for choosing our product.
- Drive safely and enjoy your journey!

User Manual

Safety Precautions

1) Safety Precautions

For your safety, avoid watching videos or operating the device while driving. Keep the volume at a level that still allows you to hear external sounds clearly.

As the product evolves, system updates will be released periodically. This manual serves as a reference, but the actual product may vary slightly.

2) Prioritize Traffic Safety

Always follow traffic laws and drive responsibly while using this device.

3) Operate the System Only When Parked

If you encounter difficulties while using the system, pull over to a safe location before making any adjustments.

User Manual

4) Keep the Device Out of Children's Reach

Do not allow children to operate the device to prevent injury or damage.

5) Follow Traffic Rules When Using Navigation

Always adhere to traffic regulations when using the navigation feature.

6) Do Not Attempt Self-Maintenance or Installation

Never attempt to install, maintain, or repair the device yourself. Performing installation or repairs while the power is connected is particularly dangerous. Improper handling by untrained individuals may result in serious risks to both the vehicle and the user.

7) Avoid Exposure to Direct Sunlight or Harmful Environments


Do not store or install the device in direct sunlight or in areas exposed to harmful substances, especially the LCD screen. If the screen is near an air vent, ensure that hot or cold air does not blow directly onto it, as this may damage the device or affect the vehicle and passengers.

User Manual

8) Handle the Display with Care

Do not scratch the display with sharp objects or press it forcefully, as this may damage the screen or touch panel.

1. Basic Operations



Version V2.3.1 —January 2026

User Manual

(1) System Reset

- If the device becomes unresponsive due to improper operation, briefly press the **RST** hole on the front panel with a pointed object (such as a pen tip) to restore normal operation.
- **Note:** The reset button is small. Use a pen tip or similar pointed object and press gently to avoid damage.

(2) Power On/Off the Device

- When the ACC is turned on:
- Briefly press the **POWER** button on the front panel to mute the system.
- Press the **POWER** button again to restore sound.
- Long press the **POWER** button to enter standby mode (screen off).
- Tap the touchscreen or press the **POWER** button again to wake the screen and return to the previous interface.

(3) Volume Adjustment

- Tap **VOL+** or **VOL-** on the touchscreen to adjust the volume.
- Long press **VOL+** or **VOL-** to continuously increase or decrease the volume.

(4) Power Button Functions


- Press the **POWER** button to mute the system.
- Press the **POWER** button again, or adjust the volume, to restore sound.

User Manual


- Long press the **POWER** button to turn off the screen.
- Press the **POWER** button again to turn the screen back on.Home Launcher UI View

2. Home Launcher UI View

Octa-core Head Unit Home UI Example



Home UI Function Area Overview



As shown in the diagram, the Home UI can be divided into **six areas**. A brief overview of each area is provided below. Detailed operation instructions are described in the following sections.

User Manual

2.1. Status Bar Area



- The Status Bar is located at the top of the screen. From left to right, it includes: **Home button**, WiFi connection indicator, **time**, **volume level display**, **multi-task window button**, and **Back button**.

2.2. Navigation Bar Area



- This is a fixed area containing icons to access key functions. The layout cannot be replaced.

2.3. UI Model Area

- Press and hold the vehicle model in this area to replace the displayed car model.

2.4. Music and Compass Widgets

- The music widget displays the currently playing song title and artist from internal storage or Bluetooth music. The compass widget provides real-time orientation based on GPS positioning.

User Manual

2.5. Shortcut Function Area

- Press and hold an icon in this area to replace it with frequently used apps for quick access.

2.6. System Control Area

- This fixed area contains **Volume + / Volume –**, **Home**, and **Back** buttons.
If your vehicle supports on-screen air-conditioning control (such as fan speed or temperature), additional AC control options will appear here after configuring the corresponding CANBUS settings.

2.7. Important Notes




This area displays the speed unit. Since different countries use different units, you can long press here to switch between km/h and MPH.

User Manual

3. App page

Tap the Apps button on the Home Screen to open the list of all applications on the head unit. You can swipe left or right on this page to view the preinstalled apps.



Note: Most preinstalled apps are system-level applications and cannot be uninstalled. User-installed apps can be removed as follows:



1. Open the **App Page**.
2. Press and hold the app you want to uninstall.
3. Drag the app to the **Trash** icon.
4. Release when the icon turns red, then tap **Confirm** to uninstall.

Version V2.3.1 —January 2026

User Manual

4. App Store

App Store is the built-in application store of the head unit. Users can update CANBUS and commonly used system-level apps through this store.




Note: CANBUS-related apps generally do not require frequent updates unless issues occur (such as steering wheel buttons or air-conditioning controls not functioning properly).

If you experience minor issues with **CarPlay** or **Android Auto**, check whether **Carlink** has an available update. It is recommended to keep Carlink updated to the latest version to ensure system stability.

User Manual

5. AUX

The head unit features a built-in **AUX** app, allowing you to play audio from external devices connected through the AUX port.



The head unit features a built-in **AUX** app that supports both audio and video input. Video signals are transmitted via the **CVBS-IN** interface, while audio is transmitted through the head unit's **AUX IN** port. This function is commonly used with external video boxes, game consoles, or other multimedia devices.

Operation:


1. To view video or listen to audio from an external device, open the **AUX** app. Content will only play while the **AUX** app is active.
2. Video and audio signals are transmitted separately: video through the **CVBS-IN** interface, audio through the **AUX IN** interface. Ensure both connections are properly made to use this function.
3. While playing content in the **AUX** app, playback from other audio sources (such as Bluetooth, USB, or internal media) will be temporarily paused. Playback will resume once you exit the **AUX** app.
4. Adjust volume either through the head unit controls or the external device if necessary.
5. This function allows seamless integration of external multimedia devices into the head unit display, providing both visual and audio output.

User Manual

6. Bluetooth

The head unit features built-in **Bluetooth** functionality, allowing you to connect your smartphone or other Bluetooth-enabled devices for hands-free calls, audio streaming, and phonebook synchronization.

6.1 Bluetooth Phone Interface



6.1 Bluetooth Phone Interface


The **Bluetooth Phone** interface allows you to make and receive calls through the head unit using a connected smartphone. It provides access to your phonebook, recent calls, and keypad for manual dialing. This interface ensures safe, hands-free communication while driving.

1. Open the **Bluetooth** app on the head unit.
2. Tap the **Phone** tab to access the Bluetooth phone interface.
3. To make a call:
 - Enter the phone number using the on-screen keypad, or
 - Select a contact from the synced phonebook.
4. Tap the **Call** button to initiate the call.
5. During a call, you can:
 - Tap **Speaker** to switch between the head unit speaker and the phone,
 - Tap **End** to hang up.

User Manual

6.2 Bluetooth Contacts

The **Bluetooth Contacts** page allows you to view and select contacts from your connected smartphone. You can quickly search for contacts, view their details, and initiate calls directly from this interface. This provides a convenient and safe way to access your contacts while driving.




1. Open the **Bluetooth** app and tap the **Contacts** tab.
2. Scroll through the contact list or use the search function to find a contact.
3. Tap a contact to immediately initiate a call to that contact.

Notes:

- Ensure your smartphone's contacts are synchronized with the head unit for accurate information.
- Only contacts stored on the connected device will be available.

User Manual

6.3 Bluetooth Call History



The **Call History** page displays recent calls from your connected smartphone, categorized into **Incoming**, **Missed**, and **Outgoing** calls. You can quickly review call activity and initiate calls directly from this interface. The page also provides a **Clear** button to delete call history entries.

1. Open the **Bluetooth** app and tap the **Call History** tab.
2. Select one of the categories: **Incoming**, **Missed**, or **Outgoing** to filter the call list.
3. Scroll through the list to view call entries.
4. Tap an entry to immediately initiate a call to that number.
5. To delete all entries, tap the **Clear** button.


Notes:

- Only call history from the connected device will be displayed.
- Clearing the call history will remove all entries permanently.
- The number of entries may be limited depending on the smartphone.

User Manual

6.4 Bluetooth Music

The **Bluetooth Music** feature allows you to play audio from a connected smartphone or other Bluetooth-enabled device through the head unit. It supports wireless music streaming and provides basic playback controls directly on the head unit. **Note that music will only play when the **Bluetooth Music** tab is active on the head unit.**



1. Open the **Bluetooth** app on the head unit and select the **Music** tab.
2. Ensure your device is connected via Bluetooth.
3. Use the playback controls on the head unit to:
 - **Play / Pause** music
 - **Next / Previous** track
 - **Adjust volume** using the head unit controls
4. While Bluetooth music is playing, audio from other sources (e.g., USB, SD, AUX) will be paused.


Important Note:

After connecting a device via Bluetooth, audio may not play automatically because the system remains on the previous audio source. To hear music from the connected device, open the **Bluetooth Music** tab on the head unit to activate the audio output.

User Manual

6.5 Bluetooth Devices

The **Bluetooth Devices** page allows you to manage all Bluetooth devices paired with the head unit. You can search for new devices, connect, disconnect, or clear paired devices directly from this interface. This provides full control over multiple Bluetooth connections.



1. Open the **Bluetooth** app and tap the **Devices** tab.
2. The page displays a list of paired devices.
3. **Search**: Tap **Search** to search for new Bluetooth devices.
4. **Link**: Select a device from the list and tap **Link** to connect.
5. **Cut**: Select a connected device and tap **Cut** to disconnect.
6. **Clear**: Tap **Clear** to remove all paired devices. Note that deleted devices must be paired again to reconnect.


Notes:

- Only devices previously paired with the head unit will appear in the list.
- Clearing paired devices will remove all pairing information permanently.
- Ensure devices are within Bluetooth range for successful connection.
- Some devices may require confirmation on the smartphone when pairing.

User Manual

6.6 Bluetooth Settings

The **Bluetooth Settings** page allows you to configure the head unit's Bluetooth system. You can set the device name, manage the pairing password, enable or disable auto answer, reset the Bluetooth system, and select or add a ringtone for incoming calls. These settings help customize Bluetooth behavior and ensure smooth operation.



1. Open the **Bluetooth** app and tap the **Settings** tab.
2. **Device Name**: Set the name displayed to other Bluetooth devices.
3. **Pairing Password**: Set or change the password used when pairing with new devices.
4. **Auto Answer**: Enable or disable automatic answering of incoming calls.
5. **BT Reset**: Reset the Bluetooth system to clear all paired devices and restore default settings.
6. **Ringtone**:
 - Tap **Ringtone** → **Set** to select a ringtone from the preloaded list.
 - **To add a custom ringtone**:
 - Open the **File Manager** and create a folder named “**brting**”.
 - Place your music or ringtone files inside this folder.
 - Return to **Bluetooth** → **Settings** → **Ringtone** → **Set** and select your preferred ringtone.

Notes : Auto Answer may automatically pick up calls even while driving; use responsibly.

Only supported audio formats can be used for custom ringtones. Ensure ringtone files are placed in the “**brting**” folder.

User Manual

7. Car link 2.0



CarLink 2.0 is the in-car smartphone connectivity feature that enables your compatible Android or iOS device to connect to the head unit and use **Android Auto** (for Android phones) or **Apple CarPlay** (for iPhones). After connecting, you control supported phone apps — such as navigation, music, calls, and messages — directly from the head unit interface. This improves safety and convenience while driving.

7.1 What Are Android Auto and Apple CarPlay?

Android Auto and **Apple CarPlay** are smartphone interfaces developed by Google and Apple, respectively, to provide a driver-friendly, simplified display of selected phone apps on the vehicle's head unit. These systems allow navigation, music, calls, messaging, and voice control (e.g., Google Assistant or Siri) to be safely used while driving.

7.2 How CarLink 2.0 Works

Wired Connection:

For a **wired connection**, simply connect your smartphone to the head unit using a compatible USB data cable. When prompted on your phone, confirm the connection. The head unit then activates Android Auto or Apple CarPlay over the USB link, and the phone's supported apps are accessible on the car display. This method is reliable and provides the most stable connection with minimal latency.

User Manual

Wireless Connection:

For **wireless connection**, the system typically uses **Bluetooth** first to establish initial pairing and negotiate supported features, then switches to **Wi-Fi** for data transmission of Android Auto or Apple CarPlay. Wireless connections eliminate the need for a cable but depend on both Bluetooth and Wi-Fi signals to remain active. Wireless setup may take a few extra seconds to establish compared to wired mode.

7.3 Operation

A. Wired Connection:


1. Use a compatible USB cable to connect your phone to the head unit.
2. On your phone, tap **Confirm** / **Allow** when a connection prompt appears.
3. The head unit will switch to Android Auto or Apple CarPlay.
4. Use supported apps from the head unit screen.

B. Wireless Connection:

1. Turn on the Bluetooth function on the head unit and pair it with your phone's Bluetooth (password: 0000).
- **Note:** For Android Auto, ensure the Android Auto app is installed on your phone and your device supports it.
2. Open the **CarLink 2.0** app (or **Zlink 5** app) on the head unit to activate CarPlay / Android Auto.
3. On your phone, set the head unit as a **vehicle-mounted device (VMT)**:

User Manual

- Go to **Bluetooth**, tap on the device name, select **Device Type**, and choose **Car Stereo**.
- If a prompt appears, tap **“Turn on Wi-Fi & Use CarPlay”** to allow the head unit to use Wi-Fi for data transfer.



User Manual

7.4 Wireless CarLink 2.0 Working Principle

1. **Bluetooth is used for authentication, Wi-Fi is used for connection.**

Bluetooth is responsible only for identity verification and capability negotiation between the phone and the head unit. The actual CarPlay/Android Auto data transmission relies on Wi-Fi due to its higher bandwidth.

2. **Bluetooth is used only for the handshake process, and will be disconnected by the phone after a successful connection.**

Once the wireless connection is established, the phone automatically disconnects Bluetooth because it is no longer required for data transfer. This is normal system behavior, not a malfunction.

3. **While connected, the phone's Wi-Fi function cannot be used for other purposes.**

During CarPlay/Android Auto wireless operation, the phone cannot:

- connect to external Wi-Fi networks,
- use mobile hotspot,
- share internet via Wi-Fi.

The Wi-Fi module is exclusively occupied by the car connection.

4. User Reminder

- The Bluetooth “disconnected” status after connection is expected behavior.
- If you need to use phone hotspot or other Wi-Fi networks, please disconnect CarLink 2.0 first.


User Manual

8. Chrome



Chrome is the built-in web browser of the head unit. When connected to Wi-Fi or a mobile hotspot, it can be used for web search, online media playback, and downloading files or applications.

9. Gallery



Gallery is the built-in application for viewing image files stored on the device or external USB storage. It supports common picture formats and allows users to browse, zoom, and preview photos.

10. Operation Guide


The Operation Guide provides a brief overview of the main functions and basic usage of the head unit. It is designed to help users quickly understand the system interface and commonly used features, allowing for easier and more efficient daily operation.

User Manual

11. Equalizer



The Equalizer function is divided into three sections: **DSP EQ**, **ASP**, and **Field**, allowing users to fully customize the audio effect according to personal preference and the in-car environment.



Version V2.3.1 —January 2026

User Manual

11.1 DSP EQ – 15-Band Adjustment

The DSP EQ interface provides **15-band frequency adjustment**, enabling precise control of bass, midrange, and treble. Users can manually adjust each frequency band to create a personalized sound style.

- Supports independent adjustment of 15 frequency bands
- Real-time effect after adjustment
- Suitable for advanced users who prefer fine-tuning

11.2 ASP – Preset Sound Modes

ASP offers multiple preset sound effects for different music styles. Users can quickly select a suitable mode or further adjust parameters based on personal preference.

- Built-in modes such as Pop, Rock, Jazz, Classic, etc.
- Supports manual fine-tuning on the basis of presets
- Easy to use without complex settings


11.3 Field – Sound Position Adjustment

The Field interface allows users to adjust the sound focus position inside the vehicle, optimizing the listening experience for different seat locations.

User Manual

- Balance adjustment (left/right)
- Fader adjustment (front/rear)
- Simulates the best sound field position

12. Google Map



Google Maps is the built-in navigation application that provides real-time map data, route planning, and turn-by-turn navigation. When connected to the Internet, it supports online navigation, traffic information, and location search.

Notes:


- **This head unit does not include pre-installed offline maps.**
- **Online navigation and real-time traffic information require an active Internet connection.**
- **If offline navigation is needed, users can download offline maps directly within the Google Maps app in advance.**
- **Map data, traffic conditions, and routing results are provided by Google and may vary by region.**
- **For driving safety, please operate the navigation system only when the vehicle is safely parked.**

User Manual

13. File Manager



File Manager is the built-in tool for managing files stored on the head unit and external storage devices. It allows users to browse, copy, move, and delete files within internal storage or USB devices.



File Manager allows you to view and manage files stored on the head unit and supported external storage devices.

On the left side of the interface, different file directories are displayed for quick selection and navigation.

To copy or move a file, tap and select the target file. Once selected, a row of operation buttons will appear at the bottom of the screen.

Choose the destination directory, then tap the corresponding operation button to complete the action.

The File Manager supports common file operations such as browsing, copying, moving, and deleting files.

Notes


- Do not remove USB storage devices during file operations to avoid data loss.
- Some system files or directories may be restricted and cannot be modified.
- For driving safety, please operate the File Manager only when the vehicle is parked

User Manual

14. Music Player

Enter the music player by tapping the application icon on the Home screen or Apps page.

If there is no previous playback record, the system will enter the music list interface by default.



1. The playlist interface provides the following categories:

- **Song List**
Displays all music files stored in the internal storage of the head unit and connected external storage devices.
- **Folder List**
Displays all folders containing music files from internal storage and external storage devices.
- **Artist List**
Sorts and displays music files based on artist information.
- **Album List**
Sorts and displays music files based on album information.

2. Playback Interface


- Select a song from the list interface to enter the playback screen.
The playback interface displays basic information about the currently playing track along with commonly used control buttons.
- Users can control playback using the on-screen buttons and drag the progress bar to fast forward or rewind the current track.

User Manual

15. Video Playback



Video Playback allows users to play video files stored in the head unit's internal storage or external USB storage devices.




- The video player can recognize video files stored in the head unit's internal storage and external storage devices. It supports playback of common video formats such as 3GP, MP4, M4V, FLV, F4V, MKV, WebM, AVI, and others.
- The player features a simple and intuitive user interface, strong decoding capability, and supports high-definition video playback.
- In the video list interface, users can view video files by selecting the storage device on the left side of the screen. The interface displays both the video list and the corresponding folder list of the selected storage device.
- Note: As shown in the illustration, the left side displays the video list of the current storage device, while the right side shows the video folder list.
- Select a video from the list to enter the playback interface. The screen displays the video title, playback progress, and other basic information. Users can drag the progress bar to fast forward or rewind the video.
- Touching the screen will cause the control interface to automatically appear or hide, providing a clearer viewing experience.
- Tap the Picture-in-Picture button to minimize the video playback window and overlay it on top of other applications. Use the zoom and full-screen buttons in the upper-right corner of the picture-in-picture window to adjust the display size.
- The picture-in-picture function allows users to continue watching videos while operating navigation or other applications.

User Manual

16. Phonelink



PhoneLink is a screen mirroring function that allows the smartphone display to be mirrored onto the head unit screen. It does not provide native system integration or independent control like Android Auto or Apple CarPlay. PhoneLink supports multiple connection methods, including **Android USB**, **Android Wi-Fi**, and **iPhone Wi-Fi**, depending on the mobile device and system compatibility.



PhoneLink is a screen mirroring feature that displays the smartphone screen on the head unit.

It supports **Android USB**, **Android Wi-Fi**, and **iPhone Wi-Fi** connections, depending on the phone model and system compatibility.

How to Use

Launch the **PhoneLink** app on the head unit.

Follow the on-screen instructions to connect your smartphone using a supported method (USB or Wi-Fi).

Once connected, the smartphone screen will be mirrored on the head unit.



PhoneLink only mirrors the phone display and does not provide system-level integration like Android Auto or Apple CarPlay.

User Manual

17. Radio



The radio function supports FM bands, allowing users to manually or automatically search for stations and save favorite channels. Users can adjust the frequency to receive local broadcasts, enjoying news, music, traffic updates, and more. This feature relies on the car's antenna, and signal quality may vary depending on geographical location.



Users can configure radio-related options such as region settings, search behavior, and station management.

These settings help optimize radio reception based on local broadcast standards.


User Manual

17.1. Radio Operation Guide

FM Radio PTY TA AF	🔍 📶 🔗 📝 📁 ⚙️
● FM: Tap this button to switch between the preset list of 18 FM stations ● PTY (Program Type): Displays the program type of the current radio station, such as news, pop music, or sports. Some stations support searching by program type. ● TA (Traffic Announcement): When enabled, the radio automatically switches to traffic announcements and returns to the previous station after the broadcast ends. This feature provides real-time traffic information. ● AF (Alternative Frequency): When the current station signal becomes weak, the radio automatically switches to another frequency of the same station to maintain stable reception. ● RDS Notice: PTY, TA, and AF are RDS (Radio Data System) functions. These features are available only when RDS is enabled and supported by the FM radio station. RDS availability may vary depending on region and broadcaster.	● Press and hold the Search icon for 3 seconds to automatically scan for available stations and save them to the preset list. This allows quick station searching without manual tuning. ● Tap the antenna icon to enable LOC (Local Mode). Tap it again to disable LOC. When enabled, the radio prioritizes strong local stations and reduces interference from weak or distant signals. ● Tap the double-circle icon to enable MONO mode. Tap it again to disable MONO. ● MONO Mode When enabled, the radio combines left and right audio channels into a single-channel output, helping reduce noise in weak signal conditions. ● When MONO is disabled, the radio plays stereo sound (if supported by the station) for improved audio quality.

User Manual

17.2 radio settings



Radio Settings / Default

Tap **Default** to restore all radio settings to factory defaults.

FM Sensitivity (FM Sens)

Adjusts the FM signal sensitivity.

Higher sensitivity allows reception of weaker stations, while lower sensitivity helps reduce noise and interference.

AUTO Sensitivity (AUTO Sens)

When enabled, the system automatically adjusts FM sensitivity based on signal conditions.

When disabled, this option changes to **Manual Sens**, allowing manual adjustment of FM sensitivity.

Radio Area


Selects the radio frequency standard according to the region.

Correct region selection ensures proper station searching and reception.

User Manual

18. Settings

18.1 Settings-WLAN



Wi-Fi

Used to connect the head unit to a wireless network for internet access, app downloads, and system updates.

Data Usage

Displays Wi-Fi data usage information, allowing users to view network data consumption.

More (Hotspot)


Used to enable the system hotspot, which is required for **wireless Apple CarPlay and Android Auto connections**.

The hotspot is used only for device connectivity and is not intended for general internet sharing.

- When using wireless Apple CarPlay or Android Auto, the system hotspot must be enabled.
- During wireless CarPlay or Android Auto connection, the hotspot is used only for device communication and does not provide internet access.
- While connected to wireless CarPlay or Android Auto, the phone may temporarily disconnect from other Wi-Fi networks.
- Wi-Fi signal stability may vary depending on the surrounding wireless environment.

User Manual

18.2 Settings-Device



Display

Used to adjust display-related settings such as screen brightness, wallpaper, and automatic screen sleep.

Sound

Contains audio-related settings.

(For detailed sound settings, please refer to the Sound section.)

GPS

Displays the current GPS status and positioning information of the device.

Storage

Used to view storage usage and manage internal or external storage devices.

Apps

Used to view and manage installed applications on the system.

USB Video Out Settings

Used to configure USB video output settings.

This function allows the head unit display to be output to an external screen, with options to adjust image-related parameters.

User Manual

18.2.1 sound settings

Keypad Tone

Controls touch sound feedback.

When enabled, a sound is played when touching the screen. When disabled, touch operations are silent.

LOUD

Enhances bass and treble output to provide a richer sound experience at lower volumes.

AMP ON / OFF

When enabled, the blue wire (marked **AMP**) on the 20-pin RCA audio harness outputs 12V.

This is typically used to power an external amplifier or activate the factory amplifier.

Noise Reduction

Reduces background noise to improve audio clarity.

Power Conditioning

Adjusts amplifier output levels to optimize volume and prevent distortion caused by excessively low or high output.

Equalizer


Provides multiple sound presets and allows manual adjustment of frequency bands for personalized sound tuning.

Speed Compensated Volume

Automatically adjusts volume according to vehicle speed to maintain a consistent listening level while driving.

User Manual

18.2.2 GPS



This interface displays the current satellite positioning status of the device, including GPS and GLONASS information.

- **Longitude & Latitude:** Displays the current geographic coordinates.
- **GPS Status:** Indicates signal reception status (e.g., *NO SIGNAL* means no satellite connection).
- **GPS / GLONASS Satellites:** Shows the number of satellites currently connected for each system.
- **Time:** Displays time synchronized from satellite signals.
- **Auto Sync:** Automatically synchronizes the system time using GPS data.
- **Mode Selection:** Allows switching between different positioning modes.


This page provides an overview of satellite signal reception and positioning information, helping users confirm GPS operation and positioning status.

User Manual

18.2.3 USB Video Out Settings

This function requires a separately purchased **USB to CVBS Video Output Adapter**.

It allows the head unit display to be output to an external screen through the adapter, with adjustable image parameters.



USB to RCA Output Adapter Share Videos with your passenger


This adapter provides a connection method between the head unit and an RCA input enabled monitor or other device. With an optional RCA cable, you can share the video with passengers in your vehicle.



User Manual

18.3 settings-General

General Settings page contains various system-level options used to configure the overall behavior of the head unit. Detailed descriptions and operating instructions for each setting are provided in the following sections.



User Manual

Settings - General Detailed Functionality

1. Press Any Key to Start

Allows the device to wake up or start by pressing any physical key.

2. Brake Wire for Video in Motion

When enabled, video playback will display **audio only without image**, and a safety warning message will appear. This function is related to driving safety restrictions.

3. Auto-start Navigation

Automatically launches the navigation application when the device boots.

4. OSD Time

Displays the current time on the screen.

5. Mute Audio When Reversing

Automatically mutes all audio sources when the vehicle is in reverse gear.

6. Mirror View on Reverse Image

Adjusts the left-right mirror orientation of the reverse camera image.

7. Backlight Control

Controls the backlight behavior of the touch keys.

User Manual

- **Time Control**

Adjusts the touch key backlight based on system time.

Example: When enabled, the backlight remains on from **19:00 to 06:59**.

- **Small Light Control**

The touch key backlight turns on only when the vehicle headlights are on.

When headlights are off, the backlight remains off.

8. Default Volume Switch

Enables the ability to set a fixed startup volume for the device.

9. GPS Mix

Adjusts the audio priority between GPS voice guidance and other sound sources.

10. Lantern Settings

Used to adjust the color of side ambient lights.

(Not applicable for Tesla-style vertical screens without side touch light panels.)

11. Sound Mixing Scale

Allows fine adjustment of the volume balance between GPS voice guidance and background audio.

12. Sound Reduction When Reversing

Reduces the volume level of the current audio source when reversing.

(This option differs from “Mute Audio When Reversing,” which fully mutes sound.)

13. Default Boot Volume

Sets the startup volume level (default value: 18).

Requires “Default Volume Switch” to be enabled.

User Manual

14. Steering Wheel Setting

Used to manually program and assign steering wheel control buttons for vehicles **without CAN bus support**.

For vehicles equipped with CAN bus, steering wheel controls are decoded automatically through the matched CAN bus module.

15. Navi App

Sets the shortcut application for the **Navigation** icon on the home screen.

Google Maps is set as the default navigation app.

16. Map Data Copy

Used to copy navigation map data.

(Usually not required for normal operation.)

17. FAN Settings

Used to configure cooling fan behavior.

This option is typically available on higher-configuration models (e.g., octa-core units with 8GB RAM / 128GB storage).

User Manual



18.4 Factory Settings

The **Factory Settings** page contains advanced system configuration options used for factory calibration, vehicle compatibility, and professional installation.

Improper modification of these settings may affect system functionality or vehicle compatibility.

In most cases, all options are preconfigured at the factory and set to default values.

Adjustment is recommended **only by qualified technicians or under technical support guidance**.




Note:

Access to this setting requires a password. To prevent improper modifications that may cause system malfunction, please do not change these settings without authorization.

Password: 3368

User Manual

18.4.1 Factory-Original Car Agreement



1. External Temperature

When enabled, the outside temperature is displayed in the status bar.

This function requires the original vehicle to support external temperature detection and CAN bus communication. Temperature data is read from the vehicle's sensor and decoded via the CANBUS box. If the vehicle does not support CAN bus, this option can be ignored.

2. Automatic Start and Stop

Controls the vehicle's automatic start-stop function, allowing the engine to shut off and restart during short stops.

This function is available only on vehicles equipped with CAN bus.

3. Radar Display ON / OFF

Enables or disables the display of parking radar information.

Requires original vehicle radar sensors. Radar data is decoded through the CANBUS box and displayed on the reversing interface.

4. Reverse Parking Line

Shows or hides parking guideline lines on the reverse camera image to assist with parking alignment.

User Manual

5. Static Trace

When enabled, parking guideline lines remain fixed and do not move with the steering wheel.
(Default setting is usually **OFF**.)

6. Reversing Track Reversal

Adjust this option if the dynamic reversing trajectory moves in the opposite direction of the steering wheel.
Applies only to vehicles equipped with dynamic trajectory lines.

7. Max Reversing Angle

Adjusts the steering angle range if the reversing trajectory does not move or has a limited movement range.

8. CAN Box Upgrade

Used to update the CANBUS box firmware to resolve compatibility or functionality issues.

9. A/C Information ON / OFF

When enabled, an air-conditioning status popup is displayed when climate controls are adjusted.

10. Door ON / OFF

Displays a door-open warning icon when any vehicle door is opened.

11. Rear Door Exchange

Adjusts the rear door display position if the left and right doors are shown incorrectly.

12. Car Audio Type

Selects the vehicle audio input channel.
(Default setting: **AUX**.)

User Manual

13. Reversal Previous and Next

Adjusts this option if the steering wheel **Previous / Next track** buttons are reversed.

14. Reversal Volume

Adjusts this option if the steering wheel **Volume Up / Down** buttons are reversed.

15. Protocol Print

Used for diagnostic purposes.

Before enabling this option, please start video recording. After turning on protocol printing, protocol data will appear in the upper-left corner of the screen.

Operate the relevant buttons **three times**, then stop recording and send the video to the after-sales support team for analysis.

16. Driver's Door Position

Switches between **Left-Hand Drive (LHD)** and **Right-Hand Drive (RHD)** vehicle configurations.

17. Temperature Unit Switch

Switches the temperature display unit between **Celsius (°C)** and **Fahrenheit (°F)**.

18. Temperature Left and Right Exchange


Adjust this option if changing the driver-side temperature affects the passenger side, or vice versa.

19. Tire Pressure Unit Switching

Switches the tire pressure unit between **kPa**, **PSI**, and **BAR**.

User Manual

18.4.2 Factory-Car Model




This page is used to configure the **CANBUS protocol**, allowing the head unit to correctly communicate with the vehicle and receive data such as steering wheel controls, door status, and air conditioning information.

- If the vehicle **does not support CANBUS**, select “**NULL – No Protocol.**”
- If a **CANBUS box** is installed, select the corresponding protocol based on the CANBUS box brand and model.

Correct configuration ensures stable system operation and proper integration with original vehicle functions.

User Manual

18.4.3 Boot Screen Logo



This option allows users to select the startup logo displayed when the device boots.


Built-in brand logos are available for selection, and a **custom logo** can also be used.

For a custom logo, please note:

- Image format must be **BMP**
- Resolution must be **768x1024**
- Create a folder named **“mycar”** and place the image file inside
- Insert the storage device into the head unit, then select the custom logo in the **Boot Screen Logo** menu

User Manual

18.4.4 Set Screen




Adjusts the **AVDD** and **VCOM** parameters of the display to optimize screen performance.

If color deviation, flickering, or abnormal display behavior occurs, these parameters can be fine-tuned to improve visual output.

This setting is intended for advanced adjustment. Incorrect values may affect display quality.

User Manual

18.4.5 Touch Screen Calibration



Calibrates the touchscreen to ensure accurate touch response.

If touch alignment is incorrect or touch input is inaccurate, use this option to recalibrate the screen and improve touch accuracy.

Quick Calibration Method:

You can also enter the calibration interface by **touching the screen with five fingers at the same time and holding for approximately 6 seconds** until the calibration screen appears automatically.

User Manual

18.4.6 Panel Key Learning

This function is used to calibrate and configure the five touch-sensitive buttons on the left side of the screen: Power, Home, Back, Volume Up, and Volume Down. It is useful when the buttons malfunction, become misaligned, or respond incorrectly.

Note: For Tesla-style vertical screens, this feature is generally not required, as these screens typically do not have touch-sensitive buttons on the side. It is mainly intended for horizontal screens with touch keys.

18.4.7 Sleep Mode Setting

Power off when ACC is off (Sleep Mode Off): The device completely shuts down when the ACC is turned off, requiring a full reboot when restarted. This mode is suitable for long-term parking or to prevent battery drain.

Sleep Mode when ACC is off (Sleep Mode On): The device enters a low-power standby state when the ACC is turned off, allowing for a faster startup when restarting the vehicle. This mode is recommended for frequent driving.

User Manual

18.4.8 Front View

This option can remain **off by default**. Enabling it does **not** automatically display the front camera view; a compatible front camera hardware is required. When turned on, the AUX input on the device will be hidden. Since this feature is rarely used, it is recommended to leave it off by default.

18.4.9 Cancel the Reverse into the Front View

This function controls whether the system automatically switches to the front camera view after reversing. When **disabled**, the system will return to the home screen or the previously used interface instead of switching to the front camera. If the vehicle does not have a front camera or this feature is not needed, it is recommended to keep it disabled to avoid unnecessary screen transitions.

User Manual

18.4.10 Local Reverse switch

This feature controls whether the device automatically switches to its own reverse camera interface when the car is shifted into reverse gear.

Enabled (default for most vehicles): The device will automatically display its rearview screen upon detecting the reverse signal.

Disabled (for select vehicles only): In certain vehicles such as Mercedes-Benz, BMW, Audi, and Cadillac, which have their own original rearview system, disabling this switch allows the original system to display the rearview image instead of the device.

Note:

For vehicles with a CAN bus box, the reverse signal is sent from the car to the CAN bus box, which then outputs 12V to the device to trigger the reverse camera interface.

User Manual

For vehicles without a CAN bus box, the reverse light positive must be connected to the "reverse detection wire" in the device harness (usually labeled as "back" or "reverse").

Recommendation:

Most vehicles: Keep this switch enabled.

Mercedes-Benz, BMW, Audi, Cadillac: Disable this switch only if you want to retain the original rearview system when reversing.

18.4.11 Unknown sources

Unknown Sources

This option controls whether apps from sources other than official app stores can be installed.

- **Enabled:** Users can install apps from third-party websites or other channels.

User Manual

- **Disabled (recommended):** Only apps from official app stores can be installed.

Note: Enabling this option increases security risks. Only enable it if the source of the app is trustworthy.

18.4.11 Door lock interference

If the remote key fails to unlock the doors or the power windows cannot be operated after installation, follow these steps:

1. Enter the password “**0000**” to unlock the settings.
2. Enable the **Door Lock Interference** option.
3. Tap the return button in the upper-right corner of the screen.
4. Restart the head unit for the changes to take effect.

User Manual

18.4.12 Plug-in Serial Device Setting

This option is used to manage and configure external devices connected via serial ports (such as USB or UART) to ensure proper communication with the head unit. Typically, no changes are required unless a specific external serial device is being used.

18.4.13 Volume Balance Settings

This setting allows you to adjust the volume balance for seven audio sources: Radio, AUX, TV, BT MUSIC, NAVI, MUSIC, and BT PHONE. It ensures a consistent volume level across different sources, preventing sudden changes that could affect the user experience.


18.4.14 MCU upgrade

Used to upgrade the MCU (Microcontroller Unit) firmware to improve system compatibility, enhance device stability, or fix known issues. However, this upgrade is generally not necessary unless there are issues such as

User Manual

system disorder or protocol communication failure. Ensure that the correct MCU upgrade file is used and keep the device powered on during the upgrade to prevent potential failures

18.4.15 Backlight current adjustment



If the screen feels too bright at night, follow these steps to adjust the minimum brightness:

1. Pull down the notification bar and adjust the brightness.
2. Go to **Settings** → **Factory** (enter password “3368”) → **Backlight Current Adjustment** (enter “5768”).
3. Lower the minimum brightness to around **16–18** and save the settings.
4. Restart the head unit.
5. Optionally, go to **Settings** → **Display** → **Brightness Level** and adjust the brightness to a comfortable level.

Note:

- Maximum value should generally **not exceed 68**.
- Minimum value should generally **not be lower than 15**.

User Manual

18.4.16 usb protocol selection

This setting allows you to select the USB communication protocol, offering **USB 1.0** and **USB 2.0** modes. The default is **USB 2.0**, which ensures optimal data transfer speed and compatibility.

- If set to **USB 1.0**, the device may not be able to read USB data.
- **Recommendation:** Keep the default **USB 2.0** setting.

18.4.17 A key to export

This feature allows you to export the current factory settings with a single click. It makes it easy to back up your configuration or replicate the settings on another device. The exported data can be saved to a USB drive.

18.4.18 HD Reversing Video Format

This setting allows you to select the input mode for the reversing camera to ensure compatibility (e.g., **TVI**, **AHD**).

User Manual

- For factory-installed cameras, select **TVI** mode.
- For cameras provided with the device, select **AHD** mode.

After making your selection:


1. Tap the return button in the upper-right corner of the screen.
2. Restart the device. You can restart by either:
 - Swiping down from the top of the screen to find the **Reboot** button, or
 - Using the “**RST**” **reset hole** in the upper-left corner of the unit.

Note:

The settings described above are the most commonly used. Options not mentioned are rarely needed in typical usage. If you have any questions while using the device, please feel free to contact us. Thank you for your support.

User Manual

18.5 Factory-User




This interface allows users to manage key device settings to optimize their experience, personalize preferences, and ensure system security and stability. The available options include:

- **Location:** Manage location access permissions and control apps' use of GPS and other location services.
- **Security:** Configure device security options such as screen lock, passwords, and encryption.
- **Language and Input:** Select system language and configure input methods.
- **Google Settings:** Manage system settings related to Google services.
- **Backup and Reset:** Options for data backup and factory reset.
- **Account:** Manage user accounts, including Google accounts and other logged-in accounts.
- **Delay Power Off When ACC Off:** Configure whether the device delays shutdown after the ACC is turned off.
- **Application Settings:** Manage installed applications, including permissions and default apps.
- This interface helps users optimize their device experience, personalize settings, and maintain system security and stability.

User Manual

18.6 Factory-System



The **System Settings** menu provides essential configurations for device management and customization of system behavior.

Available options include:

- **Date and Time:** Adjust system date and time, including time zone and automatic updates.
- **Accessibility:** Configure features to improve accessibility, such as screen magnification and assistive touch functions.
- **Developer Options:** Enable advanced debugging features, USB debugging, and system performance settings. (*For experienced users only.*)
- **About Device:** View essential device information, including system version, model, and software updates.


User Manual

19. Diagram of Pinout Definitions on the Back of the Head Unit

19.1 Power Socket Pinout

Note:

When verifying the pinout, please make sure to check the **number of pins** and the **pin orientation** for each terminal to ensure proper connection.




User Manual

19.2 20-Pin RCA Audio Socket Pinout

Note:

When verifying the pinout, please make sure to check the **number of pins** and the **pin orientation** for each terminal to ensure proper connection.




User Manual

19.3 8-Pin CAN Bus Connector Pinout

Note:

When verifying the pinout, please make sure to check the **number of pins** and the **pin orientation** for each terminal to ensure proper connection.




User Manual

19.4 4-Pin USB Port Pinout

Note:

When verifying the pinout, please make sure to check the **number of pins** and the **pin orientation** for each terminal to ensure proper connection.




User Manual

19.5 6-Pin USB Port Pinout

Note:

When verifying the pinout, please make sure to check the **number of pins** and the **pin orientation** for each terminal to ensure proper connection.




User Manual

19.6 10-Pin Rear Camera Port Pinout

Note:

When verifying the pinout, please make sure to check the **number of pins** and the **pin orientation** for each terminal to ensure proper connection.



User Manual

20. Car Android Head Unit – Frequently Asked Questions (FAQ)

1. Device Won't Turn On

Possible Causes:

- Power connection issues
- Blown fuse
- System failure

Solutions:

1. Check if the power cables (**ACC & B+**) are correctly connected.
2. Inspect the fuse and replace it if damaged.
3. Press and hold the **RST** button for 5 seconds to restart the unit.

User Manual

2. No Sound from the Device

Possible Causes:

- Volume muted or too low
- Speaker or amplifier connection issue
- Audio settings incorrect

Solutions:

1. Ensure the device is not muted and increase the volume.
2. Check speaker connections and try switching audio sources (**Radio, Bluetooth, USB**).
3. Go to **Volume Balance Settings** and check if each audio source is properly configured.

3. Reverse Camera Not Displaying / Black Screen

Possible Causes:

User Manual

- Camera not powered
- Reverse signal not connected correctly
- Incorrect camera mode selected

Solutions:

1. Verify the camera is powered (12V from reverse light or camera power).
2. Ensure the reverse signal wire is properly connected to the head unit.
3. Go to **HD Reversing Video Format** and select:
 - **TVI** for factory cameras
 - **AHD** for aftermarket cameras
4. Tap the return button and restart the head unit.

User Manual

4. WiFi Won't Connect

Possible Causes:

- Weak or unstable signal
- Incorrect password
- WiFi module failure

Solutions:

1. Ensure the WiFi signal is strong; move closer to the hotspot if needed.
2. Re-enter the WiFi password and check for typos.
3. Go to **System Settings** → **Factory Reset** and reset WiFi configurations.

5. Bluetooth Won't Connect to Phone

User Manual

Possible Causes:

- Bluetooth is turned off
- Phone's Bluetooth cache conflict
- Compatibility issue

Solutions:

1. Go to **Bluetooth Settings** and ensure Bluetooth is enabled.
2. On your phone, remove the paired device and reconnect.
3. Try using a different phone or updating the firmware.

6. Touchscreen Unresponsive / Inaccurate

Possible Causes:

User Manual

- Touch calibration off
- Hardware failure

Solutions:

1. Go to **Touch Screen Calibration** and recalibrate the touchscreen.
2. Press and hold **RST** to restart the unit.
3. If issue persists, contact customer support for hardware inspection.

7. Device is Slow or Freezes

Possible Causes:

- Too many apps running in the background
- Low storage space
- System crash

User Manual

Solutions:

1. Close unnecessary apps and clear cache.
2. Go to **System Settings** → **Storage** and free up space.
3. Perform a factory reset or update the firmware if needed.

8. USB Device Not Recognized

Possible Causes:

- Unsupported USB format
- Faulty USB device
- Incorrect USB protocol settings

Solutions:

User Manual

1. Format the USB device as **FAT32** or **NTFS**.
2. Check **USB Protocol Selection** and ensure it is set to **USB 2.0**.
3. Try another USB device or a different USB port.

9. GPS Navigation Not Working

Possible Causes:

- GPS antenna is not installed correctly
- GPS permission issue
- Signal interference

Solutions:

1. Ensure the GPS antenna is installed in an open, unobstructed location.
2. Go to **System Settings** → **App Permissions** and allow GPS access.

User Manual

3. Avoid testing in underground garages or tunnels.

10. Cannot Play Video / Format Not Supported

Possible Causes:

- Unsupported video format
- Incompatible player

Solutions:

1. Convert the video format to **MP4 (H.264 codec)**.
2. Install a third-party media player such as **VLC**.

11. Steering Wheel Controls Not Working

Possible Causes:

User Manual

- Incorrect CANBUS settings
- Steering wheel learning not completed

Solutions:

1. Go to **Car Model Settings** and select the correct **CANBUS protocol**.
2. Navigate to **Steering Wheel Learning** and reprogram the buttons.

12. Device Won't Enter Sleep Mode

Possible Causes:

- Sleep mode is disabled
- Power wiring issue

Solutions:

User Manual

1. Go to **Sleep Mode Setting** and enable sleep mode.
2. Ensure the **ACC wire** is connected to the vehicle's ACC power source.

13. Remote Key Cannot Unlock Car Doors

Possible Causes:

- CANBUS signal interference

Solutions:

Go to **Door Lock Interference**, enter the password "**0000**", enable the option, and restart the device.

14. System Time Is Incorrect

Possible Causes:

User Manual

- Auto time sync failed
- GPS time calibration not updated

Solutions:

1. Go to **Date & Time Settings**, disable automatic network time, and set the time manually.
2. Ensure GPS is functioning correctly to sync time automatically.

15. Boot Logo Does Not Display

Possible Causes:

- Incorrect image format
- Device not fully powered off

Solutions:

User Manual

1. Ensure the boot logo image is in **BMP format (768x1024 resolution)** and placed in the **mycar** folder.
2. Perform a full power cycle (disconnect power supply) and restart.

16. Reverse Guidelines Cannot Be Adjusted

Solutions:

Go to **Backup Test** and adjust the reverse guideline width and angle.

17. Device Boots into Recovery Mode Automatically

Possible Causes:

- Corrupted system files

Solutions:

User Manual

In **Recovery Mode**, select **Wipe Data / Factory Reset** to restore the system.

18. Device Restarts Randomly

Possible Causes:

- Unstable power supply
- Firmware issue

Solutions:

1. Check if the **ACC power** is stable and avoid low-quality wiring harnesses.
2. Update or reinstall the firmware.

19. No Radio Signal

Solutions:

User Manual

Go to **Antenna Normally On** and ensure the antenna power is enabled.

20. Screen Goes Black / System Crashes When Reversing

Solutions:

Go to **Reverse Power Supply** and switch the power mode.

User Manual

21. Specifications

Parameter	Specification
Operating Voltage	8V - 16.5V
Sleep Mode Current (ACC off, quick wake)	$\leq 8\text{ mA}$
Deep Standby Current (after a period ACC off)	$\leq 3\text{ mA}$

