Kids Galaxy quick start

Keep this page next to the projector.

The full steps are in the install guide and the daily guide.

Before the children arrive

About 5 minutes.

- The computer is on and shows the desktop.
- The projector is on and shows that computer.
- Both tablets are on the same Wi-Fi as the computer.
- The wall shows the dark sky.

Turn the room on

- Turn on the computer. Wait for the desktop.
- Turn on the projector. Choose HDMI.
- On the computer, open `http://127.0.0.1:8000/`.
- Press F11 so the picture fills the screen.
- Wake the tablets.

A child draws

- On the kid tablet, tap a shape and draw.
- Tap Launch.
- Look at the wall. The new planet should appear.

A grown-up

- Open Kids Galaxy Manager. It is not the drawing app.
- Tap EN / FR to change that tablet.
- Tap Projector language to change the wall words.
- Tap Print for paper. Tap STL for a 3D file.

Turn the room off

- Shut down the computer from the power menu.
- Turn off the projector.
- Let the tablets sleep.

If the wall is dark

- Check both power lights.
- Check the HDMI cable and the HDMI source.
- On the computer, open `http://127.0.0.1:8000/`.