## **INSTRUCTIONS**

for Installing

**PRH830-1600** midget


CORNER HEAD

To ProSet1600 "POP® Rivet tool

POP

Remove Nose Housing(DPN239-009) and Nose Housing Nut(DPN239-011) from the tool.

PRH830-1600 Adapter Kit Complete parts



2



Remove Jaw Guide(DPN239-006), Jaws(PRG402-8A), Jaw Pusher(DPN239-144), Jaw Pusher Spring (DPN901-001) from the tool.



Tool ready for CORNER HEAD installation.




Attach Draw Bolt Adapter(DPN239-192) and tighten.

5

Attach Corner Head Adapter(DPN239-191) and Tighten.



Tighten CORNER HEAD to Draw Bolt Adapter (DPN239-192)..



and fix the spin of Draw Bolt Adapter.



Remove Socket Screw (DPN907-003), and attach CORNER HEAD to Corner Head Adapter(DPN239-191).



Attach CORNER HEAD to Draw Bolt Adapter (DPN239-192). 10



Tighten Nut of Corner Head to Corner Head Adapter (DPN239-191).



11

Set 8.5mm or less between CORNER HEAD and Corner Head Adapter(DPN239-191).



Tool is now on ready for operation.