

IA-32 Assembly Language Reference Manual

Sun Microsystems, Inc. 901 San Antonio Road Palo Alto, CA 94303-4900 U.S.A.

Part Number 806-3773-10 February 2000

Copyright 2000 Sun Microsystems, Inc. 901 San Antonio Road, Palo Alto, California 94303-4900 U.S.A. All rights reserved.

This product or document is protected by copyright and distributed under licenses restricting its use, copying, distribution, and decompilation. No part of this product or document may be reproduced in any form by any means without prior written authorization of Sun and its licensors, if any. Third-party software, including font technology, is copyrighted and licensed from Sun suppliers.

Parts of the product may be derived from Berkeley BSD systems, licensed from the University of California. UNIX is a registered trademark in the U.S. and other countries, exclusively licensed through X/Open Company, Ltd.

Sun, Sun Microsystems, the Sun logo, docs.sun.com, AnswerBook, AnswerBook2, and Solaris are trademarks, registered trademarks, or service marks of Sun Microsystems, Inc. in the U.S. and other countries. All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. in the U.S. and other countries. Products bearing SPARC trademarks are based upon an architecture developed by Sun Microsystems, Inc.

The OPEN LOOK and Sun^{TM} Graphical User Interface was developed by Sun Microsystems, Inc. for its users and licensees. Sun acknowledges the pioneering efforts of Xerox in researching and developing the concept of visual or graphical user interfaces for the computer industry. Sun holds a non-exclusive license from Xerox to the Xerox Graphical User Interface, which license also covers Sun's licensees who implement OPEN LOOK GUIs and otherwise comply with Sun's written license agreements.

RESTRICTED RIGHTS: Use, duplication, or disclosure by the U.S. Government is subject to restrictions of FAR 52.227-14(g)(2)(6/87) and FAR 52.227-19(6/87), or DFAR 252.227-7015(b)(6/95) and DFAR 227.7202-3(a).

DOCUMENTATION IS PROVIDED "AS IS" AND ALL EXPRESS OR IMPLIED CONDITIONS, REPRESENTATIONS AND WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT, ARE DISCLAIMED, EXCEPT TO THE EXTENT THAT SUCH DISCLAIMERS ARE HELD TO BE LEGALLY INVALID.

Copyright 2000 Sun Microsystems, Inc. 901 San Antonio Road, Palo Alto, Californie 94303-4900 Etats-Unis. Tous droits réservés.

Ce produit ou document est protégé par un copyright et distribué avec des licences qui en restreignent l'utilisation, la copie, la distribution, et la décompilation. Aucune partie de ce produit ou document ne peut être reproduite sous aucune forme, par quelque moyen que ce soit, sans l'autorisation préalable et écrite de Sun et de ses bailleurs de licence, s'il y en a. Le logiciel détenu par des tiers, et qui comprend la technologie relative aux polices de caractères, est protégé par un copyright et licencié par des fournisseurs de Sun.

Des parties de ce produit pourront être dérivées du système Berkeley BSD licenciés par l'Université de Californie. UNIX est une marque déposée aux Etats-Unis et dans d'autres pays et licenciée exclusivement par X/Open Company, Ltd.

Sun, Sun Microsystems, le logo Sun, docs.sun.com, AnswerBook, AnswerBook2, et Solaris sont des marques de fabrique ou des marques déposées, ou marques de service, de Sun Microsystems, Inc. aux Etats-Unis et dans d'autres pays. Toutes les marques SPARC sont utilisées sous licence et sont des marques de fabrique ou des marques déposées de SPARC International, Inc. aux Etats-Unis et dans d'autres pays. Les produits portant les marques SPARC sont basés sur une architecture développée par Sun Microsystems, Inc.

L'interface d'utilisation graphique OPEN LOOK et SunTM a été développée par Sun Microsystems, Inc. pour ses utilisateurs et licenciés. Sun reconnaît les efforts de pionniers de Xerox pour la recherche et le développement du concept des interfaces d'utilisation visuelle ou graphique pour l'industrie de l'informatique. Sun détient une licence non exclusive de Xerox sur l'interface d'utilisation graphique Xerox, cette licence couvrant également les licenciés de Sun qui mettent en place l'interface d'utilisation graphique OPEN LOOK et qui en outre se conforment aux licences écrites de Sun.

CETTE PUBLICATION EST FOURNIE "EN L'ETAT" ET AUCUNE GARANTIE, EXPRESSE OU IMPLICITE, N'EST ACCORDEE, Y COMPRIS DES GARANTIES CONCERNANT LA VALEUR MARCHANDE, L'APTITUDE DE LA PUBLICATION A REPONDRE A UNE UTILISATION PARTICULIERE, OU LE FAIT QU'ELLE NE SOIT PAS CONTREFAISANTE DE PRODUIT DE TIERS. CE DENI DE GARANTIE NE S'APPLIQUERAIT PAS, DANS LA MESURE OU IL SERAIT TENU JURIDIQUEMENT NUL ET NON AVENU.





Contents

1.

2.

Preface 13 Assembler Input 17 Introduction 17 Source Files in Assembly Language Format 18 File Organization 18 Statements 19 Values and Symbol Types 19 Expressions 22 Expression Syntax 22 Expression Semantics (Absolute vs. Relocatable) 23 Machine Instruction Syntax 24 **Instruction Description 27** Pseudo Operations 29 General Pseudo Operations 29 Symbol Definition Pseudo Operations 32 **Instruction-Set Mapping** Introduction 36 Notational Conventions 36 References 40

```
Segment Register Instructions 40
     Load Full Pointer (lds,les, lfs, lgs, and lss)
                                                40
    Pop Stack into Word (pop)
    Push Word/Long onto Stack (push)
                                          41
I/O Instructions 42
    Input from Port (in, ins) 42
    Output from Port (out, outs)
                                   43
Flag Instructions 44
    Load Flags into AH Register (lahf) 44
    Store AH into Flags (sahf)
    Pop Stack into Flag (popf)
    Push Flag Register Onto Stack (pushf)
                                             46
    Complement Carry Flag (cmc)
    Clear Carry Flag (clc) 47
    Set Carry Flag (stc)
    Clear Interrupt Flag (cli) 47
    Set Interrupt Flag (sti)
    Clear Direction Flag (cld)
                                48
    Set Direction Flag (std)
Arithmetic Logical Instructions 49
    Integer Addition (add)
    Integer Add With Carry (adc)
                                    50
    Integer Subtraction (sub) 51
    Integer Subtraction With Borrow (sbb)
                                            52
```

IA-32 Assembly Language Reference Manual ♦ February 2000

Increment by 1 (inc)

Decrease by 1 (dec)

4

Compare Two Operands (cmp)

Logical Comparison or Test (test)

53

54

54

Shift (sal, shl, sar, shr) 55 Double Precision Shift Left (shld) 56 Double Precision Shift Right (shrd) 57 One's Complement Negation (not) 58 Two's Complement Negation (neg) Check Array Index Against Bounds (bound) 59 Logical And (and) 60 Logical Inclusive OR (or) 61 Logical Exclusive OR (xor) Multiply and Divide Instructions 63 Signed Multiply (imul) Unsigned Multiplication of AL, AX or EAX(mul) 64 Unsigned Divide (div) 65 Signed Divide (idiv) Conversion Instructions 67 Convert Byte to Word (cbtw) 67 Convert Word to Long (cwtl) 68 Convert Signed Word to Signed Double Word (cwtd) 68 Convert Signed Long to Signed Double Long (cltd) Decimal Arithmetic Instructions 69 Decimal Adjust AL after Addition (daa) 69 Decimal Adjust AL after Subtraction (das) ASCII Adjust after Addition (aaa) ASCII Adjust after Subtraction (aas) 71 ASCII Adjust AX after Multiply (aam) 72 ASCII Adjust AX before Division (aad) 72 Coprocessor Instructions 73

Wait (wait, fwait)

```
String Instructions 73
    Move Data from String to String (movs)
                                              74
    Compare String Operands (cmps) 74
    Store String Data (stos)
    The Load String Operand (lods)
                                       76
    Compare String Data (scas)
    Look-Up Translation Table (xlat)
                                       78
    Repeat String Operation (rep, repnz, repz)
                                                 78
Procedure Call and Return Instructions 79
    Far Call — Procedure Call (lcall)
    Near Call — Procedure Call (call)
                                        80
    Return from Procedure (ret)
    Long Return (lret)
    Enter/Make Stack Frame for Procedure Parameters (enter)
                                                                82
    High Level Procedure Exit (leave)
                                        83
Jump Instructions 84
    Jump if ECX is Zero (jcxz)
    Loop Control with CX Counter (loop, loopnz, loopz)
                                                           84
    Jump (jmp, ljmp)
Interrupt Instructions 86
    Call to Interrupt Procedure (int, into)
                                           86
    Interrupt Return (iret)
Protection Model Instructions 88
    Store Local Descriptor Table Register (sldt)
                                                 88
    Store Task Register (str)
    Load Local Descriptor Table Register (lldt)
                                                 89
    Load Task Register (ltr)
                              90
    Verify a Segment for Reading or Writing (verr, verw)
                                                           90
```

Store Global/Interrupt Descriptor Table Register (sgdt, sidt) 91 Load Global/Interrupt Descriptor Table (lgdt, lidt) Store Machine Status Word (smsw) 92 Load Machine Status Word (lmsw) 93 Load Access Rights (lar) Load Segment Limit (lsl) 94 Clear Task-Switched (clts) Adjust RPL Field of Selector (arpl) 96 Bit Instructions 96 Bit Scan Forward (bsf) 96 Bit Scan Reverse (bsr) 97 Bit Test (bt) 97 Bit Test And Complement (btc) 98 Bit Test And Reset (btr) 98 Bit Test And Set (bts) 99 Exchange Instructions 99 Compare and Exchange (cmpxchg)[486] Floating-Point Transcendental Instructions 100 Floating-Point Sine (fsin) Floating-Point Cosine (fcos) 100 100 Floating-Point Sine and Cosine (fsincos) Floating-Point Constant Instructions 100 Floating-Point Load One (fld) Processor Control Floating-Point Instructions 101 Floating-Point Load Control Word (fldcw) 101 Floating-Point Load Environment (fldenv) 101 Miscellaneous Floating-Point Instructions Floating-Point Different Reminder (fprem) 101

Floating-Point Comparison Instructions 102

Floating-Point Unsigned Compare (fucom) 102

Floating-Point Unsigned Compare And Pop (fucomp) 102

Floating-Point Unsigned Compare And Pop Two (fucompp) 103

Load and Move Instructions 103

Load Effective Address (lea) 103

Move (mov) 104

Move Segment Registers (movw) 104

Move Control Registers (mov) 105

Move Debug Registers (mov) 105

Move Test Registers (mov) 106

Move With Sign Extend (movsx) 106

Move With Zero Extend (movzb) 107

Pop Instructions 107

Pop All General Registers (popa) 107

Push Instructions 108

Push All General Registers (pusha) 108

Rotate Instructions 108

Rotate With Carry Left (rcl) 108

Rotate With Carry Right (rcr) 109

Rotate Left (rol) 110

Rotate Right (ror) 111

Byte Instructions 111

Byte Set On Condition (setcc) 111

Byte Swap (bswap) [486] 113

Exchange Instructions 113

Exchange And Add (xadd) [486] 113

Exchange Register / Memory With Register (xchg) 113

```
Miscellaneous Instructions 114
    Write Back and Invalidate Cache (wbinvd) [486 only]
    Invalidate (invd) [486 only]
    Invalidate Page (invlpg) [486 only]
                                       114
    LOCK Prefix (lock)
                         115
    No Operation (nop)
                          116
    Halt (hlt) 116
Real Transfer Instructions 117
    Load Real (fld) 117
    Store Real (fst)
    Store Real and Pop (fstp)
                               118
    Exchange Registers (fxch)
                               118
Integer Transfer Instructions 118
    Integer Load (fild) 118
    Integer Store (fist) 119
    Integer Store and Pop (fistp)
Packed Decimal Transfer Instructions 119
    Packed Decimal (BCD) Load (fbld) 119
    Packed Decimal (BCD) Store and Pop (fbstp)
Addition Instructions 120
    Real Add (fadd) 120
    Real Add and Pop (faddp)
                                 120
    Integer Add (fiadd)
                          120
Subtraction Instructions 120
    Subtract Real and Pop (fsub) 120
    Subtract Real (fsubp)
                          121
    Subtract Real Reversed (fsubr)
    Subtract Real Reversed and Pop (fsubrp)
                                              121
```

Integer Subtract (fisubrp) 121

Integer Subtract Reverse (fisubr) 122

Multiplication Instructions 122

Multiply Real (fmul) 122

Multiply Real and Pop (fmulp) 122

Integer Multiply (fimul) 122

Division Instructions 123

Divide Real (fdiv) 123

Divide Real and Pop (fdivp) 123

Divide Real Reversed (fdivr) 123

Divide Real Reversed and Pop (fdivrp) 123

Integer Divide (fidiv) 123

Integer Divide Reversed (fidivr) 124

Floating-Point Opcode Errors 124

Miscellaneous Arithmetic Operations 125

Square Root (fsqrt) 125

Scale (fscale) 125

Partial Remainder (fprem) 125

Round to Integer (frndint) 126

Extract Exponent and Significand (fxtract) 126

Absolute Value (fabs) 126

Change Sign (fchs) 126

Comparison Instructions 127

Compare Real (fcom) 127

Compare Real and Pop (fcomp) 127

Compare Real and Pop Twice (fcompp) 127

Integer Compare (ficom) 128

Integer Compare and Pop (ficomp) 128

Test (ftst) 129 Examine (fxam) 129 Transcendental Instructions 130 Partial Tangent (fptan) 130 Partial Arctangent (fpatan) 130 2^x - 1 (f2xm1) 130 Y * log2 X (fyl2x) 131 Y * $\log_2 (X+1)$ (fyl2xp1) 131 Constant Instructions 131 Load log₂ E (fldl2e) Load log₂ 10 (fldl2t) 132 Load log₁₀ 2 (fldlg2) 132 Load log_e 2 (fldln2) 132 Load pi (fldpi) Load + 0 (fldz) 133 Processor Control Instructions 133 Initialize Processor (finit, fnint) 133 No Operation (fnop) Save State (fsave, fnsave) Store Control Word (fstcw, fnstcw) 134 Store Environment (fstenv, fnstenv) 134 Store Status Word (fstsw, fnstsw) Restore State (frstor) 135 CPU Wait (fwait, wait) Clear Exceptions (fclex, fnclex) 135 Decrement Stack Pointer (fdecstp) 135

Free Registers (ffree)

Increment Stack Pointer (fincstp)

136

136

3. Assembler Output 137

Introduction 137

Object Files in Executable and Linking Format (ELF) 138

ELF Header 139

Section Header 141

Sections 145

Symbol Tables 147

String Tables 149

Attribute Expression 149

A. Using the Assembler Command Line 151

Assembler Command Line 151

Assembler Command Line Options 152

Disassembling Object Code 154

Index 155

Preface

This preface is a brief description of the SunOS[™] assembler that generates code for the Intel 32-bit processor architecture (IA-32). This preface also includes a list of documents that can be used for reference.

The SunOS assembler for IA-32, referred to as the "IA-32 Assembler" in this manual, translates source files that are in assembly language format into object files in linking format.

In the program development process, the assembler is a tool to use in producing program modules intended to exploit features of the IA—32 architecture in ways that cannot be easily done using high level languages and their compilers.

Whether assembly language is chosen for the development of program modules depends on the extent to which and the ease with which the language allows the programmer to control the architectural features of the processor.

The assembly language described in this manual offers full direct access to the IA—32 instruction set. The assembler may also be used in connection with SunOS 5.1 macro preprocessors to achieve full macro-assembler capability. Furthermore, the assembler responds to directives that allow the programmer direct control over the contents of the relocatable object file.

This document describes the language in which the source files must be written. The nature of the machine mnemonics governs the way in which the program's executable portion is written. This document includes descriptions of the pseudo operations that allow control over the object file. This facilitates the development of programs that are easy to understand and maintain.

Before You Read This Book

Use the following documents as references:

- Intel 80386 Programmer's Reference Manual
- i486[™] Microprocessor Programmer Reference Manual (1990)
- Intel 80387 Programmer's Reference Manual (1987)
- System V Application Binary Interface Intel 386 Processor Supplement
- System V Application Binary Interface
- SVID System V Interface Definition

You should also become familiar with the following:

- Man pages: as(1), ld(1), cpp(1), mn(4),cof2elf(1) (elf Executable and Linking Format), elf(3E), dis(1), a.out(5).
- ELF-related sections of the Programming Utilities manual.

How This Book Is Organized

This document is organized into the following chapters:

Chapter 1 describes the overall structure required by the assembler for input source files.

Chapter 2 describes the instruction set mappings for the IA-32 Assembler.

Chapter 3 provides an overview of ELF (*Executable and Linking Format*) for the relocatable object files produced by the assembler.

Appendix A describes the assembler command line options.

Ordering Sun Documents

Fatbrain.com, an Internet professional bookstore, stocks select product documentation from Sun Microsystems, Inc.

For a list of documents and how to order them, visit the Sun Documentation Center on Fatbrain.com at http://wwwl.fatbrain.com/documentation/sun.

Accessing Sun Documentation Online

The docs.sun.com $^{\text{SM}}$ Web site enables you to access Sun technical documentation online. You can browse the docs.sun.com archive or search for a specific book title or subject. The URL is http://docs.sun.com.

What Typographic Conventions Mean

The following table describes the typographic changes used in this book.

TABLE P-1 Typographic Conventions

Typeface or Symbol	Meaning	Example
AaBbCc123	The names of commands, files, and directories; on-screen computer output	Edit your .login file. Use ls -a to list all files. machine_name% you have mail.
AaBbCc123	What you type, contrasted with on-screen computer output	machine_name% su Password:
AaBbCc123	Command-line placeholder: replace with a real name or value	To delete a file, type rm filename.
AaBbCc123	Book titles, new words, or terms, or words to be emphasized.	Read Chapter 6 in <i>User's Guide</i> . These are called <i>class</i> options. You must be <i>root</i> to do this.

Shell Prompts in Command Examples

The following table shows the default system prompt and superuser prompt for the C shell, Bourne shell, and Korn shell.

TABLE P-2 Shell Prompts

Shell	Prompt
C shell prompt	machine_name%
C shell superuser prompt	machine_name#
Bourne shell and Korn shell prompt	\$
Bourne shell and Korn shell superuser prompt	#

Assembler Input

The IA-32 Assembler translates source files in the assembly language format specified in this document into relocatable object files for processing by the link editor. This translation process is called assembly. The main input required to assemble a source file in assembly language format is that source file itself.

This chapter has the following organization:

- "Introduction" on page 17
- "Source Files in Assembly Language Format" on page 18
- "Pseudo Operations" on page 29

Introduction

In whatever manner it is produced, the source input file must have a certain structure and content. The specification of this structure and content constitutes the syntax of the assembly language. A source file may be produced by one of the following:

- A programmer using a text editor
- A compiler as an intermediate step in the process of translating from a high-level language to executable code
- An automatic program generator
- Some other mechanism.

The assembler may also allow ancillary input incidental to the translation process. For example, there are several invocation options available. Each such option exercised constitutes information input to the assembler. However, this ancillary input has little direct connection to the translation process, so it is not properly a

subject for this manual. Information about invoking the assembler and the available options appears in the as(1) man pages.

This chapter describes the overall structure required by the assembler for input source files. This structure is relatively simple: the input source file must be a sequence of assembly language statements. This chapter also begins the specification of the contents of the input source file by describing assembly language statements as textual objects of a certain form.

This document completes the specification by presenting detailed assembly language statements that correspond to the IA—32 instruction set. For more information on assembly language instruction sets, please refer to the product documentation from Intel Corporation.

Source Files in Assembly Language Format

This section details the following:

- file organization
- statements
- values and symbols
- expressions
- machine instruction syntax

File Organization

Input to the assembler is a text file consisting of a sequence of statements. Each statement ends with the first occurrence of a newline character (ASCII LF), or of a semicolon (;) that is not within a string operand or between a slash and a newline character. Thus, it is possible to have several statements on one line.

To make programs easy to read, understand and maintain, however, it is good programming practice not to have more than one statement per line. As indicated above, a line may contain one or more statements. If several statements appear on a line, they must be separated by semicolons (;).

Statements

This section outlines the types of statements that apply to assembly language. Each statement must be one of the following types:

- An empty statement is one that contains nothing other than spaces, tabs, or formfeed characters.
 - Empty statements have no meaning to the assembler. They can be inserted freely to improve the appearance of a source file or of a listing generated from it.
- An assignment statement is one that gives a value to a symbol. It consists of a symbol, followed by an equal sign (=), followed by an expression.
 - The expression is evaluated and the result is assigned to the symbol. Assignment statements do not generate any code. They are used only to assign assembly time values to symbols.
- A pseudo operation statement is a directive to the assembler that does not necessarily generate any code. It consists of a pseudo operation code, optionally followed by operands. Every pseudo operation code begins with a period (.).
- A machine operation statement is a mnemonic representation of an executable machine language instruction to which it is translated by the assembler. It consists of an operation code, optionally followed by operands.

Furthermore, any statement remains a statement even if it is modified in either or both of the following ways:

- Prefixing a label at the beginning of the statement.
 - A label consists of a symbol followed by a colon (:). When the assembler encounters a label, it assigns the value of the location counter to the label.
- Appending a comment at the end of the statement by preceding the comment with a slash (/).

The assembler ignores all characters following a slash up to the next occurrence of newline. This facility allows insertion of internal program documentation into the source file for a program.

Values and Symbol Types

This section presents the values and symbol types that the assembler uses.

Values

Values are represented in the assembler by numerals which can be faithfully represented in standard two's complement binary positional notation using 32 bits. All integer arithmetic is performed using 32 bits of precision. Note, however, that the values used in an IA—32 instruction may require 8, 16, or 32 bits.

Symbols

A symbol has a value and a symbol type, each of which is either specified explicitly by an assignment statement or implicitly from context. Refer to the next section for the regular definition of the expressions of a symbol.

The following symbols are reserved by the assembler:

.Commonly referred to as dot. This is the location counter while assembling a program. It takes on the current location in the text, data, or bss section.

.text

This symbol is of type text. It is used to label the beginning of a .text section in the program being assembled.

.data

This symbol is of type data. It is used to label the beginning of a data section in the program being assembled.

.bss

This symbol is of type bss. It is used to label the beginning of a .bss section in the program being assembled.

.init

This is used with C++ programs which require constructors.

.fini

This is used with C++ programs which require destructors.

Symbol Types

Symbol type is one of the following:

undefined

A value is of undefined symbol type if it has not yet been defined. Example instances of undefined symbol types are forward references and externals.

absolute

A value is of absolute symbol type it does not change with relocation. Example instances of absolute symbol types are numeric constants and expressions whose proper sub-expressions are themselves all absolute.

text

A value is of text symbol type if it is relative to the .text section.

data

A value is of data symbol type if it is relative to the .data section.

bss

A value is of bss symbol type if it is relative to the .bss section.

You can give any of these symbol types the attribute EXTERNAL.

Sections

Five of the symbol types are defined with respect to certain sections of the object file into which the assembler translates the source file. This section describes symbol types.

If the assembler translates a particular assembly language statement into a machine language instruction or into a data allocation, the translation is associated with one of the following five sections of the object file into which the assembler is translating the source file:

TABLE 1-1 Translations and their Associations

Section	Purpose
text	This is an initialized section. Normally, it is read-only and contains code from a program. It may also contain read-only tables
data	This is an initialized section. Normally, it is readable and writable. It contains initialized data. These can be scalars or tables.
bss	This is an initialized section. Space is not allocated for this segment in the object file.
init	This is used with C++ programs that require constructors.
fini	This is used by C++ programs that require destructors.

An optional section, .comment, may also be produced.

The section associated with the translated statement is .text unless the original statement occurs after a section control pseudo operation has directed the assembler to associate the statement with another section.

Expressions

The expressions accepted by the assembler are defined by their syntax and semantics. The following are the operators supported by the assembler:

TABLE 1-2 Operators Supported by the Assembler

Operator	Action
+	Addition
-	Subtraction
*	Multiplication
\bigvee	Division
&	Bitwise logical and
	Bitwise logical or
>>	Right shift
<<	Left shift
\%	Remainder operator
!	Bitwise logical and not
۸	Bitwise logical XOR

Expression Syntax

Table 1–3 shows syntactic rules, the non terminals are represented by lowercase letters, the terminal symbols are represented by uppercase letters, and the symbols enclosed in double quotes are terminal symbols. There is no precedence assigned to the operators. You must use square brackets to establish precedence.

```
expr : term
  expr "+" term
expr "-" term
  expr "\*" term
  expr "\/" term
  expr "&" term
  expr "|" term
  expr ">>" term
  expr "<<" term
  expr "\%" term
  expr "!" term
 expr "^" term
term : id
  number | "-" term
"[" expr "]"
  "<0>" term
  "<s>" term
id: LABEL
number : DEC_VAL
  HEX_VAL
OCT_VAL
  BIN_VAL
```

The terminal nodes are given by the following regular expressions:

```
= [a-zA-Z_][a-zA-Z0-9_]*:
DEC_VAL = [1-9][0-9]*
HEX_VAL = 0[Xx][0-9a-fA-F][0-9a-fA-F]*
OCT_VAL = 0[0-7]*
BIN_VAL = 0[Bb][0-1][0-1]*
```

In the above regular expressions, choices are enclosed in square brackets; a range of choices is indicated by letters or numbers separated by a dash (-); and the asterisk (*) indicates zero or more instances of the previous character.

Expression Semantics (Absolute vs. Relocatable)

Semantically, the expressions fall into two groups, absolute and relocatable. The equations later in this section show the legal combinations of absolute and relocatable operands for the addition and subtraction operators. All other operations are only legal on absolute-valued expressions.

All numbers have the absolute attribute. Symbols used to reference storage, text, or data are relocatable. In an assignment statement, symbols on the left side inherit their relocation attributes from the right side.

In the equations below, a is an absolute-valued expression and r is a relocatable-valued expression. The resulting type of the operation is shown to the right of the equal sign.

```
a + a = a
r + a = r
a - a = a
r - a = r
r - r = a
```

In the last example, you must declare the relocatable expressions before taking their difference.

Following are some examples of valid expressions:

```
label
$label + 0x100]
[label1 - label2]
$(label1 - label2]
```

Following are some examples of invalid expressions:

```
[$label - $label]
[label1 * 5]
(label + 0x20)
```

Machine Instruction Syntax

This section describes the instructions that the assembler accepts. The detailed specification of how the particular instructions operate is not included; for this, see Intel's 80386 Programmer's Reference Manual.

The following list describes the three main aspects of the IA-32 Assembler assembler:

- All register names use the percent sign (%) as a prefix to distinguish them from symbol names.
- Instructions with two operands use the left one as the source and the right one as the destination. This is reversed from Intel's notation.
- Most instructions that can operate on a byte, word, or long may have b, w, or l appended to them. When an opcode is specified with no type suffix, it usually defaults to long. In general, the IA-32 Assembler derives its type information from the opcode, where the Intel assembler can derive its type information from the

operand types. Where the type information is derived motivates the b, w, and l suffixes used in the IA-32 Assembler. For example, in the instruction movw \$1,%eax the w suffix indicates the operand is a word.

Operands

Three kinds of operands are generally available to the instructions: register, memory, and immediate. Indirect operands are available only to jump and call instructions.

The assembler always assumes it is generating code for a 32-bit segment. When 16-bit data is called for (e.g., movw %ax, %bx), the assembler automatically generates the 16-bit data prefix byte.

Byte, word, and long registers are available on the IA—32 processor. The instruction pointer (%eip) and flag register (%efl) are not available as explicit operands to the instructions. The code segment (%cs) may be used as a source operand but not as a destination operand.

The names of the byte, word, and long registers available as operands and a brief description of each follow. The segment registers are also listed.

TABLE 1-4 8-bit (byte) General Registers

%al	Low byte of %ax register
%ah	High byte of %ax register
%cl	Low byte of %cx register
%ch	High byte of %cx register
%dl	Low byte of %dx register
%dh	High byte of %dx register
%bl	Low byte of %bx register
%bh	High byte of %bx register

TABLE 1-5 16-bit (word) General Registers

%ax	Low 16-bits of %eax register
%сх	Low 16-bits of %ecx register
%dx	Low 16-bits of %edx register
%bx	Low 16-bits of %ebx register
%sp	Low 16-bits of the stack pointer
%bp	Low 16-bits of the frame pointer
%si	Low 16-bits of the source index register
%di	Low 16-bits of the destination index register

TABLE 1–6 32-bit (long) General Registers

%eax	32-bit general register
%ecx	32-bit general register
%edx	32-bit general register
%ebx	32-bit general register
%esp	32-bit stack pointer
%ebp	32-bit frame pointer
%esi	32-bit source index register
%edi	32-bit destination index register

TABLE 1-7 Description of Segment Registers

%cs	Code segment register; all references to the instruction space use this register
%ds	Data segment register, the default segment register for most references to memory operands
%ss	Stack segment register, the default segment register for memory operands in the stack (i.e., default segment register for %bp, %sp, %esp, and %ebp)
%es	General-purpose segment register; some string instructions use this extra segment as their default segment
%fs	General-purpose segment register
%gs	General-purpose segment register

Instruction Description

This section describes the IA—32 instruction syntax.

The assembler assumes it is generating code for a 32-bit segment, therefore, it also assumes a 32-bit address and automatically precedes word operations with a 16-bit data prefix byte.

Addressing Modes

Addressing modes are represented by the following:

```
[sreg:][offset][([base][,index][,scale])]
```

- All the items in the square brackets are optional, but at least one is necessary. If you use any of the items inside the parentheses, the parentheses are mandatory.
- sreg is a segment register override prefix. It may be any segment register. If a segment override prefix is present, you must follow it by a colon before the offset component of the address. sreg does not represent an address by itself. An address must contain an offset component.
- offset is a displacement from a segment base. It may be absolute or relocatable. A
 label is an example of a relocatable offset. A number is an example of an absolute
 offset.

■ base and index can be any 32-bit register. scale is a multiplication factor for the index register field. Its value may be 1, 2, 4, 8 to indicate the number to multiply by. The multiplication then occurs by 1, 2, 4, and 8.

Refer to Intel's 80386 Programmer's Reference Manual for more details on IA—32 addressing modes.

Following are some examples of addresses:

```
movl var, %eax
```

Move the contents of memory location var into %eax.

```
movl %cs:var, %eax
```

Move the contents of the memory location var in the code segment into %eax.

```
movl $var, %eax
```

Move the address of var into %eax.

```
movl array_base(%esi), %eax
```

Add the address of memory location array_base to the contents of %esi to get an address in memory. Move the contents of this address into %eax.

```
movl (%ebx, %esi, 4), %eax
```

Multiply the contents of %esi by 4 and add this to the contents of %ebx to produce a memory reference. Move the contents of this memory location into %eax.

```
movl struct_base(%ebx, %esi, 4), %eax
```

Multiply the contents of %esi by 4, add this to the contents of %ebx, and add this to the address of struct_base to produce an address. Move the contents of this address into %eax.

Expressions and Immediate Values

An immediate value is an expression preceded by a dollar sign:

```
immediate: "$" expr
```

Immediate values carry the absolute or relocatable attributes of their expression component. Immediate values cannot be used in an expression, and should be considered as another form of address, i.e., the immediate form of address.

```
immediate: "$" expr "," "$" expr
```

The first expr is 16 bits of segment. The second expr is 32 bits of offset.

Pseudo Operations

The pseudo-operations listed in this section are supported by the IA-32 Assembler.

General Pseudo Operations

Below is a list of the pseudo operations supported by the assembler. This is followed by a separate listing of pseudo operations included for the benefit of the debuggers (dbx(1)).

```
.align val
```

The align pseudo op causes the next data generated to be aligned modulo val. val should be a positive integer value.

```
.bcd val
```

The .bcd pseudo op generates a packed decimal (80-bit) value into the current section. This is not valid for the .bss section. val is a nonfloating-point constant.

.bss

The .bss pseudo op changes the current section to .bss.

```
.bss tag, bytes
```

Define symbol tag in the .bss section and add bytes to the value of dot for .bss. This does not change the current section to .bss. bytes must be a positive integer value.

```
.byte val [, val]
```

The .byte pseudo op generates initialized bytes into the current section. This is not valid for .bss. Each val must be an 8-bit value.

```
.comm name, expr [, alignment]
```

The .comm pseudo op allocates storage in the .data section. The storage is referenced by the symbol name, and has a size in bytes of expr. expr must be a positive integer. name cannot be predefined. If the alignment is given, the address of the name is aligned to a multiple of alignments.

.data

The data pseudo op changes the current section to .data.

.double val

The .double pseudo op generates an 80387 64 bit floating-point constant (IEEE 754) into the current section. Not valid in the .bss section. val is a floating-point constant. val is a string acceptable to atof(3); that is, an optional sign followed by a non-empty string of digits with optional decimal point and optional exponent.

.even

The .even pseudo op aligns the current program counter (.) to an even boundary.

```
.file "string"
```

The .file op creates a symbol table entry where *string* is the symbol name and STT_FILE is the symbol table type. *string* specifies the name of the source file associated with the object file.

.float val

The .float pseudo op generates an 80387 32 bit floating-point constant (IEEE 754) into the current section. This is not valid in the .bss section. val is a floating-point constant. val is a string acceptable to atof(3); that is, an optional sign followed by a non-empty string of digits with optional decimal point and optional exponent.

```
.globl symbol [, symbol]*
```

The globl op declares each *symbol* in the list to be global; that is, each symbol is either defined externally or defined in the input file and accessible in other files; default bindings for the symbol are overridden.

- A global symbol definition in one file satisfies an undefined reference to the same global symbol in another file.
- Multiple definitions of a defined global symbol is not allowed. If a defined global symbol has more than one definition, an error occurs.

Note - This pseudo-op by itself does not define the symbol.

```
.ident ''string''
```

The .ident pseudo op creates an entry in the comment section containing string. string is any sequence of characters, not including the double quote (").

```
.lcomm name, expr
```

The .lcomm pseudo op allocates storage in the .bss section. The storage is referenced by the symbol name, and has a size of expr. name cannot be predefined, and expr must be a positive integer type. If the alignment is given, the address of name is aligned to a multiple of alignment.

```
.local symbol [, symbol]*
```

Declares each *symbol* in the list to be local; that is, each symbol is defined in the input file and not accessible in other files; default bindings for the symbol are overridden. These symbols take precedence over *weak* and *global* symbols.

Because local symbols are not accessible to other files, local symbols of the same name may exist in multiple files.

Note - This pseudo-op by itself does not define the symbol.

```
.long val
```

The .long pseudo op generates a long integer (32-bit, two's complement value) into the current section. This pseudo op is not valid for the .bss section. val is a nonfloating-point constant.

```
.nonvolatile
```

Defines the end of a block of instruction. The instructions in the block may not be permuted. This pseudo-op has no effect if:

- The block of instruction has been previously terminated by a Control Transfer Instruction (CTI) or a label
- There is no preceding .volatile pseudo-op

```
.section section_name [, attributes]
```

Makes the specified section the current section.

The assembler maintains a section stack which is manipulated by the section control directives. The current section is the section that is currently on top of the stack. This pseudo-op changes the top of the section stack.

- If *section_name* does not exist, a new section with the specified name and attributes is created.
- If *section_name* is a non-reserved section, *attributes* must be included the first time it is specified by the .section directive.

```
.set name, expr
```

The .set pseudo op sets the value of symbol name to expr. This is equivalent to an assignment.

```
.string ``str''
```

This pseudo op places the characters in str into the object module at the current location and terminates the string with a null. The string must be enclosed in double quotes (""). This pseudo op is not valid for the .bss section.

.text

The .text pseudo op defines the current section as .text.

```
.value expr [,expr]
```

The .value pseudo op is used to generate an initialized word (16-bit, two's complement value) into the current section. This pseudo op is not valid in the .bss section. Each expr must be a 16-bit value.

.version string

The .version pseudo op puts the C compiler version number into the .comment section.

.volatile

Defines the beginning of a block of instruction. The instructions in the section may not be changed. The block of instruction should end at a .nonvolatile pseudo-op and should not contain any Control Transfer Instructions (CTI) or labels. The volatile block of instructions is terminated after the last instruction preceding a CTI or label.

```
.weak symbol [, symbol]
```

Declares each *symbol* in the list to be defined either externally, or in the input file and accessible to other files; default bindings of the symbol are overridden by this directive.

- A *weak* symbol definition in one file satisfies an undefined reference to a global symbol of the same name in another file.
- Unresolved *weak* symbols have a default value of zero; the link editor does not resolve these symbols.
- If a *weak* symbol has the same name as a defined *global* symbol, the weak symbol is ignored and no error results.

Note - This pseudo-op does not itself define the symbol.

symbol =expr

Assigns the value of expr to symbol.

Symbol Definition Pseudo Operations

.def name

The .def pseudo op starts a symbolic description for symbol name. See endef. name is a symbol name.

```
.dim expr [,expr]
```

The .dim pseudo op is used with the .def pseudo op. If the name of a .def is an array, the expressions give the dimensions; up to four dimensions are accepted. The type of each expression should be positive.

.endef

The .endef pseudo op is the ending bracket for a .def.

.file name

The .file pseudo op is the source file name. Only one is allowed per source file. This must be the first line in an assembly file.

.line expr

The .line pseudo op is used with the .def pseudo op. It defines the source line number of the definition of symbol name in the .def. expr should yield a positive value.

```
.ln line [,addr]
```

This pseudo op provides the relative source line number to the beginning of a function. It is used to pass information through to sdb.

```
.scl expr
```

The .scl pseudo op is used with the .def pseudo op. Within the .def it gives name the storage class of expr. The type of expr should be positive.

```
.size expr
```

The .size pseudo op is used with the .def pseudo op. If the name of a .def is an object such as a structure or an array, this gives it a total size of expr. expr must be a positive integer.

```
.stabs name type 0 desc value .stabn type 0 desc value
```

The .stabs and .stabn pseudo ops are debugger directives generated by the C compiler when the -g option is used. name provides the symbol table name and type structure. type identifies the type of symbolic information (that is, source file, global symbol, or source line). desc specifies the number of bytes occupied by a variable or type, or the nesting level for a scope symbol. value specifies an address or an offset.

.tag str

The .tag pseudo op is used in conjunction with a previously defined .def pseudo op. If the name of a .def is a structure or a union, str should be the name of that structure or union tag defined in a previous .def-.endef pair.

.type expr

The .type pseudo op is used within a .def-.endef pair. It gives name the C compiler type representation expr.

.val expr

The .val pseudo op is used with a .def-.endef pair. It gives name (in the .def) the value of expr. The type of expr determines the section for name.

Instruction-Set Mapping

This chapter describes the instruction set mappings for the IA-32 Assembler processor. For more details of the operation and a summary of the exceptions, refer to the *Intel 486 Microprocessor Family Programmer's Reference Manual* from Intel Corporation.

This chapter is organized as follows:

- "Introduction" on page 36
- "Segment Register Instructions" on page 40
- "I/O Instructions" on page 42
- "Flag Instructions" on page 44
- "Arithmetic Logical Instructions" on page 49
- "Multiply and Divide Instructions" on page 63
- "Conversion Instructions" on page 67
- "Decimal Arithmetic Instructions" on page 69
- "Coprocessor Instructions" on page 73
- "String Instructions" on page 73
- "Procedure Call and Return Instructions" on page 79
- "Jump Instructions" on page 84
- "Interrupt Instructions" on page 86
- "Protection Model Instructions" on page 88
- "Bit Instructions" on page 96
- "Exchange Instructions" on page 99
- "Floating-Point Transcendental Instructions" on page 100
- "Floating-Point Constant Instructions" on page 100

- "Processor Control Floating-Point Instructions" on page 101
- "Miscellaneous Floating-Point Instructions" on page 101
- "Floating-Point Comparison Instructions" on page 102
- "Load and Move Instructions" on page 103
- "Pop Instructions" on page 107
- "Push Instructions" on page 108
- "Rotate Instructions" on page 108
- "Byte Instructions" on page 111
- "Exchange Instructions" on page 113
- "Miscellaneous Instructions" on page 114
- "Real Transfer Instructions" on page 117
- "Integer Transfer Instructions" on page 118
- "Packed Decimal Transfer Instructions" on page 119
- "Addition Instructions" on page 120
- "Subtraction Instructions" on page 120
- "Multiplication Instructions" on page 122
- "Division Instructions" on page 123
- "Miscellaneous Arithmetic Operations" on page 125
- "Comparison Instructions" on page 127
- "Transcendental Instructions" on page 130
- "Constant Instructions" on page 131
- "Processor Control Instructions" on page 133

Introduction

Although the IA—32 architecture supports address-size attributes of either 16 or 32 bits, the IA—32 assembler only supports address-size attributes of 32 bits. The operand-size is either 16 or 32 bits. An instruction that accesses 16-bit words or 32-bit longs has an operand-size attribute of either 16 or 32 bits.

Notational Conventions

The notational conventions used in the instructions included in this chapter are described below:

- The mnemonics are expressed in a regular expression-type syntax.
- When a group of letters is separated from other letters by a bar (|) within square brackets or curly braces, then the group of letters between the bars or between a bar and a closing bracket or brace is considered an atomic unit.

For example, fld[lst] means fld1, flds, or fldt; fst{ls} means fst, fst1, or fsts; and fild{1|11} means fild, fild1, or fild11.

- Square brackets ([]) denote choices, but at least one is required.
- Alternatives enclosed within curly braces ({ }) denote that you can use one or none of them
- The vertical bar separates different suffixes for operators or operands. For example, the following indicates that an 8-, 16-, or 32-bit immediate value is permitted in an instruction:

```
imm[8|16|32]
```

The assembler's operators are built from the Intel operators by adding suffixes to them. The 80387, 80486 deals with three data types: integer, packed decimal, and

The assembler is not typed; the operator has to carry with it the type of data item it is operating on. If the operation is on an integer, the following suffixes apply: none for Intel's short (16 bits), 1 for Intel's long (32 bits), and 11 for Intel's longlong (64 bits). If the operator applies to reals, then: s is short (32 bits), 1 is long (64 bits), and t is temporary real (80 bits).

■ reg[8|16|32] defines a general-purpose register, where each number indicates one of the following:

```
32: %eax, %ecx, %edx, %ebx, %esi, %edi, %ebp, %esp
   16: %ax, %cx, %dx, %bx, %si, %di, %bp, %sp
8: %al, %ah, %cl, %ch, %dl, %dh, %bl, %bh
```

- imm[8|16|32|48] an immediate value. You define immediate values using the regular expression syntax previously described (see also Expressions and Immediate Values on page 210). If there is a choice between operand sizes, the assembler will choose the smallest representation.
- mem[8|16|32|48|64|80] a memory operand; the 8, 16, 32, 48, 64, and 80 suffixes represent byte, word, long (or float), inter-segment, double, and long double memory address quantities, respectively.
- creq a control register; the control registers are: %cr0, %cr2, %cr3, or %cr4.
- r/m[8|16|32] is a general-purpose register or memory operand; the operand type is determined from the suffix. They are: 8 = byte, 16 = word, and 32 = long. The registers for each operand size are the same as reg[8|16|32] above.
- dreg is a debug register; the debug registers are: %db0, %db1, %db2, %db3, %db6, %db7.

- sreg is a segment register. The 16-bit segment registers are: %cs, %ds, %ss, %es, %fs, and %qs.
- treg is a test register. The test registers are: %tr6 and %tr7.
- freg* is floating-point registers %st (%st(0)), %st(1) %st(7).
- An instruction can act on zero or more operands. An operand can be any of the following:
 - an immediate operand (in the instruction itself)
 - a register (32-bit genera, segment, or status/instruction register), (16-bit word register), and (8-bit byte register).
 - a pointer to a memory location.
 - an I/O port

■ Instruction syntax is:

 $operand1 \rightarrow operand2$

where operand1 and operand2 are operated on and the result stored in operand2. The \rightarrow arrow shows the direction. The direction is opposite of that described in the IA 486 Microprocessor Family Programmer's Reference Manual.

- disp[8|32] the number of bits used to define the distance of a relative jump; because the assembler only supports a 32-bit address space, only 8-bit sign extended and 32-bit addresses are supported.
- immPtr an immediate pointer; when the immediate form of a long call or a long jump is used, the selector and offset are encoded as an immediate pointer. An immediate pointer consists of Simm16, Simm32 where the first immediate value represents the segment and the second represents the offset.
- cc condition codes; the 30 condition codes are:

TABLE 2-1 Condition Codes

a	above
ae	above or equal
b	below
be	below or equal
c	carry
e	equal
g	greater
-	

 TABLE 2-1
 Condition Codes
 (continued)

ge greater than or equal to

l less than

le less than or equal to

na not above

nae not above or equal to

nb not below

nbe not below or equal to

ne not carry not equal

ng not greater than

nge not greater than or equal to

nl not less than

nle not less than or equal to

no not overflow

np not parity

ns not sign

nz not zero

o overflow

p parity

pe parity even

po parity odd

s sign

z zero

References

This document presumes that you are familiar with the manner in which the Intel instruction sets function. For more information on specific instruction descriptions, please refer to the *Intel 486 Microprocessor Family Programmer's Reference Manual* from Intel Corporation.

Segment Register Instructions

The following are the segment register instructions supported by the IA—32 processor.

Load Full Pointer (lds,les, lfs, lgs, and lss)

```
lds{w1} mem[32|48], reg[16|32]
les{w1} mem[32|48], reg[16|32]
lfs{w1} mem[32|48], reg[16|32]
lgs{w1} mem[32|48], reg[16|32]
lss{w1} mem[32|48], reg[16|32]
```

Operation

```
mem[32|48] \rightarrow reg[16|32]
```

Description

Reads a full pointer from memory and stores it in the specified segment register (DS, ES, FS, GS or SS) with a 16- or 32-bit offset value.

Example

Load a 16-bit pointer from memory location 0x44444444 into the DX register:

```
ldsw 0x4444444, %dx
```

Load a 32-bit pointer from memory location 0x33333333 into the EDX register:

```
ldsl 0x33333333, %edx
```

Pop Stack into Word (pop)

```
pop{wl} r/m[16|32]
pop{1} [%ds|%ss|%es|%fs|%gs]
```

Operation

```
stack \rightarrow r/m[16\,|\,32] stack \rightarrow segment\ register
```

Description

Replaces the previous contents of the register or memory operand with a word or long from the top of the stack.

Replaces the previous contents of the segment register operand with a long.

```
For a word, SP + 2; for a long, SP + 4.
```

Example

Replace the contents of the memory location pointed to by the EDI register, plus an offset of 4, with the word from the top of the stack:

```
popw 4(edi
```

Replace the contents of the memory location pointed to by the EAX register with the long from the top of the stack:

```
popl %eax
```

Push Word/Long onto Stack (push)

```
push{wl} r/m[16|32]
push{wl} imm[8|16|32]
push{1} [%cs|%ds|%ss|%es|%fs|%gs]
```

Operation

```
r/m[16 \mid 32] \rightarrow stack segment register \rightarrow stack
```

Description

For a word, SP - 2; for a long, SP - 4. Replaces the new top of stack, pointed to by SP, with the register, memory, immediate, or segment register operand.

Example

Replaces the new top of stack with the 16-bit immediate value, -126:

```
pushw $-126
```

Replaces the new top of stack with the 32-bit immediate value, 23456789:

```
pushl $23456789
```

Replaces the new top of stack with the content of the AX register:

```
oushw %ax
```

Replaces the new top of stack with the content of the EBX register:

```
pushl %ebx
```

I/O Instructions

Input from Port (in, ins)

```
in{bwl} imm8
in{bwl} (%dx)
ins{bwl}
```

Operation

```
\begin{aligned} & imm[8\,|\,16\,|\,32] \,\rightarrow\, [AL\,|\,AX\,|\,EAX] \\ & DX \,\rightarrow\, [AL\,|\,AX\,|\,EAX] \,\,DX \,\rightarrow\, ES:(E)DI \end{aligned}
```

Description

in transfers a byte, word, or long from the immediate port into the byte, word, or long memory address pointed to by the AL, AX, or EAX register, respectively.

The second form of the in instruction transfers a byte, word, or long from a port (0 to 65535), specified in the DX register, into the byte, word, or long memory address pointed to by the AL, AX, or EAX register, respectively.

When an 8-bit port is specified, the upper-eight bits of the port address will be 0.

The ins instruction transfers a string from a port specified in the DX register to the memory byte or word pointed to by the ES:destination index. Load the desired port number into the DX register and the desired destination address into the DI or EDI index register before executing the ins instruction. After a transfer occurs, the destination-index register is automatically incremented or decremented as

determined by the value of the direction flag (DF). The index register is incremented if DF = 0 (DF cleared by a cld instruction); it is decremented if DF = 1 (DF set by a std instruction). The increment or decrement count is 1 for a byte transfer, 2 for a word, and 4 for a long. Use the rep prefix with the ins instruction for a block transfer of CX bytes or words.

Example

Transfer an immediate 8-bit port address into the AL register:

```
inb $0xff
```

Transfer a 16-bit port address, specified in the DX register, into the AX register:

```
inw (%dx)
```

Transfer a string from the port address, specified in the DX register, into the ES:destination index register:

insl

Output from Port (out, outs)

```
out{bwl} imm8
out{bwl}
          (%dx)
outs{bwl}
```

Operation

```
[AL | AX | EAX] \rightarrow imm[8 | 16 | 32]
[AL | AX | EAX] \rightarrow DX
ES:(E)DI \rightarrow DX
```

Description

Transfers a byte, word, or long from the memory address pointed to by the content of the AL, AX, or EAX register to the immediate 8-, 16-, or 32-bit port address.

The second form of the out instruction transfers a byte, word, or long from the AL, AX, or EAX registers respectively to a port (0 to 65535), specified by the DX register.

The outs instruction transfers a string from the memory byte or word pointed to by the ES:source index to the port addressed in the DX register. Load the desired port number into the DX register and the desired source address into the SI or ESI index register before executing the outs instruction. After a transfer occurs, the destination-index register is automatically incremented or decremented as determined by the value of the direction flag (DF). The index register is incremented if DF = 0 (DF cleared by a cld instruction); it is decremented if DF = 1 (DF set by a std instruction). The increment or decrement count is 1 for a byte transfer, 2 for a word, and 4 for a long. Use the rep prefix with the outs instruction for a block transfer of CX bytes or words.

Example

Transfer a word from the AX register into the 16-bit port address, 0xff:

outw \$0xff

Transfer a long from the EAX register into the 32-bit port address specified by the DX register:

outl (%dx)

Transfer a string from the memory byte or word pointed to by the ES:source index to the port addressed in the DX register:

outsl

Flag Instructions

Load Flags into AH Register (lahf)

lahf

Operation

 $SF:ZF:xx:AF:xx:PF:xx:CF \,\rightarrow\, AH$

Description

Transfers the low byte of the flags word to the AH register. The bits (lsb to msb) are: sign, zero, indeterminate, auxiliary carry, indeterminate, parity, indeterminate, and carry.

Example

Transfer the flags word into the AH register:

Store AH into Flags (sahf)

sahf

Operation

 $AH \rightarrow SF:ZF:xx:AF:xx:PF:xx:CF$

Description

Loads flags (sign, zero, indeterminate, auxiliary carry, indeterminate, parity, indeterminate, and carry) with values from the AH register.

Example

Load values from the AH register into the flags word:

sahf

Pop Stack into Flag (popf)

popf{wl}

Operation

 $stack \rightarrow flags\ register$

Description

Pops the word or long from the top of the stack and stores the value in the flags register. Stores a word in FLAGS; stores a long in EFLAGS.

Example

Pops the word from the top of the stack and stores it in the flags register:

popfw

Pops the long from the top of the stack and stores it in the eflags register:

popfl

Push Flag Register Onto Stack (pushf)

pushf {wl}

Operation

 $flags\ register \rightarrow stack$

Description

For a word, SP - 2 and copies FLAGS to the new top of stack pointed to by SP. For a long, SP - 4 and copies EFLAGS to the new top of stack pointed to by SS:eSP.

Example

Pushes the flags register onto the top of the stack:

pushfw

Pushes the eflags register onto the top of the stack:

pushfl

Complement Carry Flag (cmc)

cmc

Operation

 $not \ CF \to \ CF$

Description

Reverses the setting of the carry flag; affects no other flags.

Example

Reverse the setting of the carry flag:

cmc

Clear Carry Flag (clc)

clc

Operation

 $0\,\to\, CF$

Description

Sets the carry flag to zero; affects no other flags.

Example

Clear the carry flag:

Set Carry Flag (stc)

stc

Operation

 $1 \to CF \,$

Description

Sets the carry flag to 1.

Example

Set the carry flag:

stc

Clear Interrupt Flag (cli)

cli

Operation

 $0 \to \, IF$

Description

Clears the interrupt flag if the current privilege level is at least as privileged as IOPL; affects no other flags. External interrupts disabled at the end of the cli instruction or from that point on until the interrupt flag is set.

Example

Clear the interrupt flag:

cli

Set Interrupt Flag (sti)

sti

Operation

 $1 \, \to \, IF$

Description

Sets the interrupt flag to 1.

Example

Set the interrupt flag:

sti

Clear Direction Flag (cld)

cld

Operation

 $0 \to \, DF$

Description

Clears the direction flag; affects no other flags or registers. Causes all subsequent string operations to increment the index registers, (E)SI and/or (E)DI, used during the operation.

Example

Clear the direction flag:

cld

Set Direction Flag (std)

std

Operation

 $1\,\to\,DF$

Description

Sets the direction flag to 1, causing all subsequent string operations to decrement the index registers, (E)SI and/or (E)DI, used during the operation.

Example

Set the direction flag:

std

Arithmetic Logical Instructions

Integer Addition (add)

Operation

```
 \begin{split} & reg[8\,|\,16\,|\,32] \,+\, r/m[8\,|\,16\,|\,32] \,\to\, r/m[8\,|\,16\,|\,32] \\ & r/m[8\,|\,16\,|\,32] \,+\, reg[8\,|\,16\,|\,32] \,\to\, reg[8\,|\,16\,|\,32] \end{split}
```

Description

Integer adds operand1 to operand2 and stores the result in operand2.

When an immediate byte is added to a word or long, the immediate value is sign-extended to the size of the word or long operand.

If you wish to decimal adjust (daa) or ASCII adjust (aaa) the add result, use the form of add that stores the result in AL.

Example

Integer adds the 8-bit constant, -126, to the content of the AL register:

```
addb $-126,%al
```

Integer adds the word contained in the effective address (addressed by the EDI register plus an offset of 4) to the content of the DX register:

```
addw 4(%edi),%dx
```

Integer adds the content of the EDX register to the effective address (addressed by the EDI register plus an offset of 4):

```
addl %edx, 4(%edi)
```

Integer Add With Carry (adc)

```
adc{bwl} reg[8|16|32], r/m[8|16|32]
adc{bwl} r/m[8|16|32], reg[8|16|32]
adc{bwl} imm[8|16|32], r/m[8|16|32]
```

Operation

```
 \begin{split} & (reg[8\,|\,16\,|\,32]\,+\,CF)\,+\,r/m[8\,|\,16\,|\,32] \,\to\,r/m[8\,|\,16\,|\,32] \\ & (r/m[8\,|\,16\,|\,32]\,+\,CF)\,+\,reg[8\,|\,16\,|\,32] \,\to\,reg[8\,|\,16\,|\,32] \\ & (imm[8\,|\,16\,|\,32]\,+\,CF)\,+\,r/m[8\,|\,16\,|\,32] \,\to\,r/m[8\,|\,16\,|\,32] \end{split}
```

Description

Integer adds operand1 and the carry flag to operand2 and stores the result in operand2. adc is typically executed as part of a multi-byte or multi-word add operation. When an immediate byte is added to a word or long, the immediate value is sign-extended to the size of the word or long operand.

Example

Integer add the 8-bit content of the effective memory address (ESI register plus an offset of 1) and the carry flag to the content of the address in the CL register:

```
adcb 1(%esi), %cl
```

Integer add the 16-bit content of the effective memory address (EDI register plus an offset of 4) and the carry flag to the content of the address in the DX register:

```
adcw 4(%edi), %dx
```

Integer add the 32-bit content of the address in the EDX register and the carry flag to the effective memory address (EDI register plus an offset of 4):

```
adcl %edx, 4(%edi)
```

Integer Subtraction (sub)

```
sub\{bwl\} reg[8|16|32], r/m[8|16|32]
sub\{bwl\} r/m[8|16|32], reg[8|16|32]
sub\{bwl\} imm[8|16|32], r/m[8|16|32]
```

Operation

```
r/m[8|16|32] - reg[8|16|32] \rightarrow r/m[8|16|32]
reg[8|16|32] - r/m[8|16|32] \rightarrow reg[8|16|32]
r/m[8 \,|\, 16 \,|\, 32] - imm[8 \,|\, 16 \,|\, 32] \rightarrow r/m[8 \,|\, 16 \,|\, 32]
```

Description

Subtracts operand from operand and stores the result in operand. When an immediate byte value is subtracted from a word, the immediate value is sign-extended to the size of the word operand before the subtract operation is executed.

If you wish to decimal adjust (das) or ASCII adjust (aas) the sub result, use the form of sub that stores the result in AL.

Example

Integer subtract the 8-bit constant, -126, from the content of the effective address (addressed by the ESI register plus an offset of 1):

```
subb $-126, 1(%esi)
```

Integer subtract the 16-bit constant, 1234, from the content of the effective address (addressed by the EDI register plus an offset of 4):

```
subw $1234, 4(%edi)
```

Integer subtract the 32-bit content of the EDX register from the effective address (addressed by the EDI register plus an offset of 4):

```
subl %edx, 4(%edi)
```

Integer Subtraction With Borrow (sbb)

```
sbb{bwl} reg[8 | 16 | 32], r/m[8 | 16 | 32]
sbb{bwl} r/m[8 | 16 | 32], reg[8 | 16 | 32]
sbb{bwl} imm[8 | 16 | 32], r/m[8 | 16 | 32]
```

Operation

```
 \begin{split} r/m[8\,|\,16\,|\,32] - (reg[8\,|\,16\,|\,32] + CF) &\rightarrow r/m[8\,|\,16\,|\,32] \\ reg[8\,|\,16\,|\,32] - (r/m[8\,|\,16\,|\,32] + CF) &\rightarrow reg[8\,|\,16\,|\,32] \\ r/m[8\,|\,16\,|\,32] - (imm[8\,|\,16\,|\,32] + CF) &\rightarrow r/m[8\,|\,16\,|\,32] \end{split}
```

Description

Subtracts (operand1 and the carry flag) from operand2 and stores the result in operand2. When an immediate byte value is subtracted from a word, the immediate value is sign-extended to the size of the word operand before the subtract operation is executed.

Example

Integer subtract the 8-bit content of the CL register plus the carry flag from the effective address (addressed by the ESI register plus an offset of 1):

```
sbbb %cl, 1(%esi)
```

Integer subtract the 16-bit constant, -126, plus the carry flag from the AL register:

```
sbbw $-126, %al
```

Integer subtract the 32-bit constant, 12345678, plus the carry flag from the effective address (addressed by the EDI register plus an offset of 4):

```
sbbl $12345678, 4(%edi)
```

Compare Two Operands (cmp)

Operation

```
r/m[8 | 16 | 32] - reg[8 | 16 | 32]
reg[8|16|32] - r/m[8|16|32]
r/m[8|16|32] - imm[8|16|32]
```

Description

Subtracts operand1 from operand2, but does not store the result; only changes the flags. cmp is typically executed in conjunction with conditional jumps and the setccinstruction. If an operand greater than one byte is compared to an immediate byte, the immediate byte value is first sign-extended.

Example

Compare the 8-bit constant, 0xff, with the content of the AL register:

```
cmpb $0xff, %al
```

Compare the 16-bit content of the DX register with the effective address (addressed by the EDI register plus an offset of 4):

```
cmpw %dx, 4(%edi)
```

Compare the 32-bit content of the effective address (addressed by the EDI register plus an offset of 4) to the EDX register:

```
cmpl 4(%edi), %edx
```

Increment by 1 (inc)

```
r/m[8|16|32]
inc{bwl}
```

Operation

```
r/m[8\,|\,16\,|\,32]\,+\,1\,\rightarrow\,r/m[8\,|\,16\,|\,32]
```

Description

Adds 1 to the operand and does not change the carry flag. Use the add instruction with an immediate value of 1 to change the carry flag.

Example

Add 1 to the contents of the byte at the effective address (addressed by the ESI register plus an offset of 1):

```
incb 1(%esi)
```

Add 1 to the 16-bit contents of the AX register:

```
incw %ax
```

Add 1 to the 32-bit contents at the effective address (addressed by the EDI register):

```
incl 4(%edi)
```

Decrease by 1 (dec)

```
dec\{bwl\} r/m[8|16|32]
```

Operation

```
r/m[8\,|\,16\,|\,32]\,\,\hbox{--}\,1\,\to\,r/m[8\,|\,16\,|\,32]
```

Description

Subtracts 1 from the operand. Does not change the carry flag. To change the carry flag, use the sub instruction with an immediate value of 1.

Example

Subtract 1 from the 8-bit contents of the effective address (addressed by the ESI register plus an offset of 1):

```
decb 1(%esi)
```

Subtract 1 from the 16-bit contents of the BX register:

decw %bx

Subtract 1 from the 32-bit contents of the effective address (addressed by the EDI register plus an offset of 4):

```
decl 4(%edi)
```

Logical Comparison or Test (test)

```
\label{eq:test_bwl} \begin{array}{ll} \text{test\{bwl\}} & \text{reg[8|16|32], r/m[8|16|32]} \\ \text{test\{bwl\}} & \text{r/m[8|16|32], reg[8|16|32]} \\ \text{test\{bwl\}} & \text{imm[8|16|32], r/m[8|16|32]} \\ \end{array}
```

Operation

```
reg[8 | 16 | 32] and r/m[8 | 16 | 32] \rightarrow r/m[8 | 16 | 32] r/m[8 | 16 | 32] and reg[8 | 16 | 32] \rightarrow reg[8 | 16 | 32]
```

Description

Performs a bit-wise logical AND of the two operands. The result of a bit-wise logical AND is 1 if the value of that bit in both operands is 1; otherwise, the result is 0. test discards the results and modifies the flags. The OF and CF flags are cleared; SF, ZF and PF flags are set according to the result.

Example

Perform a logical AND of the constant, 0xff, and the 8-bit contents of the effective address (addressed by the ESI register plus an offset of 1):

```
testb $0xff, 1(%esi)
```

Perform a logical AND of the 16-bit contents of the DX register and the contents of the effective address (addressed by the EDI register plus an offset of 4):

```
testw %dx, 4(%edi)
```

Perform a logical AND of the constant, 0xffeeddcc, and the 32-bit contents of the effective address (addressed by the EDI register plus an offset of 4):

```
testl $0xffeeddcc, 4(%edi)
```

Shift (sal, shl, sar, shr)

shl{bwl} %cl, r/m[8 | 16 | 32] sar{bwl} imm8, r/m[8 | 16 | 32] sar{bwl} %cl, r/ m[8|16|32] shr{bwl} imm8, r/m[8|16|32]

```
%cl, r/m[8|16|32]
sal{bwl}
shl{bwl}
         imm8, r/m[8|16|32]
sal\{bwl\} imm8, r/m[8|16|32]
shr\{bwl\} %cl, r/m[8|16|32]
```

Operation

```
shift-left r/m[8 | 16 | 32] by imm8 \rightarrow r/m[8 | 16 | 32]
shift-left r/m[8 | 16 | 32] by %cl \rightarrow r/m[8 | 16 | 32]
shift-right r/m[8 | 16 | 32] by imm8 \rightarrow r/m[8 | 16 | 32]
shift-right r/m[8 | 16 | 32] by %cl \rightarrow r/m[8 | 16 | 32]
```

Description

sal (or its synonym shl) left shifts (multiplies) a byte, word, or long value for a count specified by an immediate value and stores the product in that byte, word, or long respectively. The second variation left shifts by a count value specified in the CL register. The high-order bit is shifted into the carry flag; the low-order bit is set to 0.

sar right shifts (signed divides) a byte, word, or long value for a count specified by an immediate value and stores the quotient in that byte, word, or long respectively. The second variation right shifts by a count value specified in the CL register. sar rounds toward negative infinity; the high-order bit remains unchanged.

shr right shifts (unsigned divides) a byte, word, or long value for a count specified by an immediate value and stores the quotient in that byte, word, or long respectively. The second variation divides by a count value specified in the CL register. shr sets the high-order bit to 0.

Example

Right shift, count specified by the constant (253), the 8-bit contents of the effective address (addressed by the ESI register plus an offset of 1):

```
sarb $253, 1(%esi)
```

Right shift, count specified by the contents of the CL register, the 16-bit contents of the effective address (addressed by the EDI register plus an offset of 4):

```
shrw %cl, 4(%edi)
```

Left shift, count specified by the constant (253), the 32-bit contents of the effective address (addressed by the EDI register plus an offset of 4):

```
shll $253, 4(%edi)
```

Double Precision Shift Left (shld)

```
shld{wl} imm8, reg[16|32], r/m[16|32]
shld{wl} %cl, reg[16|32], r/m[16|32]
```

Operation

```
by imm8 shift-left r/m[16 | 32] bits reg[16 | 32] \rightarrow r/m[16 | 32] by reg[16 | 32] shift-left r/m[16 | 32] bits r/m[16 | 32] \rightarrow r/m[16 | 32]
```

Description

shld double-precision left shifts a 16- or 32-bit register value into a word or long for the count specified by an immediate value, MODULO 32 (0 to 31). The result is stored in that particular word or long.

The second variation of shld double-precision left shifts a 16- or 32-bit register or memory value into a word or long for the count specified by register CL MODULO 32 (0 to 31). The result is stored in that particular word or long.

shld sets the SF, ZF, and PF flags according to the value of the result; CS is set to the value of the last bit shifted out; OF and AF are undefined.

Example

Use the count specified by the constant, 253, to double-precision left shift a 16-bit register value from the DX register to the effective address (addressed by the EDI register plus an offset of 4):

```
shldw $253, %dx, 4(%edi)
```

Use the count specified (%CL MOD 32) by the 32-bit EDX register to double-precision left shift a 32-bit memory value at the effective address (addressed by the EDI register plus an offset of 4):

```
shldl %cl,%edx, 4(%edi)
```

Double Precision Shift Right (shrd)

```
shrd{wl} imm8, reg[16|32], r/m[16|32]
shrd{wl} %cl, reg[16|32], r/m[16|32]
```

Operation

```
by imm8 shift-right r/m[16 | 32] bits reg[16 | 32] \rightarrow r/m[16 | 32]
by reg[16 | 32] shift-right r/m[16 | 32] bits r/m[16 | 32] \rightarrow r/m[16 | 32]
```

Description

shrd double-precision right shifts a 16- or 32-bit register value into a word or long for the count specified by an immediate value MODULO 32 (0 to 31). The result is stored in that particular word or long.

The second variation of shrd double-precision right shifts a 16- or 32-bit register or memory value into a word or long for the count specified by register CL MODULO 32 (0 to 31). The result is stored in that particular word or long.

shrd sets the SF, ZF, and PF flags according to the value of the result; CS is set to the value of the last bit shifted out; OF and AF are undefined.

Example

Use the count specified by the constant, 253, to double-precision right shift a 16-bit register value from the DX register to the effective address (addressed by the EDI register plus an offset of 4):

```
shrdw $253, %dx, 4(%edi)
```

Use the count specified (%CL MOD 32) by the 32-bit EDX register to double-precision right shift a 32-bit memory value at the effective address (addressed by the EDI register plus an offset of 4)

```
shrdl %cl, %edx, 4(%edi)
```

One's Complement Negation (not)

```
not{bwl} r/m[8|16|32]
```

Operation

not $r/m[8|16|32] \rightarrow r/m[8|16|32]$

Description

Inverts each bit value of the byte, word, or long; that is, every 1 becomes a 0 and every 0 becomes a 1.

Example

Invert each of the 8-bit values at the effective address (addressed by the ESI register plus an offset of 1):

```
notb 1(%esi)
```

Invert each of the 16-bit values at the effective address (addressed by the EDI register plus an offset of 4):

```
notw 4(%edi)
```

Invert each of the 32-bit values at the effective address (addressed by the EDI register plus an offset of 4):

```
notl 4(%edi)
```

Two's Complement Negation (neg)

```
neg\{bwl\} r/m[8|16|32]
```

Operation

two's-complement $r/m[8\,|\,16\,|\,32] \rightarrow r/m[8\,|\,16\,|\,32]$

Description

Replace the value of the byte, word, or long with its two's complement; that is, neg subtracts the byte, word, or long value from 0, and puts the result in the byte, word, or long respectively.

neg sets the carry flag to 1, unless initial value of the byte, word, or long is 0. In this case neg clears the carry flag to 0.

Example

Replace the 8-bit contents of the effective address (addressed by the ESI register plus an offset of 1) with its two's complement:

```
neqb 1(%esi)
```

Replace the 16-bit contents of the effective address (addressed by the EDI register plus an offset of 4) with its two's complement:

```
negw 4(%edi)
```

Replace the 32-bit contents of the effective address (addressed by the EDI register plus an offset of 4) with its two's complement:

```
negl 4(%edi)
```

Check Array Index Against Bounds (bound)

```
bound{wl} reg[16|32], r/m[16|32]
```

Operation

r/m[16|32] bound reg $[16|32] \rightarrow CC$ is unchanged

Description

Ensures that a signed array index (16- or 32-bit register) value falls within the upper and lower bounds of a block of memory. The upper and lower bounds are specified by a 16- or 32-bit register or memory value. If the signed array index value is not within the bounds, an Interrupt 5 occurs; the return EIP points to the bound instruction.

Example

Check the 16-bit signed array index value in the AX register against the doubleword with the upper and lower bounds specified by DX:

```
boundw %ax, %dx
```

Check the 32-bit signed array index value in the EAX register against the doubleword with the upper and lower bounds specified by EDX:

```
boundl %eax, %edx
```

Logical And (and)

Operation

```
 \begin{split} & reg[8\,|\,16\,|\,32] \ land \ r/m[8\,|\,16\,|\,32] \to r/m[8\,|\,16\,|\,32] \\ & r/m[8\,|\,16\,|\,32] \ land \ reg[8\,|\,16\,|\,32] \to reg[8\,|\,16\,|\,32] \\ & imm[8\,|\,16\,|\,32] \ land \ r/m[8\,|\,16\,|\,32] \to r/m[8\,|\,16\,|\,32] \end{split}
```

Description

Performs a logical AND of each bit in the values specified by the two operands and stores the result in the second operand.

TABLE 2-2 Logical AND

Values	Result
0 LAND 0	0
0 LAND 1	0
1 LAND 0	0
1 LAND 1	1

Example

Perform an 8-bit logical AND of the CL register and the contents of the effective address (addressed by the ESI register plus an offset of 1):

```
andb %cl, 1(%esi)
```

Perform a 16-bit logical AND of the constant, 0xffee, and the contents of the effective address (addressed by the AX register):

```
andw $0xffee, %ax
```

Perform a 32-bit logical AND of the contents of the effective address (addressed by the EDI register plus an offset of 4) and the EDX register:

```
andl 4(%edi), %edx
```

Logical Inclusive OR (or)

```
reg[8|16|32], r/m[8|16|32]
or{bwl}
        r/m[8|16|32], reg[8|16|32]
or{bwl}
        imm[8|16|32], r/m[8|16|32]
```

Operation

```
reg[8\,|\,16\,|\,32]\;LOR\;r/m[8\,|\,16\,|\,32] \to r/m[8\,|\,16\,|\,32]
r/m[8\,|\,16\,|\,32]\;LOR\;reg[8\,|\,16\,|\,32] \,\to\, reg[8\,|\,16\,|\,32]
imm[8 \,|\, 16 \,|\, 32] LOR r/m[8 \,|\, 16 \,|\, 32] \rightarrow r/m[8 \,|\, 16 \,|\, 32]
```

Description

Performs a logical OR of each bit in the values specified by the two operands and stores the result in the second operand.

TABLE 2-3 Inclusive OR

Values	Result
0 LOR 0	0
0 LOR 1	1
1 LOR 0	1
1 LOR 1	1

Example

Perform an 8-bit logical OR of the constant, 0xff, and the AL register:

```
orb $0xff, %al
```

Perform a 16-bit logical OR of the constant, 0xff83, and the contents of the effective address (addressed by the EDI register plus an offset of 4):

```
orw $0xff83, 4(%edi)
```

Perform a 32-bit logical OR of the EDX register and the contents of the effective address (addressed by the EDI register plus an offset of 4):

```
orl %edx, 4(%edi)
```

Logical Exclusive OR (xor)

```
xor{bwl} reg[8|16|32], r/m[8|16|32]
xor{bwl} r/m[8|16|32], reg[8|16|32]
xor{bwl} imm[8|16|32], r/m[8|16|32]
```

Operation

```
 \begin{split} & \operatorname{reg}[8\,|\,16\,|\,32] \,\, XOR \,\, r/m[8\,|\,16\,|\,32] \,\, \to \,\, r/m[8\,|\,16\,|\,32] \\ & r/m[8\,|\,16\,|\,32] \,\, XOR \,\, \operatorname{reg}[8\,|\,16\,|\,32] \,\, \to \,\, \operatorname{reg}[8\,|\,16\,|\,32] \\ & \operatorname{imm}[8\,|\,16\,|\,32] \,\, XOR \,\, r/m[8\,|\,16\,|\,32] \,\, \to \,\, r/m[8\,|\,16\,|\,32] \end{split}
```

Description

Performs an exclusive OR of each bit in the values specified by the two operands and stores the result in the second operand.

TABLE 2-4 Exclusive XOR

Values	Result
0 XOR 0	0
0 XOR 1	1
1 XOR 0	1
1 XOR 1	0

Example

Perform a 8-bit exclusive OR of the constant, 0xff, and the AL register:

```
xorb $0xff, %al
```

Perform a 16-bit exclusive OR of the constant, 0xff83, and the contents of the effective address (addressed by the EDI register plus an offset of 4):

```
xorw $0xff83, 4(%edi)
```

Perform a 32-bit exclusive OR of the EDX register and the contents of the effective address (addressed by the EDI register plus an offset of 4):

```
xorl %edx, 4(%edi)
```

Multiply and Divide Instructions

When the type suffix is not included in a multiply or divide instruction, it defaults to a long.

Signed Multiply (imul)

```
imulb r/m8
imulw r/m16
imul{1} r/m32
imul\{wi\} r/m[16|32], reg[16|32]
imul{bw1} imm[16|32], r/m[16|32], reg[16|32]
```

Operation

```
r/m8 \times AL \rightarrow AX \ r/m16 \times AX \rightarrow DX:AX
r/m32 \times EAX \rightarrow EDX:EAX \; r/m[16\,|\,32] \times reg[16\,|\,32] \rightarrow reg\,|\,16\,|\,32]
imm[16 | 32] \times r/m[16 | 32] \rightarrow reg | 16 | 32]
```

Description

The single-operand form of imul executes a signed multiply of a byte, word, or long by the contents of the AL, AX, or EAX register and stores the product in the AX, DX:AX or EDX:EAX register respectively.

The two-operand form of imul executes a signed multiply of a register or memory word or long by a register word or long and stores the product in that register word or long.

The three-operand form of imul executes a signed multiply of a 16- or 32-bit immediate by a register or memory word or long and stores the product in a specified register word or long.

imul clears the overflow and carry flags under the following conditions:

TABLE 2-5 Clearing OR and CF Flags — imul

Instruction Form	Condition for Clearing OF and CF
$r/m8 \times AL \rightarrow AX$	AL = sign-extend of AL to 16 bits
$r/m16 \times AX \rightarrow DX{:}AX$	AX= sign-extend of AX to 32 bits
$r/m32 \times EAX \rightarrow EDX:EAX$	EDX:EAX= sign-extend of EAX to 32 bits
$r/m[16 32]\timesreg[16 32]\toreg 16 32]$	Product fits exactly within reg[16 32]
$imm[16 32]\timesr/m[16 32]\rightarrowreg 16 32]$	Product fits exactly within reg[16 32]

Example

Perform an 8-bit signed multiply of the AL register and the contents of the effective address (addressed by the ESI register plus an offset of 1):

imulb 1(%esi)

Perform a 16-bit signed multiply of the constant, -126, and the contents of the effective address (addressed by the EDI register plus an offset of 4). Store the result in the DX register:

imulw \$-126, 4(%edi), %dx

Perform a 32-bit signed multiply of the constant, 12345678, and the contents of the effective address (addressed by the EDI register plus an offset of 4). Store the result in the EDX register:

imull \$12345678, 4(%edi), %edx

Unsigned Multiplication of AL, AX or EAX(mul)

 $mul\{bwl\} r/m[8|16|32]$

Operation

 $r/m8 \times AL \rightarrow AX$ $r/m16 \times AX \rightarrow DX:AX$ $r/m32 \times EAX \rightarrow EDX:EAX$

Description

mul executes a unsigned multiply of a byte, word, or long by the contents of the AL, AX, or EAX register and stores the product in the AX, DX:AX or EDX:EAX register respectively.

mul clears the overflow and carry flags under the following conditions:

TABLE 2-6 Clearing OF and CF Flags — mul

Instruction Form	Condition for Clearing OF and CF
$r/m8 \times AL \rightarrow AX$	clear to 0 if AH is 0; otherwise, set to 1
$r/m16 \times AX \to DX\text{:}AX$	clear to 0 if DX is 0; otherwise, set to 1
$r/m32 \times EAX \rightarrow EDX{:}EAX$	clear to 0 if EDX is 0; otherwise, set to 1

Example

Perform an 8-bit unsigned multiply of the AL register and the contents of the effective address (addressed by the ESI register plus an offset of 1):

```
mulb 1(%esi)
```

Perform a 16-bit unsigned multiply of the AL register and the contents of the effective address (addressed by the EDI register plus an offset of 4):

```
mulw 4(%edi)
```

Perform a 32-bit unsigned multiply of the AL register and the contents of the effective address (addressed by the EDI register plus an offset of 1):

```
mull 1(%edi)
```

Unsigned Divide (div)

```
div\{bwl\} r/m[8|16|32]
```

Operation

```
AX r/m8 \rightarrow AL DX:AX
```

 $r/m16 \to AX \; EDX{:}EAX$

 $r/m32 \,\rightarrow\, EAX$

Description

div executes unsigned division. div divides a 16-, 32-, or 64-bit register value (dividend) by a register or memory byte, word, or long (divisor). The quotient is stored in the AL, AX, or EAX register respectively.

The remainder is stored in AH, Dx, or EDX. The size of the divisor (8-, 16- or 32-bit operand) determines the particular register used as the dividend.

The OF, SF, ZF, AR, PF and CF flags are undefined.

Example

Perform an 8-bit unsigned divide of the AX register by the contents of the effective address (addressed by the ESI register plus an offset of 1) and store the quotient in the AL register, and the remainder in AH:

```
divb 1(%esi)
```

Perform a 16-bit unsigned divide of the DX:AX register by the contents of the effective address (addressed by the EDI register plus an offset of 4) and store the quotient in the AX register, and the remainder in DX:

```
divw 4(%edi)
```

Perform a 32-bit unsigned divide of the EDX:EAX register by the contents of the effective address (addressed by the EDI register plus an offset of 4) and store the quotient in the EAX register, and the remainder in EDX:

```
divl 4(%edi)
```

Signed Divide (idiv)

```
idiv\{bwl\} r/m[8|16|32]
```

Operation

```
AX r/m8 \rightarrow AL 
DX:AX r/m16 \rightarrow AX 
EDX:EAX r/m32 \rightarrow EAX
```

Description

idiv executes signed division. idiv divides a 16-, 32-, or 64-bit register value (dividend) by a register or memory byte, word, or long (divisor). The size of the divisor (8-, 16- or 32-bit operand) determines the particular register used as the dividend, quotient, and remainder.

TABLE 2-7 idiv Register Assignment

Divisor Operand Size	Dividend	Quotient	Remainder
byte	AX	AL	АН
word	DX:AX	AX	DX
long	EDX:EAX	EAX	EDX

If the resulting quotient is too large to fit in the destination, or if the divisor is 0, an Interrupt 0 is generated. Non-integral quotients are truncated toward 0. The remainder has the same sign as the dividend; the absolute value of the remainder is always less than the absolute value of the divisor.

Example

Perform a 16-bit signed divide of the DX:AX register by the contents of the effective address (addressed by the EDI register plus an offset of 4) and store the quotient in the AX register

divw 4(%edi)

Conversion Instructions

Convert Byte to Word (cbtw)

Operation

 $sign\text{-}extend \ AL \to \ AX$

Description

cbtw converts the signed byte in AL to a signed word in AX by extending the most-significant bit (sign bit) of AL into all bits of AH.

Example

cbtw

Convert Word to Long (cwtl)

cwtl

Operation

 $sign\text{-}extend \ AX \to EAX$

Description

cwtl converts the signed word in AX to a signed long in EAX by extending the most-significant bit (sign bit) of AX into two most-significant bytes of EAX.

Example

cwtl

Convert Signed Word to Signed Double Word (cwtd)

cwtd

Operation

 $sign\text{-}extend \ AX \to DX\text{:}AX$

Description

cwtd converts the signed word in AX to a signed double word in DX:AX by extending the most-significant bit (sign bit) of AX into all bits of DX.

Example

cwtd

Convert Signed Long to Signed Double Long (cltd)

cltd

Operation

 $sign\text{-}extend \ EAX \rightarrow EDX\text{:}EAX$

Description

cltd converts the signed long in EAX to a signed double long in EDX:EAX by extending the most-significant bit (sign bit) of EAX into all bits of EDX.

Example

cltd

Decimal Arithmetic Instructions

Decimal Adjust AL after Addition (daa)

daa

Operation

 $decimal\text{-}adjust\ AL \to\ AL$

Description

Use daa only after executing the form of an add instruction that stores a two-BCD-digit byte result in the AL register. daa then adjusts AL to a two-digit packed decimal result.

Example

Decimal adjust the two-BCD-digit in the AL register:

daa

Decimal Adjust AL after Subtraction (das)

Operation

decimal-adjust AL → AL

Description

Use das only after executing the form of a sub instruction that stores a two-BCD-digit byte result in the AL register. das then adjusts AL to a two-digit packed decimal result.

Example

Decimal adjust the two-BCD-digit in the AL register:

das

ASCII Adjust after Addition (aaa)

aaa

Operation

ASCII-adjust $AL \rightarrow AL$

Description

You use aaa only after executing the form of an add instruction that stores a two-BCD-digit byte result in the AL register. aaa then adjusts AL to contain the correct decimal result. The top nibble of AL is set to 0. To convert AL to an ASCII result, follow the aaa instruction with:

or %al, 0x30

Table 2–8 shows how aaa handles a carry.

TABLE 2-8 aaa Handling a Carry

Carry	Action
decimal carry	AH + 1; CF and AF set to 1
no decimal carry	AH unchanged; CF and AF cleared to 0

Example

Adjust the AL register to contain the correct decimal result after an add instruction that stores a two-BCD-digit byte.

ASCII Adjust after Subtraction (aas)

Operation

ASCII-adjust $AL \rightarrow AL$

Description

Use aas only after executing the form of an add instruction that stores a two-BCD-digit byte result in the AL register. aas then adjusts AL to contain the correct decimal result. The top nibble of AL is set to 0. To convert AL to an ASCII result, follow the aas instruction with:

or %al, 0x30

Table 2-9 shows how aas handles a carry.

TABLE 2-9 How aas Handles a Carry

Сагту	Action
decimal carry	AH - 1; CF and AF set to 1
no decimal carry	AH unchanged; CF and AF cleared to 0

Example

Adjust the AL register to contain the correct decimal result after a sub instruction that stores a two-BCD-digit byte

aas

ASCII Adjust AX after Multiply (aam)

aam

Operation

 $AL~10 \rightarrow ~AH~mod~10~AL \rightarrow ~AL$

Description

You use aam only after executing a mul instruction between two BCD digits (unpacked). mul stores the result in the AX register. The result is less than 100 so it can be contained in the AL register (the low byte of the AX register). aam unpacks the AL result by dividing AL by 10, stores the quotient (most-significant digit) in AH, and stores the remainder (least-significant digit) in AL.

Example

Adjust the AL register to contain the correct decimal result after a ${\tt mul}$ instruction between two BCD digits:

aam

ASCII Adjust AX before Division (aad)

aad

Operation

$$AL + (AH \times 10) \rightarrow AL 0 \rightarrow AH$$

Description

aad prepares two unpacked BCD digits for a division operation that yields an unpacked result. The least-significant digit is in AL; the most-significant in AH.

aad prepares the AL and AH registers:

AX is then equal to the binary equivalent of the original unpacked two-digit BCD number.

Example

Adjust the AL and AH registers for a division operation by setting the AX register equal to the original unpacked two-digit number:

Coprocessor Instructions

fwait

Wait (wait, fwait)

wait

Description

wait — processor suspends instruction execution until the BUSY # pin is inactive (high).

fwait — processor checks for pending unmasked numeric exceptions before proceeding.

Example

Suspend instruction execution until not BUSY and check for exceptions:

wait

String Instructions

All string op mnemonics default to long.

Move Data from String to String (movs)

```
movs{bwl} movs{bwl} m[8|16|32], reg[16|32]
```

Operation

```
move {bwl} [(E)SI] \rightarrow ES: (E)DI]
move {bwl} DS: [(E)SI] \rightarrow ES: [(E)DI]
```

Description

Copies the byte, word, or long in [(E)SI] to the byte, word, or long in ES:[(E)DI]. Before executing the move instruction, load the index values into the SI source- and DI destination-index registers.

The destination operand must be addressable from the ES register; it cannot span segments. A source operand, however, can span segments; the default is DS.

After the data is moved, both the source- and destination-index registers are automatically incremented or decremented as determined by the value of the direction flag (DF). The index registers are incremented if DF = 0 (DF cleared by a cld instruction); they are decremented if DF = 1 (DF set by a std instruction). The increment/decrement count is 1 for a byte move, 2 for a word, and 4 for a long.

For a block move of CX bytes or words, precede a movs instruction with a rep prefix.

Example

Copy the 8-bit byte from the DS:[(E)SI] to the ES:[(E)DI] register.

Compare String Operands (cmps)

```
cmps{bwl}
```

Operation

compare DS:[(E)SI] with ES:[(E)DI]

Description

Compares the byte, word, or long in DS:[(E)SI] with the byte, word, or long in ES:[(E)DI]. Before executing the $\tt cmps$ instruction, load the index values into the SI source- and DI destination-index registers.

cmps subtracts the operand indexed by the destination-index from the operand indexed by the source-index register.

After the data is compared, both the source- and destination-index registers are automatically incremented or decremented as determined by the value of the direction flag (DF). The index registers are incremented if DF = 0 (DF cleared by a cld instruction); they are decremented if DF = 1 (DF set by a std instruction). The increment/decrement count is 1 for a byte move, 2 for a word, and 4 for a long.

For a block compare of CX or ECX bytes, words or longs, precede a cmps instruction with a repz or repnz prefix.

Example

Compare the 8-bit byte in the DS:[(E)SI] register to the ES:[(E)DI] register.

Compare the 16-bit word in the DS:[(E)SI] register to the ES:[(E)DI] register.

Compare the 32-bit word in the DS:[(E)SI] register to the ES:[(E)DI] register.

Store String Data (stos)

stos{bwl}

Operation

store $[AL \mid AX \mid EAX] \rightarrow ES:[(E)DI]$

Description

Transfers the contents of the AL, AX, or EAX register to the memory byte or word addressed in the destination register relative to the ES segment. Before executing the move instruction, load the index values into the DI destination-index register.

The destination operand must be addressable from the ES register; it cannot span segments.

After the data is transferred, the destination-index register is automatically incremented or decremented as determined by the value of the direction flag (DF). The index registers are incremented if DF = 0 (DF cleared by a cld instruction); they are decremented if DF = 1 (DF set by a std instruction). The increment/decrement count is 1 for a byte move, 2 for a word, and 4 for a long.

For a block transfer of CX bytes, words or longs, precede a stos instruction with a rep prefix.

Example

Transfer the contents of the AL register to the memory byte addressed in the destination register, relative to the ES segment.

stosb

Transfer the contents of the AX register to the memory word addressed in the destination register, relative to the ES segment

stosw

Transfer the contents of the EAX register to the memory double-word addressed in the destination register, relative to the ES segment

stosl

The Load String Operand (lods)

lods{bwl}

Operation

load ES: $[(E)DI] \rightarrow [AL \mid AX \mid EAX]$

Description

Loads the memory byte or word addressed in the destination register into the AL, AX, or EAX register. Before executing the lods instruction, load the index values into the SI source-index register.

After the data is loaded, the source-index register is automatically incremented or decremented as determined by the value of the direction flag (DF). The index register is incremented if DF = 0 (DF cleared by a cld instruction); it is decremented if DF = 1 (DF set by a std instruction). The increment/decrement count is 1 for a byte move, 2 for a word, and 4 for a long.

For a block transfer of CX bytes, words or longs, precede a lods instruction with a rep prefix; however, lods is used more typically within a loop construct where further processing of the data moved into AL, AX, or EAX is usually required.

Example

Load the memory byte addressed in the destination register, relative to the ES segment register, into the AL register.

lodsb

Load the memory word addressed in the destination register, relative to the ES segment register, into the AX register.

Load the memory double-word addressed in the destination register, relative to the ES segment register, into the EAX register.

lodsl

Compare String Data (scas)

scas{bwl}

Operation

compare ES:[(E)DI] with [AL | AX | EAX]

Description

Compares the memory byte or word addressed in the destination register relative to the ES segment with the contents of the AL, AX, or EAX register. The result is discarded; only the flags are set.

Before executing the scas instruction, load the index values into the DI destination-index register. The destination operand must be addressable from the ES register; it cannot span segments.

After the data is transferred, the destination-index register is automatically incremented or decremented as determined by the value of the direction flag (DF). The index registers are incremented if DF = 0 (DF cleared by a cld instruction); they are decremented if DF = 1 (DF set by a std instruction). The increment/decrement count is 1 for a byte move, 2 for a word, and 4 for a long.

For a block search of CX or ECX bytes, words or longs, precede a scas instruction with a repz or repnz prefix.

Example

Compare the memory byte addressed in the destination register, relative to the ES segment, with the contents of the AL register.

scasb

Compare the memory word addressed in the destination register, relative to the ES segment, with the contents of the AX register

scasw

Compare the memory byte double-word addressed in the destination register, relative to the ES segment, with the contents of the EAX register

scasl

Look-Up Translation Table (xlat)

xlat

Operation

set AL to DS:[(E)BX + unsigned AL]

Description

Changes the AL register from the table index to the table entry. AL should be the unsigned index into a table addressed by DS:BX (16-bit address) or DS:EBX (32-bit address).

Example

Change the AL register from the table index to the table entry.

xlat

Repeat String Operation (rep, repnz, repz)

rep;
repnz;
repz;

Operation

repeat string-operation until tested-condition

Description

Use the rep (repeat while equal), repnz (repeat while nonzero) or repz (repeat while zero) prefixes in conjunction with string operations. Each prefix causes the

associated string instruction to repeat until the count register (CX) or the zero flag (ZF) matches a tested condition.

Example

Repeat while equal: Copy the 8-bit byte from the DS:[(E)SI] to the ES:[(E)DI] register.

rep; movsb

Repeat while not zero: Compare the memory byte double-word addressed in the destination register EDL, relative to the ES segment, with the contents of the EAX register.

repnz; scasl

Repeat while zero:Transfer the contents of the EAX register to the memory double-word addressed in the destination register EDL, relative to the ES segment.

repz; stosl

Procedure Call and Return Instructions

Far Call — Procedure Call (lcall)

lcall lcall *mem48

Operation

far call ptr16:{16 | 32} far call m16:{16 | 32}

Description

The lcall instruction calls intersegment (far) procedures using a full pointer. lcall causes the procedure named in the operand to be executed. When the called procedure completes, execution flow resumes at the instruction following the lcall instruction (see the return instruction).

lcall ptr16:{16 | 32} uses a four-byte or six-byte operand as a long pointer to the called procedure.

lcall m16:{16 | 32} fetches the long pointer from the specified memory location.

In Real Address Mode or Virtual 8086 Mode, the long pointer provides 16 bits for the CS register and 16 or 32 bits for the EIP register. Both forms of the lcall instruction push the CS and IP or EIP registers as a return address.

Example

Use a four-byte operand as a long pointer to the called procedure.

```
lcall $0xfebc, $0x12345678
```

Fetch a long pointer from the memory location addressed by the edx register, offset by 3.

```
lcall *3(%edx)
```

Near Call — Procedure Call (call)

```
call disp32 call *r/m32
```

Operation

```
near call rel\{16 \mid 32\}
near call r/m\{16 \mid 32\}
```

Description

The call instruction calls near procedures using a full pointer. call causes the procedure named in the operand to be executed. When the called procedure completes, execution flow resumes at the instruction following the call instruction (see the return instruction).

call rel{16 | 32} adds a signed offset to address of the instruction following the call instruction to determine the destination; that is, the displacement is relative to the next instruction. The displacement value is stored in the EIP register. For rel16, the upper 16 bits of EIP are cleared to zero resulting in an offset value that does not exceed 16 bits.

call r/m{16 | 32} specifies a register or memory location from which the absolute segment offset is fetched. The offset of the instruction following the call instruction is pushed onto the stack. After the procedure completes, the offset is popped by a near ret instruction within the procedure.

Both forms of the call instruction have no affect on the CS register.

Example

Program counter minus 0x11111111.

```
call .-0x11111111
```

Add a signed offset value to the address of the next instruction.

```
call *4(%edi)
```

Return from Procedure (ret)

```
ret imm16
```

Operation

return to caller

Description

The ret instruction transfers control to the return address located on the stack. This address is usually placed on the stack by a call instruction. Issue the ret instruction within the called procedure to resume execution flow at the instruction following the call.

The optional numeric (16- or 32-bit) parameter to ret specifies the number of stack bytes or words to be released after the return address is popped from the stack. Typically, these bytes or words are used as input parameters to the called procedure.

For an intersegment (near) return, the address on the stack is a segment offset that is popped onto the instruction pointer. The CS register remains unchanged.

Example

Transfer control to the return address located on the stack.

Transfer control to the return address located on the stack. Release the next 16-bytes of parameters.

```
ret $-32767
```

Long Return (lret)

```
1ret
lret
          imm16
```

Operation

return to caller

Description

The lret instruction transfers control to a return address located on the stack. This address is usually placed on the stack by an lcall instruction. Issue the lret instruction within the called procedure to resume execution flow at the instruction following the call.

The optional numeric (16- or 32-bit) parameter to lret specifies the number of stack bytes or words to be released after the return address is popped from the stack. Typically, these bytes or words are used as input parameters to the called procedure.

For an intersegment (far) return, the address on the stack is a long pointer. The offset is popped first, followed by the selector.

In Real Mode, CS and IP are loaded directly. In Protected mode, an intersegment return causes the processor to check the descriptor addressed by the return selector. The AR byte of the descriptor must indicate a code segment of equal or lesser privilege (or greater or equal numeric value) than the current privilege level. Returns to a lesser privilege level cause the stack to be reloaded from the value saved beyond the parameter block.

Example

Transfer control to the return address located on the stack.

lret

Transfer control to the return address located on the stack. Release the next 16-bytes of parameters.

lret \$-32767

Enter/Make Stack Frame for Procedure Parameters (enter)

enter imm16, imm8

Operation

make stack frame for procedure parameters

Description

Create the stack frame required by most block-structured high-level languages. The imm16 operand specifies the number of bytes of dynamic storage allocated on the stack for the routine being entered. The imm8 operand specifies the lexical nesting level (0 to 31) of the routine within the high-level language source code. The nesting level determines the number of stack frame pointers copied into the new stack frame from the preceding frame.

Example

Create a stack frame with 0xfecd bytes of dynamic storage on the stack and a nesting level of 0xff.

enter \$0xfecd, \$0xff

High Level Procedure Exit (leave)

leave

Operation

set (E)SP to (E)BP, then pop (E)BP

Description

The leave instruction reverses the actions of an enter instruction. leave copies the frame pointer to the stack point and releases the stack space formerly used by a procedure for its local variables. leave pops the old frame pointer into (E)BP, thus restoring the caller's frame. A subsequent ret nn instruction removes any arguments pushed onto the stack of the exiting procedure.

Example

Copy the frame pointer to the stack pointer and release the stack space.

leave

Jump Instructions

Jump if ECX is Zero (jcxz)

```
jcxz disp8
```

Operation

jump to disp8 if (E)CX is 0

Description

The jcxz instruction tests the contents of the CX or ECX register for 0. jcxz differs from other conditional jumps that it tests the flags, rather than (E)CX.

jcxz is useful at the beginning of a loop that terminates with a conditional loop instruction; such as:

```
loopne .-126
```

In this case, jcxz tests CX or ECX for 0 prior to entering the loop, thus executing 0 times:

Example

```
jcxz .-126
...
loopne .-126
```

Loop Control with CX Counter (loop, loopnz, loopz)

```
loop disp8
loopnz disp8
loopne disp8
loopz disp8
loope disp8
```

Operation

```
decrement count; jump to disp8 if count not equal 0
```

decrement count; jump to disp8 if count not equal 0 and ZF = 0

Description

loop decrements the count register; the flags register remains unchanged. Conditions are checked for by the particular form of loop you used. If the conditions match, a short jump is made to the address specified by the disp8 operand. The range of the disp8 operand, relative to the current instruction, is +127 decimal bytes to -128 decimal bytes.

loop instructions provide iteration control and combine loop index management with conditional branching. Prior to using the loop instruction, load the count register with an unsigned iteration count. Then, add the loop instruction at the end of a series of instructions to be iterated. The disp8 operand points to the beginning of the iterative loop.

Example

Decrement the count register and when the count is not equal to zero, jump short to the disp8 location.

```
loopne .-126
```

Jump (jmp, ljmp)

```
jmp disp{8|16|32}
jmp *r/m{16|32}
ljmp immPtr
ljmp *mem48
jcc disp{8|32}
```

Operation

jump short or near; displacement relative to next instruction jump far (intersegment; 4- or 6-byte immediate address jump if condition is met; displacement relative to next instruction

Description

The jmp instruction transfers execution control to a different point in the instruction stream: records no return information.

Jumps with destinations of disp[8|16|32] or r/m[16|32] are near jumps and do not require changes to the segment register value.

jmp rel{16 | 32} adds a signed offset to the address of the instruction following the jmp instruction to determine the destination; that is, the displacement is relative to the next instruction. The displacement value is stored in the EIP register. For rel16, the upper 16 bits of EIP are cleared to zero resulting in an offset value not to exceed 16 bits.

1 jmp ImmPtr or *mem48 use a four- or six-byte operand as a long pointer to the destination. In Real Address Mode or Virtual 8086 mode, the long pointer provides 16 bits for the CS register and 16 or 32 bits for the EIP register. In Protected mode, both long pointer forms consult the AR (Access Rights) byte of the descriptor indexed by the selector part of the long pointer. The jmp performs one of the following control transfers depending on the value of the AR byte:

- A jump to a code segment at the same privilege level
- A task switch

Example

Jump to the relative effective address (addressed by the EDI register plus an offset of 4):

```
jmp *4(%edi)
```

Long jump, use 0xfebc for the CS register and 0x12345678 for the EIP register:

```
ljmp $0xfebc, $0x12345678
```

Jump if not equal:

jne .+10

Interrupt Instructions

Call to Interrupt Procedure (int, into)

int 3
int imm8
into

Operation

interrupt 3 — trap to debugger interrupt numbered by immediate byte interrupt 4 — if overflow flag is 1

Description

The int instruction generates a software call to an interrupt handler. The imm8 (0 to 255) operand specifies an index number into the IDT (Interrupt Descriptor Table) of the interrupt routine to be called. In Protect Mode, the IDT consists of an array of 8-byte descriptors; the descriptor for the interrupt invoked must indicate an interrupt, trap, or task gate. In Real Address Mode, the IDT is an array of four byte-long pointers. In Protected and Real Address Modes, the base linear address of the IDT is defined by the contents of the IDTR.

The into form of the int instruction implies interrupt 4. The interrupt occurs only if the overflow flag is set.

The first 32 interrupts are reserved for system use. Some of these interrupts are used for internally generated exceptions.

The int imm8 form of the interrupt instruction behaves like a far call except that the flags register is pushed onto the stack before the return address. Interrupt procedures return via the iret instruction, which pops the flags and return address from the stack.

In Real Address Mode, the int imm8 pushes the flags, CS, and the return IP onto the stack, in that order, then jumps to the long pointer indexed by the interrupt number.

Example

Trap to debugger:

int \$3

Trap to interrupt 0xff:

int \$0xff

Trap to interrupt 4:

into

Interrupt Return (iret)

iret

Operation

 $return \rightarrow routine$

Description

In Real Address Mode, iret pops CS, the flags register, and the instruction pointer from the stack and resumes the routine that was interrupted. In Protected Mode, the setting of the nested task flag (NT) determines the action of iret. The IOPL flag register bits are changed when CPL equals 0 and the new flag image is popped from the stack.

iret returns from an interrupt procedure without a task switch if NT equals 0. Returned code must be equally or less privileged than the interrupt routine as indicated CS selector RPL bits popped from the stack. If the returned code is less privileged, iret pops SS and the stack pointer from the stack.

iret reverses the operation of an INT or CALL that caused the task switch if NT equals 1. The task executing iret is updated and saved in its task segment. The code that follows iret is executed if the task is re-entered.

Example

Resume the interrupted routine:

iret

Protection Model Instructions

Store Local Descriptor Table Register (sldt)

sldt r/m16

Operation

 $LDTR \rightarrow r/m[16]$

Description

The Local Descriptor Table Register (LDTR) is stored by sldt as indicated by the effective address operand. LDTR is stored into the two-byte register or the memory location.

sldt is not used in application programs. It is used only in operating systems.

Example

Store the LDTR in the effective address (addressed by the EBX register plus and offset of 5):

sldt 5(%ebx)

Store Task Register (str)

str r/m16

Operation

 $STR \rightarrow r/m(16$

Description

The contents of the task register is stored by sldt as indicated by the effective address operand. STR is stored into the two-byte register or the memory location.

Example

Store str in the effective address (addressed by the EBX register plus an offset of 5): str 5(%ebx)

Load Local Descriptor Table Register (lldt)

lldt r/m16

Operation

 $SELECTOR \to LDTR$

Description

LDTR is loaded by LLDT. The operand (word) contains a selector to a local GDT (Global Descriptor Table). The descriptor registers are not affected. The task state segment LDT field does not change.

The LDTR is marked invalid if the selector operand is 0. A #GP fault is caused by all descriptor references (except LSL VERR, VERW, or LAR instructions).

LLDT is not used in application programs. It is used in operating systems.

Example

Load the LLDT register from the effective address (addressed by the EBX register plus and offset of 5):

11dt 5(%ebx)

Load Task Register (ltr)

ltr r/m16

Operation

r/m16 → Task Register

Description

The task register is loaded by LTR from the source register or memory location specified by the operand. The loaded task state segment is tagged busy. A task switch does not occur.

Example

Load the TASK register from the effective address (addressed by the EBX register plus and offset of 5):

ltr 5(%ebx)

Verify a Segment for Reading or Writing (verr, verw)

verr r/m16 verw r/m16

Operation

 $1 \rightarrow ZF$ (if segment can be read or written)

Description

VERR and VERW contains the value of a selector in the two-byte register or memory operand. VERR and VERW determine if the indicated segment can be reached in the current privilege level and whether it is readable (VERR) or writable (VERW). If the segment can be accessed, the zero flag (ZF) is set to 1, otherwise the zero flag is set to 0. For the zero flag to be set these conditions must be met:

- The selector denotes a descriptor; the selector is "defined".
- The selector is a code or data segment; not a task statement, LDT or a gate.
- For VERR, the segment must be readable, for VERW, writable.
- The descriptor privilege level (DPL) can be any value for VERR. otherwise the DPL must have the same or less privilege as the current level and the DPL of the selector.

Validation is performed as if the segment were loaded into DS, ES, FS, or GS and the indicated write or read performed. The validation results are indicated by the zero flag. The value of the selector cannot result in an exception.

Example

Determine if the segment indicated by the effective address (addressed by the EBX register plus an offset of 5) can be reached in the current privilege level and whether it is readable (VERR):

verr 5(%ebx)

Store Global/Interrupt Descriptor Table Register (sgdt, sidt)

sgdt mem48 sidt mem48

Operation

 $DTR \rightarrow \, mem48$

Description

The contents of the descriptor table register is copied by sgdt/sidt to the six bytes of memory specified by the operand. The first word at the effective address is assigned the LIMIT field of the register. If the operand-size attribute is 32-bits:

- The base field of the register is assigned to the next three bytes.
- The fourth byte is written as zero.
- The last byte is undefined.

If the operand-size attribute is 16-bits, the 32-bit BASEfield of the register is assigned to the next four bytes.

sgdt/sldt are not used in application programs, they are used in operating systems.

Example

Copy the contents of the Global Descriptor Table Register to the specified memory location:

sgdt 0x55555555

Copy the contents of the Interrupt Descriptor Table Register to the effective address (addressed by the EBX register plus an offset of 5):

Load Global/Interrupt Descriptor Table (lgdt, lidt)

lgdt mem48 lidt mem48

Operation

 $MEM48 \rightarrow GDTR \ MEM48 \rightarrow IDTR$

Description

The GDTR and IDTR are loaded with a linear base address and limit value from a six-byte operand in memory by the lgdt/lidt instructions. For a 16-bit operand:

- Load the register with a 16-bit limit and a 24-bit base.
- The six-byte data operand high-order eight bits are not used.

For a 32-bit operand:

- Load the register with a 16-bit limit and a 32-bit base.
- The six-byte data operand high-order eight bits are used as the high-order base address bits.

All 48-bits of the six-byte data operand are always stored into by the sgdt/sidt instructions. For a 16-bit and a 32-bit operand, the upper eight-bits are written with the high-order eight address bits. lgdt or lidt, when used with a 16-bit operand to load the register stored by sgdt or sidt, stores the upper eight-bits as zeros.

lgdt and lidt are not used in application programs; they are used in operation system. lgdt and lidt are the only instructions that load a linear address directly in 80386 Protected Mode.

Example

Load the Global/Interrupt Descriptor Table Register from memory address 0x55555555:

lgdt 0x55555555 lidt 0x55555555

Store Machine Status Word (smsw)

smsw r/mle

Operation

 $MSW \rightarrow r/m16$

Description

The machine status word is stored by smsw in the two-byte register of memory location pointed to by the effective address operand.

80386 machines should use MOV ..., CR0.

Example

Store the machine status word in the effective address (addressed by the EBX register plus an offset of 5):

smsw 5(%ebx)

Load Machine Status Word (lmsw)

r/m16 lmsw

Operation

 $r/m16 \rightarrow MSW$

Description

The machine status word (part of CR0) is loaded by lmsw from the source operand. lmsw can be used to switch to Protected Mode if followed by an intersegment jump to clear the instruction queue. 1msw cannot switch back to Real Address Mode.

lmsw is not used in application programs. It is used in operating systems.

Example

Load the machine status word from the contents of the effective address (addressed by the EBX register plus an offset of 5):

lmsw 5(%ebx)

Load Access Rights (lar)

lar r/m32, reg32

Operation

```
r/m16 (masked by FF00) \rightarrow r16 r/m32 (masked by 00FxFF00) \rightarrow r32
```

Description

If the selector is visible at the CPL (modified by the RPL) and is a valid descriptor type, lar stores a form of the second doubleword of the descriptor for the source selector. The designated register is loaded with the double-word (high-order) of the descriptor masked by 00FxFF00, and the zero flag is set to 1. The x in 00Fx ... indicates that these four bits loaded by lar are undefined. The zero flag is cleared if the selector is invisible or of the wrong type.

The 32-bit value is stored in the 32-bit destination register if the 32-bit operand size is specified. If the 16-bit operand size is specified, the lower 16-bits of this value are stored in the 16-bit destination register.

For lar, all data segment descriptors and code are valid.

Example

Load access rights from the contents of the effective address (addressed by the EBX register plus an offset of 5) into the EDX register:

```
lar 5(%ebx), %edx
```

Load Segment Limit (lsl)

```
lsl r/m32, reg32
```

Operation

```
Selector rm16 (byte) \rightarrow r16
Selector rm32 (byte) \rightarrow r32
Selector rm16 (page) \rightarrow r16
Selector rm32 (page) \rightarrow r32
```

Description

lsl loads a register with a segment limit (unscrambled). The descriptor type must be accepted by lsl, and the source selector must be visible at the CPL weakened by

RPL. ZF is then set to 1. Otherwise, ZF is set to 0 and the destination register is unchanged.

The segment limit is loaded as a byte value. A page value limit in the descriptor is translated by 1s1 to a byte limit before 1s1 loads it in the destination register (the 20-bit limit from the descriptor is shifted left 12 and OR'd with 00000FFFH).

1s1 stores the 32-bit granular limit in the 16-bit destination register.

For 1s1, code and data segment descriptors are valid.

Example

Load a segment limit from the contents of the effective address (addressed by the EBX register plus an offset of 5) into the EDX register.

lsl 5(%ebx), %edx

Clear Task-Switched (clts)

clts

Operation

 $0 \to TS \; Flag \; in \; CR0$

Description

The task-switched flag in register CRO is cleared by clta. The TS Flag is set by the 80386 for each task switch. The TS Flag is used as follows:

- If the TS Flag is set, each execution of the ESC instruction is trapped.
- If the TS Flag and the MP Flag are both set, execution of a Wait instruction is trapped.

If a task switch is made after an ESC instruction is started, save the processor extension context before a new ESC instruction can be run. The fault handler resets the TS Flag and saves the context.

clts is not used in application program, it is used in operating systems.

clts can only be executed at privilege level 0.

Example

Clear the TS flag:

clts

Adjust RPL Field of Selector (arpl)

arpl r16, r/m16

Operation

If RPL 1 < RPL 2, $1 \rightarrow ZF$

Description

arpl has two operands. The first operand is a 16-bit word register or memory variable that contains the value of a selector. The second operand is a word register. If the RPL field of the second operand is greater than the RPL field of the first operand, ZF is set to 1 and the RPL field of the first operand is increased to match the RPL field of the second operand. Otherwise, no change is made to the first operand and the ZF is set to 0.

arpl is not used in application programs, it is used in operating systems.

arpl guarantees that a selector to a subroutine does not request a privilege greater than allowed. Normally, the second operand of arpl is a register that contains the CS selector value of the caller.

Example

arpl %sp, 5(%ebx)

Bit Instructions

Bit Scan Forward (bsf)

 $bsf\{wl\} r/m[16|32], reg[16|32]$

Operation

```
(r/m = 0) 0 \rightarrow ZF (r/m \neq 0) 0 \rightarrow ZF
```

Description

bsf scans the bits, starting at bit 0, in the doubleword operand or the second word. If the bits are all zero, ZF is cleared. Otherwise, ZF is set and the bit index of the first set bit, found while scanning in the forward direction, is loaded into the destination register.

Example

bsf 4(%edi), %edx

Bit Scan Reverse (bsr)

```
bsr{wl} r/m[16|32], reg[16|32]
```

Operation

```
(r/m = 0) 0 \rightarrow ZF (r/m \neq 0) 0 \rightarrow ZF
```

Description

bsr scans the bits, starting at the most significant bit, in the doubleword operand or the second word. If the bits are all zero, ZF is cleared. Otherwise, ZF is set and the bit index of the first set bit found, while scanning in the reverse direction, is loaded into the destination register

Example

```
bsr 4(%edi), %edx
```

Bit Test (bt)

```
bt\{wl\} imm8, r/m[16|32]
bt\{wl\} reg[16|32], r/m[16|32]
```

Operation

 $BIT \ [LeftSRC, RightSRC] \rightarrow CF$

Description

The bit indicated by the first operand (base) and the second operand (offset) are saved by *bt* into CF (carry flag).

Example

```
btl $253, 4(%edi)
btl %edx, 4(%edi)
```

Bit Test And Complement (btc)

```
btc\{wl\} = imm8, \ r/m[16 | 32] \ btc\{wl\} = reg[16 | 32], \ r/m[16 | 32]
```

Operation

```
BIT [LeftSRC, RightSRC] \rightarrow CF NOT BIT [LeftSRC, RightSRC] \rightarrow BIT[LeftSRC, RightSRC]
```

Description

The bit indicated by the first operand (base) and the second operand (offset) are saved by *btc* into CF (carry flag) and complements the bit.

Example

```
btl $253, 4(%edi)
btl %edx, 4(%edi)
```

Bit Test And Reset (btr)

Operation

```
\begin{aligned} &BIT[LeftSRC,\,RightSRC] \rightarrow CF \\ &0 \rightarrow BIT[LeftSRC,\,RightSRC] \end{aligned}
```

Description

The value of the first operand (base) and the second operand (bit offset) are saved by btr into the carry flag and then it stores 0 in the bit.

Example

```
btrl $253, 4(%edi)
btrl $edx, 4(%edi)
```

Bit Test And Set (bts)

```
bts\{wl\}
             imm8, r/m[16|32]
bts{wl}
             reg[16|32], r/m[16|32]
```

Operation

```
BIT[LeftSRC, RightSRC] \rightarrow CF
0 \rightarrow BIT[LeftSRC, RightSRC]
```

Description

The value of the first operand (base) and the second operand (bit offset) are saved by bts into the carry flag and then it stores 1 in the bit.

Example

```
btsl $253, 4(%edi)
btsl $edx, 4(%edi)
```

Exchange Instructions

Compare and Exchange (cmpxchg)[486]

```
reg[8|16|32], r/m[8|16|32]
cmpxchg{bwl}
```

Example

```
cmpxchgb %cl, 1(%esi)
cmpxchgl %edx, 4(%edi)
```

Floating-Point Transcendental Instructions

Floating-Point Sine (fsin)

fsin

Example

Replace the contents of the top of the stack with its sine.

fsir

Floating-Point Cosine (fcos)

fcos

Example

Replace the contents of the top of the stack with its cos.

fcos

Floating-Point Sine and Cosine (fsincos)

fsincos

Example

Replace the contents of the top of the stack with its sine and then push the cosine onto the FPU stack.

fsincos

Floating-Point Constant Instructions

Floating-Point Load One (fld)

fld1

fld12+

fld12e

fldpi

fldlg2

Example

Use these constant instructions to push often-used values onto the FPU stack.

fldl 2(%ecx)

Processor Control Floating-Point Instructions

Floating-Point Load Control Word (fldcw)

fldcw r/m16

Example

Load the FPU control word with the value in the specified memory address.

fldcw 2(%ecx)

Floating-Point Load Environment (fldenv)

fldenv mem

Example

Reload the FPU environment from the source-operand specified memory space.

fldenv 2(%ecx)

Miscellaneous Floating-Point **Instructions**

Floating-Point Different Reminder (fprem)

fprem1

Example

Divide stack element $\mathbf{0}$ by stack element $\mathbf{1}$ and leave the remainder in stack element $\mathbf{0}$

fprem

Floating-Point Comparison Instructions

Floating-Point Unsigned Compare (fucom)

fucom freg

Description:

Compare stack element 0 with stack element (i). Use condition codes:

No compare: 111

(i) < stack 0: 000

(i) > stack 0: 001

(i) = stack 0: 100

Example

Compare stack element 0 with stack element 7.

fucom %st(7)

Floating-Point Unsigned Compare And Pop (fucomp)

fucomp freg

Description

Compare stack element 0 with stack element (i). Use condition codes shown for fucom. Then pop the stack.

Example

fucomp %st(7)

Floating-Point Unsigned Compare And Pop Two (fucompp)

fucompp

Description

Compare stack element 0 with stack element (i). Use condition codes shown for fucom. Then pop the stack twice.

Example

fucompp %st(7)

Load and Move Instructions

Load Effective Address (lea)

```
lea{wl} r/m[16|32], reg[16|32]
```

Operation

```
Addr(m)\,\rightarrow\,r16\,\,Addr(m)\,\rightarrow\,r32
Truncate to 16 bits(Addr(m)) → r16
Truncate to 16 bits(Addr(m)) \rightarrow r32
```

Description

The offset part of the effective address is calculated by lea and stored in the specified register. The specified register determines the operand-size attribute if the instruction. The USE attribute of the segment containing the second operand determines the address-size attribute.

Example

leal 0x33333333, %edx

Move (mov)

Operation

```
SRC \to \, DEST
```

Description

mov stores or loads the following special registers in or from a general purpose register.

- Control registers CR0, CR2, and CR3
- Debug registers DR0, DR1, DR2, DR3, DR6, and DR7
- Test registers TR6 and TR7

These instructions always use 32-bit operands.

Example

```
movl %cr3, %ebp
movl %db7, %ebp
movl %ebp, %cr3
movl %ebp, %db7
movl %tr7, %ebp
movl %ebp, %tr7
```

Move Segment Registers (movw)

```
movw sreg,r/m16
movw r/m16, sreg
```

Operation

```
r/m16 \rightarrow Sreg Sreg \rightarrow r/m16
```

Description

movw copies the first operand to the second operand, including data from a descriptor. The descriptor table entry for the selector contains the data for the

register. The DS and ES registers can be loaded with a null selector without causing an exception. Use of DS or ES however, causes a #GP(0), and no memory reference occurs.

All interrupts are inhibited until after the execution of the next instruction, after a movw into SS. Special actions and checks result from loading a segment register under Protected Mode.

Example

```
movw %CS, 5(%ebx)
movw %(%ebx), %CS
```

Move Control Registers (mov)

```
mov\{1\} creg, reg32 mov\{1\} reg32, creg
```

Operation

 $SRC \,\rightarrow\, DEST$

Description

This form of mov stores or loads the Control Register CR0, CR2, or CR4 to or from a general purpose register.

These instructions are always used with 32-bit operands.

Example

```
movl %cr3, %ebp
movl %ebp, %cr3
```

Move Debug Registers (mov)

```
\begin{array}{ll} \text{mov}\{1\} \text{ dreg, reg32} \\ \text{mov}\{1\} \text{ reg32, dreg} \end{array}
```

Operation

 $SRC \to DEST$

Description

This form of mov stores or loads the Debug Register DR1, DR2, or DR3, DR6, and DR7 to or from a general purpose register.

These instructions are always used with 32-bit operands.

Example

```
movl %db7, %ebp
movl %ebp, %db7
```

Move Test Registers (mov)

```
\begin{array}{ll} mov\{1\} & treg, reg32 \\ mov\{1\} & reg32, treg \end{array}
```

Operation

 $SRC \to DEST$

Description

This form of mov stores or loads the Test Register TR6 or TR7 to or from a general purpose register.

These instructions are always used with 32-bit operands.

Example

```
movl %tr7, %ebp
movl %ebp, %tr7
```

Move With Sign Extend (movsx)

```
\begin{array}{lll} \texttt{movsx}\{\texttt{wl}\} & \texttt{r/m8}, \ \texttt{reg}[\texttt{16} \, | \, \texttt{32}] \\ \texttt{movsxwl} & \texttt{r/m16}, \ \texttt{reg32} \end{array}
```

Operation

 $SignExtend(SRC) \rightarrow DEST$

Description

movsx reads the contents of the register or effective address as a word or byte. movsx then sign-extends the 16- or 32-bit value to the operand-size attribute of the instruction. The result is stored in the destination register by movsx.

Example

```
movsxbl 1(%esi), %edx
movsxwl 5(%ebx), %edx
```

Move With Zero Extend (movzb)

```
movzb[wl] r/m8, reg[16|32]
movzwl r/m16, reg32
```

Operation

 $SignExtend(SRC) \rightarrow DEST$

Description

movzx reads the contents of the register or effective address as a word or byte. movzx then sign-extends the 16- or 32-bit value to the operand-size attribute of the instruction. The result is stored in the destination register by movzx.

Pop Instructions

Pop All General Registers (popa)

popa{wl}

Operation

 $POP \rightarrow \ r16 \ POP \rightarrow \ r32$

Description

The eight 16-bit general registers are popped by popa. However, the SP value is not loaded into SP, It is discarded. popa restores the general registers to their values before a previous pusha was executed. DI is the first register popped.

The eight 32-bit registers are popped by popad. However, the ESP value is not loaded into ESP, it is discarded. popad restores the general registers to their values before a previous pushad was executed. EDI is the first register popped.

Push Instructions

Push All General Registers (pusha)

pusha{wl}

Operation

 $SP\,\rightarrow\,r16$

 $SP\,\rightarrow\,r32$

Description

The 16-bit or 32-bit general registers are saved by pusha and pushad, respectively. The stack pointer is decremented by 16 by pusha to hold the eight word values. The stack pointer is decremented by 32 by pushad to hold the eight doubleword values. The registers are pushed onto the stack in the order received; the stack bytes appear in reverse order. DI or EDI is the last stack pushed.

Example

pushal

Rotate Instructions

Rotate With Carry Left (rcl)

Operation

 $r/m \ high-order \ bit \rightarrow CF$

```
CF \rightarrow r/m low-order bit
r/m \rightarrow ShiftLeft
```

Description

The left rotate instruction shifts all bits in the register or memory operand specified. The carry flag (CF) is included in the rotation. The most significant bit is rotated to the carry flag, the carry flag is rotated to the least significant bit position, all other bits are shifted to the left. The result includes the original value of the carry flag.

The first operand value indicates how many times the rotate takes place. The value is either the contents of the CL register or an immediate number. For a single rotate, where the first operand is one, the overflow flag (OF) is defined. For all other cases, OF is undefined. After the shift, the carry flag bit is XORed with the most significant result bit.

Example

```
rclb $1, 1(%esi)
rclb $253, 1(%esi)
rclb %cl, 1(%esi)
rcll $1, 4(%edi)
rcll $253, 4(%edi)
rcll %cl, 4(%edi)
```

Rotate With Carry Right (rcr)

```
rcr{bwl} imm8, r/m[8|16|32]
rcr{bwl} %cl, r/m[8|16|32]
```

Operation

```
r/m high-order bit \rightarrow CF
CF \rightarrow r/m low-order bit
r/m \rightarrow ShiftRight
```

Description

The right rotate instruction shifts all bits in the register or memory operand specified. The carry flag (CF) is included in the rotation. The least significant bit is rotated to the carry flag, the carry flag is rotated to the most significant bit position, all other bits are shifted to the right. The result includes the original value of the carry flag.

The first operand value indicates how many times the rotate takes place. The value is either the contents of the CL register or an immediate number. For a single rotate, where the first operand is one, the overflow flag (OF) is defined. For all other cases,

OF is undefined. After the shift, the carry flag bit is XORed with the two most significant result bits.

Example

```
rcrb $1, 1(%esi)
rcrb $253, 1(%esi)
rcrb %cl, 1(%esi)
rcrl $1, 4(%edi)
rcrl $253, 4(%edi)
rcrl %cl, 4(%edi)
```

Rotate Left (rol)

```
rol{bwl} imm8, r/m[8|16|32] rol{bwl} %cl, r/m[8|16|32]
```

Operation

```
r/m high-order bit \rightarrow CF CF \rightarrow r/m low-order bit r/m \rightarrow ShiftLeft
```

Description

The left rotate instruction shifts all bits in the register or memory operand specified. The most significant bit is rotated to the carry flag, the carry flag is rotated to the least significant bit position, all other bits are shifted to the left. The result *does not* include the original value of the carry flag.

The first operand value indicates how many times the rotate takes place. The value is either the contents of the CL register or an immediate number. For a single rotate, where the first operand is one, the overflow flag (OF) is defined. For all other cases, OF is undefined. After the shift, the carry flag bit is XORed with the most significant result bit.

Example

```
rclb $1, 1(%esi)
rclb $253, 1(%esi)
rclb %cl, 1(%esi)
rcll $1, 4(%edi)
rcll $253, 4(%edi)
rcll %cl, 4(%edi)
```

Rotate Right (ror)

```
imm8, r/m[8|16|32]
ror{bwl}
ror\{bwl\} %cl, r/m[8|16|32]
```

Operation

```
r/m high-order bit \rightarrow CF
CF \rightarrow r/m low-order bit
r/m \rightarrow ShiftRight
```

Description

The right rotate instruction shifts all bits in the register or memory operand specified. The least significant bit is rotated to the carry flag, the carry flag is rotated to the most significant bit position, all other bits are shifted to the right. The result does not include the original value of the carry flag. The first operand value indicates how many times the rotate takes place. The value is either the contents of the CL register or an immediate number. For a single rotate, where the first operand is one, the overflow flag (OF) is defined. For all other cases, OF is undefined. After the shift, the carry flag bit is XORed with the two most significant result bits.

Example

```
rcrb $1, 1(%esi)
rcrb $253, 1(%esi)
rcrb %cl, 1(%esi)
rcrl $1, 4(%edi)
rcrl $253, 4(%edi)
rcrl %cl, 4(%edi)
```

Byte Instructions

Byte Set On Condition (setcc)

```
setcc r/m8
```

Operation

```
ConditionTrue: 1 \rightarrow r/m8
ConditionFalse: 0 \rightarrow rm/8
```

Description

If the condition is met, setcc stores a one byte at the destination specified by the effective address. If the condition is not met, setcc stores a zero byte. The following table lists the setcc condition options. Similar condition options are separated by commas, followed by the flag condition.

 TABLE 2-10
 set cc
 Condition List

Instruction (set+cc)	Set Byte If:
seta, setnbe	greater, not equal or less than, CF=0 & ZF=0
setae, setnc, setnb	equal or greater, not carry, not less than, CF=0
setb, setc, setnae	less than carry, carry = 1, not equal or greater than, CF=1
setbe, setna	equal or less than, not greater than carry, CF=1 or ZF=1
sete, setz	equal, zero, ZF=1
setg, setnle	greater, ZF=0 or SF=OF. not equal or less, ZF=1 or SF \neq OF
setge, setnl	equal or greater, not less, SF = OF
setl, setnge	less, not equal or greater, $SF \neq OF$
setle, setng	equal or less, not greater, $ZF = 1$ and $SF \neq OF$
setne, setnz	not equal, not zero, $ZF = 0$
setno	not overflow, OF = 0
setns	not sign, SF=0
seto	overflow, OF = 1
setpe, setp	parity even, parity, PF = 1
setpo, setnp	parity odd, not parity, PF = 0
sets	sign, SF = 1

set(cc) 1(%esi)

Byte Swap (bswap) [486]

bswap reg[16|32]

Example

Convert little/big endian to big/little endian by swapping bytes.

bswap %ebx

Exchange Instructions

Exchange And Add (xadd) [486]

 $xadd\{bwl\}$ reg[8|16|32], r/m[8|16|32]

Example

Exchange the byte contents of the ESI register with the byte register and load the sum into the ESI register.

xaddb %cl, 1(%esi)

Exchange Register / Memory With Register (xchg)

 $xchg\{bwl\} reg[8|16|32], r/m[8|16|32]$

Operation

 $DEST \rightarrow temp$

 $SRC \rightarrow DEST$

 $temp \rightarrow SRC$

Description

Two operands, in either order, are exchanged by xchg. During the exchange, BUS LOCK is asserted (regardless of the value of IOPL or the LOCK prefix) if a memory operand is part of the exchange.

```
xchgb %cl, 1(%esi) /*exchange byte register with EA byte */
xchgl %ebp, %eax
xchgl %ebx, %eax
xchgl %ecx, %eax
xchgl %edi, %eax
xchgl %edx, %eax
xchgl %edx, %eax
xchgl %edx, 4(%edi) /*exchange word register with EA word */
xchgl %esi, %eax
xchgl %esp, %eax
```

Miscellaneous Instructions

Write Back and Invalidate Cache (wbinvd) [486 only]

wbinvd

Example

Write back and invalidate the cache.

wbinvd

Invalidate (invd) [486 only]

invd

Example

Invalidate the entire cache.

invd

Invalidate Page (invlpg) [486 only]

invlpg mem32

Example

Invalidate a single entry in the translation lookaside buffer.

invlpg 5(%ebx)

LOCK Prefix (lock)

lock

Operation

 $LOCK\# \to NEXT\ Instruction$

Description

The LOCK # signal is asserted during execution of the instruction following the lock prefix. This signal can be used in a multiprocessor system to ensure exclusive use of shared memory while LOCK # is asserted. The bts instruction is the read-modify-write sequence used to implement test-and-run.

The lock prefix works only with the instructions listed here. If a lock prefix is used with any other instructions, an undefined opcode trap is generated.

bt, bts, btr, btc	m, r/imm
xchg	r, m
xchg	m, r
add, or, adc, sbb, and, sub, xor	m, r/imm
not, neg, inc, dec	m

Memory field alignment does not affect the integrity of lock.

If a different 80386 processor is concurrently executing an instruction that has a characteristic listed here, locked access is not guaranteed. The previous instruction:

- Does not follow a lock prefix
- Is not on the previous list of acceptable instructions
- A memory operand specified has a partial overlap with the destination operand.

Example

lock

No Operation (nop)

nop

Operation

NO OPERATION

Description

No operations are performed by nop. The xchgl %eax, eax instruction is an alias for the nop instruction.

Example

nop

Halt (hlt)

hlt Address Prefix addr16 Data Prefix data16

Operation

 $HLT \rightarrow \, ENTER \,\, HALT \,\, STATE$

Description

halt puts the 80386 in a HALT state by stopping instruction execution. Execution is resumed by an nmi or an enabled interrupt. After a halt, if an interrupt is used to continue execution, the saved CS:EIP or CS:IP value points to the next instruction (after the halt).

The halt instruction is privileged.

Example

hlt

Real Transfer Instructions

Load Real (fld)

fld{lst}

Operation

 $SRC \to STACK \; ELEMENT \; 0$

Description

The source operand is pushed onto the stack by fld. The register used before the stack top-pointer is decremented, is the register number used if the source is a register.

Example

Load stack element 7 onto stack element 0.

fld %st (7)

Store Real (fst)

fst{ls}

Operation

STACK ELEMENT $0 \rightarrow DESTINATION$

Description

The current value of stack element 0 is copied to the destination. The destination can be a single- or double-real memory operand or another register.

Example

Store the contents of stack element 7 onto stack element 0.

%fst (7)

Store Real and Pop (fstp)

fstp{lst}

Operation

STACK ELEMENT 0 -> DESTINATION THEN POP

Description

The current value of stack element 0 is copied to the destination. The destination can be a single-, double-, or extended-real memory operand, or another register. Then pop the stack register.

Example

Copy the contents of stack element 0 onto stack element 7 and pop stack element 0.

%fstp (7)

Exchange Registers (fxch)

fxch

Example

Exchange the contents of stack element 0 and stack element 7.

fxch %st(7)

Integer Transfer Instructions

Integer Load (fild)

fild{1|11}

Example

Convert the integer operand (signed) into extended-real and load it onto the floating-point stack.

fild 2(%eax)

Integer Store (fist)

 $fist{1}$

Example

Convert the value in stack element 0 into a signed integer and transfer the result to register ECX with an offset of 2.

fist 2(%ecx)

Integer Store and Pop (fistp)

 $fistp{1|11}$

Example

Convert the value in stack element 0 into a signed integer and transfer the result to register ECX with an offset of 2, then pop the stack.

fistp 2(%ecx)

Packed Decimal Transfer Instructions

Packed Decimal (BCD) Load (fbld)

fbld

Example

Convert the source operand (BCD) into extended-real and push it onto the floating-point stack.

fbld 2(%ecx)

Packed Decimal (BCD) Store and Pop (fbstp)

fbstp

Example

Convert the value in stack element 0 to a packed decimal integer and store the result in register ECX with an offset of 2, and pop the stack.

fbstp 2(%ecx)

Addition Instructions

Real Add (fadd)

 $fadd\{ls\}$

Example

Add stack element 7 to stack element 0 and return the sum to stack element 0.

fadd %st(7), %st

Real Add and Pop (faddp)

faddr

Example

Add stack element 0 to stack element 7 and return the sum to stack element 7, then pop the stack.

faddp %st, %st(7)

Integer Add (fiadd)

fiadd{1}

Example

Add the integer contents of register ECX to stack element 0.

fiadd 2(%ecx)

Subtraction Instructions

Subtract Real and Pop (fsub)

fsub{ls}

Subtract stack element 7 from stack element 0 and return the difference to stack element 0.

fsub %st(7), %st

Subtract Real (fsubp)

fsubp

Example

Subtract stack element 7 from stack element 0 and return the difference to stack element 7, then pop the stack.

fsubp %st, %st(7)

Subtract Real Reversed (fsubr)

fsubr{ls}

Example

Subtract stack element 0 from stack element 7 and return the difference to stack element 0.

fsubr %st(7), %st

Subtract Real Reversed and Pop (fsubrp)

fsubrp

Example

Subtract stack element 0 from stack element 7 and return the difference to stack element 7, then pop the stack.

fsubrp %st, %st(7)

Integer Subtract (fisubrp)

fisubrp

Example

Subtract stack element 0 from the integer contents of register ECX (with an offset of 2) and return the difference to register ECX, then pop the stack.

fisubrp 2(%ecx)

Integer Subtract Reverse (fisubr)

fisubr{1}

Example

Subtract stack element 0 from the integer contents of register ECX (with an offset of 2) and return the difference to stack element 0.

fisubr 2(%ecx)

Multiplication Instructions

Multiply Real (fmul)

fmul{ls}

Example

Multiply stack element 7 by stack element 0 and return the product to stack element 0.

fmul %st(7), %st

Multiply Real and Pop (fmulp)

fmulp

Example

Multiply stack element 0 by stack element 7 and return the product to stack element 7, then pop the stack.

fmulp %st, %st(7)

Integer Multiply (fimul)

fimul{1}

Example

Multiply the integer contents of register ECX by stack element 0, return the product to register ECX.

fimul 2(%ecx)

Division Instructions

Divide Real (fdiv)

 $fdiv\{ls\}$

Example

Divide stack element 0 by stack element 7 and return the result to stack element 0.

fdiv %st(7), %st

Divide Real and Pop (fdivp)

fdivp

Example

Divide stack element 7 by stack element 0 and return the result to stack element 7, then pop the stack.

fdivp %st, %st(7)

Divide Real Reversed (fdivr)

fdivr{ls}

Example

Divide stack element 0 by stack element 7 and return the result to stack element 7.

fdivr %st, %st(7)

Divide Real Reversed and Pop (fdivrp)

fdivrp

Example

Divide stack element 0 by stack element 7 and return the result to stack element 7, then pop the stack.

fdivrp %st, %st(7)

Integer Divide (fidiv)

 $fidiv\{1\}$

Divide stack element 0 by the integer contents of register ECX, with an offset of 2, and return the result to register ECX.

fidiv 2(%ecx)

Integer Divide Reversed (fidivr)

fidivr{1}

Example

Divide the integer contents of register ECX, with an offset of 2, by stack element 0 and return the result to stack element 0.

fidivr 2(%ecx)

Floating-Point Opcode Errors



Caution - The IA-32 Assembler generates the wrong object code for some of the floating-point opcodes fsub, fsubr, fdiv, and fdivr when there are two floating register operands, and the second op destination is not the zeroth floating-point register. This error has been made in many IA-32 assemblers and would probably cause problems if it were fixed.

Replace the following instructions, in column 1, with their substitutions, in column 2, for IA—32 platforms:

TABLE 2-11 Floating-point Opcodes

fsub %st,%st(n)	fsubr %st, %st(n)
fsubp %st,%st(n)	fsubrp %st, %st(n)
fsub	fsubr
fsubr %st,%st(n)	fsub %st, %st(n)
fsubrp %st,%st(n)	fsubp %st, %st(n)
fsubr	fsub
fdiv %st,%st(n)	fdivr %st,%st(n)
fdivp %st,%st(n)	fdivrp %st,%st(n)

 TABLE 2-11
 Floating-point Opcodes (continued)

fsub %st,%st(n)	fsubr %st, %st(n)	
fdiv	fdivr	
fdivr %st, %st(n)	fdvir %st, %st(n)	
fdivrp %st, %st(n)	fdivp %st, %st(n)	
fdivr	fdiv	

Miscellaneous Arithmetic Operations

Square Root (fsqrt)

fsqrt

Example

Replace stack element 0 with the square root of its value.

fsqrt

Scale (fscale)

fscale

Example

Add the integer value in stack element 1 to the exponent of stack element $\boldsymbol{0}$ (multiplication and division by powers of 2).

fscale

Partial Remainder (fprem)

fprem

Divide stack element 0 by stack element 1 and return the (partial) remainder to stack element 0.

fprem

Round to Integer (frndint)

frndint

Example

Round the value in stack element 0 to an integer according to the FPU control word RC field.

frndint

Extract Exponent and Significand (fxtract)

fxtract

Example

Separate stack element 0 into its exponent and significand and return the exponent to stack element 0, then push the significand onto the FPU stack.

fxtract

Absolute Value (fabs)

fabs

Example

Replace stack element 0 with its absolute value.

fabs

Change Sign (fchs)

fchs

Example

Replace the sign of stack element 0 with the opposite sign.

fchs

Comparison Instructions

Compare Real (fcom)

fcom{ls}

Example

Compare stack element 0 with stack element 7. Condition codes contain the result: No compare=111, st 0 greater than st 7=000, st 0 less than st 7=001, equal compare=100.

fcom %st(7)

Compare Real and Pop (fcomp)

 $\mathtt{fcomp}\{\mathtt{ls}\}$

Example

Compare stack element 0 with stack element 7. Condition codes contain the result: No compare=111, st 0 greater than st 7=000, st 0 less than st 7=001, equal compare=100, then pop the stack.

fcomp %st(7)

Compare Real and Pop Twice (fcompp)

fcompp

Compare stack element 0 with stack element 1. Condition codes contain the result: No compare=111, st 0 greater than st 7=000, st 0 less than st 7=001, equal compare=100, then pop the stack twice.

fcompp

Integer Compare (ficom)

ficom{1}

Example

Integer compare stack element 0 with the contents of register ECX (with an offset of 2). Condition codes contain the result: No compare=111, st 0 greater than st 7=000, st 0 less than st 7=001, equal compare=100,

ficom 2(%ecx)

Integer Compare and Pop (ficomp)

 $ficomp\{1\}$

Example

Integer compare stack element 0 with the contents of register ECX (with an offset of 2). Condition codes contain the result: No compare=111, st 0 greater than st 7=000, st 0 less than st 7=001, equal compare=100, then pop the stack.

ficomp 2(%ecx)

Test (ftst)

ftst

Example

Compare stack element 0 with the value 0.0. Condition codes contain the result: No compare=111, st 0 greater than st 7=000, st 0 less than st 7=001, equal compare=100, ftst

Examine (fxam)

fxam

Example

Report the type of object in stack element 0. FPU flags C3, C2, and C0 return the type:

Unsupported	000
NaN	001
Normal	010
Infinity	011
Zero	100
Empty	101
Denormal	110

fxam

Transcendental Instructions

Partial Tangent (fptan)

fptan

Example

Replace stack element 0 with its tangent and push a value of 1 onto the FPU stack.

Partial Arctangent (fpatan)

fpatan

Example

Divide stack element 1 by stack element 0, compute the arctangent and return the result in radians to stack element 1, then pop the stack.

fpatan

$$2^{x} - 1$$
 (f2xm1)

f2xm1

Example

Replace the contents of stack element 0 (st) with the value of (2st-1).

$$Y * log2 X (fyl2x)$$

fyl2x

Example

Compute the logarithm (base-2) of stack element 0 and multiply the result by stack element 1 and return the result to stack element 1, then pop the stack.

fy12x

$$Y * log_{2}(X+1) (fyl2xp1)$$

fyl2xp1

Example

Compute the logarithm (base-2) of stack element 0 plus 1.0 and multiply the result by stack element 1 and return the result to stack element 1, then pop the stack.

fy12xpl

Constant Instructions

Load log₂ E (fldl2e)

fldl2e

 $Push \ log_2 e \ onto \ the \ FPU \ stack$ fldl2e

Load log₂ 10 (fldl2t)

fld12t

Example

Push $\log_2 10$ onto the FPU stack. fldl2t

Load log₁₀ 2 (fldlg2)

fldlg2

Example

Push \log_{10} 2 onto the FPU stack. fldlg2

Load log_e 2 (fldln2)

fldln2

Push log₂e onto the FPU stack.

fldln2

Load pi (fldpi)

fldpi

Example

Push p onto the FPU stack.

fldpi

$$Load + 0$$
 (fldz)

Example

Push +0.0 onto the FPU stack.

fldz

Processor Control Instructions

Initialize Processor (finit, fnint)

finitfninit

Example

finit

No Operation (fnop)

fnop

Example

fnop

Save State (fsave, fnsave)

fsave fnsave

Example

fsave 2(%ecx)

Store Control Word (fstcw, fnstcw)

fstcw fnstcw

Example

fstcw 2(%ecx)

Store Environment (fstenv, fnstenv)

fstenv fnstenv

Example

fstenv 2(%ecx)

Store Status Word (fstsw, fnstsw)

fstsw fnstsw

Example

fstsw %ax

frstor 2(%ecx) CPU Wait (fwait, wait) fwait wait Example fwait Clear Exceptions (fclex, fnclex) fclex fnclex Example fclex

Decrement Stack Pointer (fdecstp)

Restore State (frstor)

frstor

Example

fdecstp

fdecstp

Free Registers (ffree)

ffree

Example

ffree %st(7)

Increment Stack Pointer (fincstp)

fincstp

Example

fincstp

Assembler Output

This chapter is an overview of ELF (*Executable and Linking Format*) for the relocatable object files produced by the assembler. The fully detailed definition of ELF appears in the System V Application Binary Interface and the Intel 386 Processor Supplement.

This chapter is organized as follows:

- "Introduction" on page 137
- "Object Files in Executable and Linking Format (ELF)" on page 138

Introduction

The main output produced by assembling an input assembly language source file is the translation of that file into an object file in (ELF). ELF files produced by the assembler are relocatable files that hold code and/or data. They are input files for the linker. The linker combines these relocatable files with other ELF object files to create an executable file or a shared object file in the next stage of program building, after translation from source files into object files.

The three main kinds of ELF files are relocatable, executable and shared object files.

The assembler can also produce ancillary output incidental to the translation process. For example, if the assembler is invoked with the -V option, it can write information to standard output and to standard error.

The assembler also creates a default output file when standard input or multiple input files are used. Ancillary output has little direct connection to the translation process, so it is not properly a subject for this manual. Information about such output appears in as(1) manual page.

Certain assembly language statements are directives to the assembler regarding the organization or content of the object file to be generated. Therefore, they have a direct effect on the translation performed by the assembler. To understand these directives, described in Chapter 2 it is helpful to have some working knowledge of ELF, at least for relocatable files.

Object Files in Executable and Linking Format (ELF)

Relocatable ELF files produced by the assembler consist of:

- An ELF header
- A section header table
- Sections

The ELF header is always the first part of an ELF file. It is a structure of fixed size and format. The fields, or members, of the structure describe the nature, organization and contents of the rest of the file. The ELF header has a field that specifies the location within the file where the section header table begins.

The section header table is an array of section headers that are structures of fixed size and format. The section headers are the elements of the array, or the entries in the table. The section header table has one entry for each section in the ELF file. However, the table can also have entries (section headers) that do not correspond to any section in the file. Such entries and their array indices are reserved. The members of each section header constitute information useful to the linker about the contents of the corresponding section, if any.

All of a relocatable file's information that does not lie within its ELF header or its section header table lies within its sections. Sections contain most of the information needed to combine relocatable files with other ELF files to produce shared object files or executable files. Sections also contain the material to be combined. For example, sections can hold:

- Relocation tables
- Symbol tables
- String tables

Each section in an ELF file fills a contiguous (possibly empty) sequence of that file's bytes. Sections never overlap. However, the (set theoretic) union of a relocatable ELF header, the section header table, and all the sections can omit some of the bytes. Bytes of a relocatable file that are not in the ELF header, or in the section header table, or in any of the sections constitute the inactive space. The contents of a file's inactive space, if any, are unspecified.

ELF Header

The ELF *header* is always located at the beginning of the ELF file. It describes the ELF file organization and contains the actual sizes of the object file control structures.

The ELF header consists of the following fields, or members, some have the value $\boldsymbol{0}$ for relocatable files:

e_ident	This is a byte array consisting of the EI_NIDENT initial bytes of the ELF header, where EI_NIDENT is a name for 16. The elements of this array mark the file as an ELF object file and provide machine-independent data that can be used to decode and interpret the file's contents.
e_type	Identifies the object file type. A value of 1, that has the name ET_REL, specifies a relocatable file. Table 3–1 describes all the object file types.
e_machine	Specifies the required architecture for an individual file. A value of 3, that has the name EM_386, specifies Intel 80386. EM_486, specifies Intel 80486.
e_version	Identifies the version of this object file's format. This field should have the current version number, named EV_CURRENT.
e_entry	Virtual address where the process is to start. A value of 0 indicates no associated entry point.
e_phoff	Program header table's file offset, in bytes. The value of 0 indicates no program header. (Relocatable files do not need a program header table.)
e_shoff	Section header table's file offset, in bytes. The value of 0 indicates no section header table. (Relocatable files must have a section header table.)
e_flag	Processor-specific flags associated with the file. For the Intel 80386, this field has value 0.
e_ehsize	ELF header's size, in bytes.

e_phentsize	Size, in bytes, of entries in the program header table. All entries are the same size. (Relocatable files do not need a program header table.)
e_phnum	Number of entries in program header table. A value of 0 indicates the file has no program header table. (Relocatable files do not need a program header table.)
e_shentsize	Size, in bytes, of the section header structure. A section header is one entry in the section header table; all entries are the same size.
e_shnum	Number of entries in section header table. A value of 0 indicates the file has no section header table. (Relocatable files must have a section header table.)
e_shstrndx	Section header table index of the entry associated with the section name string table. A value of Shn_under indicates the file does not have a section name string table.

TABLE 3–1 Object File Types

Туре	Value	Description
none	0	No file type
rel	1	Relocatable file
exec	2	Executable file
dyn	3	Shared object file
core	4	Core file
loproc	0xff00	Processor-specific
hiproc	0xffff	Processor-specific

Section Header

The section header table has all of the information necessary to locate and isolate each of the file's sections. A section header entry in a section header table contains information characterizing the contents of the corresponding section, if the file has such a section.

Each entry in the section header table is a section header. A section header is a structure of fixed size and format, consisting of the following fields, or members:

sh_name	Specifies the section name. The value of this field is an index into the section header string table section, wherein it indicates the beginning of a null-terminated string that names the section.
sh_type	Categorizes the section's contents and semantics. Table 3-3 describes the section types.
sh_flags	One-bit descriptions of section attributes. Table 3–2 describes the section attribute flags.
sh_addr	Address where the first byte resides if the section appears in the memory image of a process; a value of 0 indicates the section does not appear in the memory image of a process.
sh_offset	Specifies the byte offset from the beginning of the file to the first byte in the section.
	Note - If the section type is SHT_NOBITS, the corresponding section occupies no space in the file. In this case, sh_offset specifies the location at which the section would have begun if it did occupy space within the file.
sh_size	Specifies the size, in byte units, of the section.
	Note - Even if the section type is SHT_NOBITS, sh_size can be nonzero; however, the corresponding section still occupies no space in the file.
sh_link	Section header table index link. The interpretation of this information depends on the section type, as described in Table 3-3.

sh_info	Extra information. The interpretation of this information depends on the section type, as described in Table 3–3.
sh_addralign	If a section has an address alignment constraint, the value in this field is the modulus, in byte units, by which the value of sh_addr must be congruent to 0; i.e., sh_addr = 0 (mod sh_addralign). For example, if a section contains a long (32 bits), the entire section must be ensured long alignment, so sh_addralign has the value 4. Only 0 and positive integral powers of 2 are currently allowed as values for this field. A value of 0 or 1 indicates no address alignment constraints.
sh_entsize	Size, in byte units, for entries in a section that is a table of fixed-size entries, such as a symbol table. Has the value 0 if the section is not a table of fixed-size entries

TABLE 3–2 Section Attribute Flags

Flag	Default Value	Description
SHF_WRITE	0x1	Contains data that is writable during process execution.
SHF_ALLOC	0x2	Occupies memory during process execution. This attribute is <i>off</i> if a control section does not reside in the memory image of the object file.
SHF_EXECINSTR	0x4	Contains executable machine instructions.
SHF_MASKPROC	0xf0000000	Reserved for processor-specific semantics.

TABLE 3–3 Section Types

Name Value Descripti		Description	on Interpretation by	
			sh_info	sh_link
SHT_NULL	0	Marks section header as inactive; file has no corresponding section.	0	SHN_UNDEF
SHT_PROGBITS	1	Contains information defined by the program, and in a format and with a meaning determined solely by the program.	0	SHN_UNDEF
SHT_SYMTAB	2	Is a complete symbol table, usually for link editing. This table can also be used for dynamic linking; however, it can contain many unnecessary symbols.	One greater than the symbol table index of the last local symbol.	The section header index of the associated string table.
		Note: Only one section of this type is allowed in a file		
SHT_STRTAB	3	Is a string table. A file can have multiple string table sections.	0	SHN_UNDEF
SHT_RELA	4	Contains relocation entries with explicit addends. A file can have multiple relocation sections.	The section header index of the section to where the relocation applies.	The section header index of the associated symbol table.
SHT_HASH	5	Is a symbol rehash table.	0	The section
		Note: Only one section of this type is allowed in a file		
SHT_DYNAMIC	6	Contains dynamic linking information.	0	The section header index
		Note: Only one section of this type is allowed in a file		of the string table used by entries in the section.
SHT_NOTE	7	Contains information that marks the file.	0	SHN_UNDEF

 TABLE 3-3
 Section Types
 (continued)

Name	Value	Description	Interpretation by	
			sh_info	sh_link
SHT_NOBITS	8	Contains information defined by the program, and in a format and with a meaning determined by the program. However, a section of this type occupies no space in the file, but the section header's <i>offset</i> field specifies the location at which the section would have begun if it did occupy space within the file.	0	SHN_UNDEF
SHT_REL	9	Contains relocation entries without explicit addends. A file can have multiple relocation sections.	The section header index of the section to where the relocation applies.	The section header index of the associated symbol table.
SHT_SHLIB	10	Reserved.	0	SHN_UNDEF
SHT_DYNSYM	11	Is a symbol table with a minimal set of symbols for dynamic linking. Note: Only one section of this type is allowed in a file	One greater than the symbol table index of the last local symbol.	The section header index of the associated string table.
SHT_LOPROC	0x70000000 0x7fffffff	Lower and upper bounds of range of section types reserved for processor-specific semantics.	0	SHN_UNDEF
SHT_HIPROC				
SHT_LOUSER SHT_HIUSER	0x80000000 0xffffffff	Lower and upper bounds of range of section types reserved for application programs.	0	SHN_UNDEF
		Note: Section types in this range can be used by an application without conflicting with system-defined section types.		

Note - Some section header table indices are reserved, and the object file does not contain sections for these special indices.

Sections

A section is the smallest unit of an object file that can be relocated. Sections containing the following material usually appear in relocatable ELF files:

- Executable text
- Read-only data
- Read-write data
- Read-write uninitialized data (only section header appears)

Sections do not need to occur in any particular order within the object file. The sections of a relocatable ELF file contain all of the file information that is not contained in the ELF header or in the section header table. The sections in any ELF file must satisfy several conditions:

- Every section in the file must have one section header entry in the section header table to describe the section. However, the section header table can have section header entries that correspond to no section in the file.
- 2. Each section occupies one contiguous sequence of bytes within a file. The section can be empty (even so, its section header entry in the section header table can have a nonzero value for the field sh size).
- 3. A byte in a file can reside in at most one section. Sections in a file cannot overlap.
- 4. An object file can have inactive space. Inactive space is the set of all bytes in the file that are not part of the ELF header, the section header table, the program header table (for executable files), or of any section in the file. The contents of the inactive space are unspecified.

Sections can be added for multiple text or data segments, shared data, user-defined sections, or information in the object file for debugging.

Note - Not all of the sections where there are entries in the file section header table need to be present.

Predefined Sections

Sections having certain names beginning with "." (dot) are predefined, with their types and attributes already assigned. These special sections are of two kinds: predefined user sections and predefined nonuser sections.

Predefined User Sections

Sections that an assembly language programmer can manipulate by issuing section control directives in the source file are *user sections*. The predefined user sections are those predefined sections that are also user sections.

Table 3-4 lists the names of the predefined user sections and briefly describes each.

TABLE 3-4 Predefined User Sections

Section Name	Description
".bss"	Uninitialized read-write data.
".comment"	Version control information.
".data" & ".data1"	Initialized read-write data.
".debug"	Debugging information.
".fini"	Runtime finalization instructions.
".init"	Runtime initialization instructions.
".rodata" & ".rodata1"	Read-only data.
".text"	Executable instructions.
".line"	Line # info for symbolic debugging.
".note"	Special information from vendors or system builders.

Predefined Non-User Sections

Table 3–5 shows the predefined sections that are not user sections, because assembly language programmers cannot manipulate them by issuing section control directives in the source file.

TABLE 3-5 Predefined Non-user Sections

Section Name	Description
".dynamic"	Dynamic linking information.
".dynstr"	Strings needed for dynamic linking.
".dynsym"	Dynamic linking symbol table.
".got"	Global offset table.
".hash"	A symbol hash table.

TABLE 3–5 Predefined Non-user Sections

Section Name	Description
".interp"	The path name of a program interpreter.
".plt"	The procedure linking table.
"rel <i>name</i> " & ".rela <i>name</i> "	Relocation information. name is the section to which the relocations apply. e.g., ".rel.text", ".rela.text".
".shstrtab"	String table for the section header table names.
".strtab"	The string table.
".symtab"	The symbol table.

Relocation Tables

Locations represent addresses in memory if a section is allocatable; that is, its contents are to be placed in memory at program runtime. Symbolic references to these locations must be changed to addresses by the link editor.

The assembler produces a companion relocation table for each relocatable section. The table contains a list of relocations (that is, adjustments to locations in the section) to be performed by the link editor.

Symbol Tables

The symbol table contains information to locate and relocate symbolic definitions and references. The assembler creates the symbol table section for the object file. It makes an entry in the symbol table for each symbol that is defined or referenced in the input file and is needed during linking.

The symbol table is then used by the link editor during relocation. The symbol table's section header contains the symbol table index for the first non-local symbol.

The symbol table contains the following information:

Index into the object file symbol string table. A st_name value of zero indicates the corresponding entry in the symbol table has no name; otherwise, the value represents the string table index that gives the symbol name.

st_value	Value of the associated symbol. This value is dependent on the context; for example, it can be an address, or it can be an absolute value.
st_size	Size of symbol. A value of 0 indicates that the symbol has either no size or an unknown size.
st_info	Specifies the symbol type and binding attributes. Table 3–6 and Table 3–7 describe the symbol types and binding attributes.
st_other	Undefined meaning. Current value is 0.
st_shndx	Contains the section header table index to another relevant section, if specified. As a section moves during relocation, references to the symbol continue to point to the same location because the value of the symbol changes as well.

TABLE 3-6 Symbol Types

Value	Туре	Description
0	notype	Type not specified.
1	object	Symbol is associated with a data object; for example, a variable or an array.
2	func	<i>Symbol</i> is associated with a function or other executable code. When another object file references a function from a shared object, the link editor automatically creates a procedure linkage table entry for the referenced symbol.
3	section	Symbol is associated with a section. These types of symbols are primarily used for relocation.
4	file	Gives the name of the source file associated with the object file.
13	loproc	Values reserved for processor-specific semantics.
15	hiproc	

TABLE 3–7 Binding Attributes

Value	Binding	Description
0	local	Symbol is defined in the object file and not accessible in other files. Local symbols of the same name can exist in multiple files.
1	global	Symbol is either defined externally or defined in the object file and accessible in other files.
2	weak	<i>Symbol</i> is either defined externally or defined in the object file and accessible in other files; however, these definitions have a lower precedence than globally defined symbols.
13	loproc	Values reserved for processor-specific semantics.
15	hiproc	

String Tables

A string table is a section which contains null-terminated variable-length character sequences, or strings. The object file uses these strings to represent symbol names and file names. The strings are referenced by indices into the string table section. The first and last bytes of a string table must be the null character.

- A string table index can refer to any byte in the section.
- Empty string table sections are permitted if zero is the value of sh_size in the section header entry for the string table in the section header table.

A string can appear multiple times and can also be referenced multiple times. References to substrings can exist, and unreferenced strings are allowed.

Attribute Expression

Attribute expressions are used to generate entries of relocation table. The form of the attribute expression is:

symbol-name@attribute

Attributes begin with the @ sign followed by a reserved identifier. Table 3-8 describes the identifier attributes used in the IA-32 assembler.

TABLE 3-8 Identifier Attributes

Attribute	Description	Relocation Table Entry Generated
@GOT	Address of the Global Offset Table (GOT) entry for the identifier	R_386_GOT32
@GOTOFF	The difference between a symbol's value and the Global Offset Table (GOT).	R_386_GOTOFF
@PLT	Address of a function's Procedure Linkage Table ()LT) entry	R_386_PLT32

 $\mbox{\bf Note}$ - To obtain correct position-independent code, conform to the IA–32 architecture and the System V ABI.

The special symbol <code>_GLOBAL_OFFSET_TABLE_</code> can be used in the IA–32 assembler for building of position-independent code.

Using the Assembler Command Line

This chapter describes how to invoke the assembler and use the command-line options.

This chapter is organized as follows:

- "Assembler Command Line" on page 151
- "Assembler Command Line Options" on page 152
- "Disassembling Object Code" on page 154

Assembler Command Line

Invoke the assembler command line as follows:

as [options] [inputfile] ...

Note - The language drivers (such as cc and f77) invoke the assembler command line with the fbe command. You can use either the as or fbe command to invoke the assembler command line.

The as command translates the assembly language source files, *inputfile*, into an executable object file, *objfile*. The assembler recognizes the file name argument *hyphen* (-) as the standard input. It accepts more than one file name on the command line. The input file is the concatenation of all the specified files. If an invalid option is given or the command line contains a syntax error, the assembler prints the error (including a synopsis of the command line syntax and options) to standard error output, and then terminates.

The assembler supports #define macros, #include files, and symbolic substitution through use of the C preprocessor *cpp*. The assembler invokes the preprocessor before assembly begins if it has been specified from the command line as an option. (See the -P option.)

Assembler Command Line Options

Enable Sun SourceBrowser. -b When the -P option is in effect, these options are -Dname passed to the *cpp* preprocessor without interpretation by the as command; otherwise, they are ignored. -Ipath When the -P option is in effect, this option is passed to the *cpp* preprocessor without interpretation by the as command; otherwise, it is ignored. -K {pic.PIC} Generate position-independent code. Save all symbols, including temporary labels that -Lare normally discarded to save space, in the ELF symbol table. This new option runs m4 macro preprocessing on -m input. The *m4* preprocessor is more powerful than the C preprocessor (invoked by the -P option), so it is more useful for complex preprocessing. See the m4(1) for a detailed description of the m4 macro-processor. -o outfile Takes the next argument as the name of the output file to be produced. By default, the .s suffix, if present, is removed from the input file and the .o suffix is appended to form the output file name. -P Run *cpp*, the C preprocessor, on the files being assembled. The preprocessor is run separately on each input file, not on their concatenation. The preprocessor output is passed to the assembler.

This new option produces the "assembler version" information in the comment section of the output object file if the y option is specified; if the n option is specified, the information is suppressed.

-s

This new option places all stabs in the .stabs section. By default, stabs are placed in stabs.excl sections, that are stripped out by the static linker ld during final execution. When the -s option is used, stabs remain in the final executable because .stab sections are not stripped out by the static linker ld.

-S [[aAbBcClL]]

Produce a disassembly of the emitted code to the standard output. Adding the character to the S option:

- a disassembling with address
- b disassembling with '.bof'
- c disassembling with comments (default)
- l disassembling with line numbers

Capital letters turn switch off for corresponding option

-T

This is a migration option for 4.1 assembly files to be assembled on 5.0 systems. With this option, the symbol names in 4.1 assembly files will be interpreted as 5.0 symbol names.

-U**name**

When the $\neg P$ option is in effect, this option is passed to the $\it cpp$ preprocessor without interpretation by the as command; otherwise, it is ignored.

-V

This option writes the version information on the standard error output.

-xF

Generates additional information for performance analysis of the executable using WorkShop (SPARCworks) analyzer. If the input file does not contain any stabs (debugging directives), then the assembler will generate some default stabs which are needed by the SPARCworks analyzer.

Disassembling Object Code

The dis program is the object code disassembler for ELF. It produces an assembly language listing of the object file. For detailed information about this function, see the dis(1) manual page.

Index

A addresses 147 addressing mode base and index 28 offset 28	I/O inst immed input fo instruct ado
scale 28	
segment register 27	
as command 151	
assembler (as)	
addition instructions 120	
arithmetic logical instructions 49, 62	
bit instructions 96, 99	
byte instructions 111, 113	
comparison instructions 127, 129	
constant instructions 131, 133	
conversion instructions 67, 68	
coprocessor instructions 73	
decimal arithmetic instructions 69, 72	
division instructions 123, 124	
exchange instructions 99, 113 expressions 22, 28	
flag instructions 44, 49	
floating point comparison	
instructions 102, 103	
floating point constant instructions 100,	
101	
floating point opcode errors 124	
floating point transcendental	
instructions 100	

O instructions 42 immediate values 28 input format 18, 19 instruction descriptions 27, 38 addressing modes 27, 28

instructions	load and move instructions 103, 107
addition 120	miscellaneous arithmetic operations 125,
arithmetic logical 49 to 62	126
arithmetic/logical 49	miscellaneous instructions 114, 116
bit 96 to 99	mnemonics
byte 111, 113	addition 120
comparison 127 to 129	arithmetic 125
constant 131 to 133	multiplication instructions 122
conversion 67, 68	multiply and divide instructions 63, 66
coprocessor 73	object file
decimal arithmetic 69 to 72	.comment section 21
division 123, 124	operands
exchange 99, 113	immediate 25
flag 44 to 49	memory 25
floating point comparison 102, 103	overview 25
floating point constant 100, 101	register 25
floating point transcendental 100	operations, dbx pseudo 33
I/O 42, 43	operations, general pseudo 29, 32
integer transfer 118, 119	operators 22
interrupt 86, 87	other floating point instructions 101
jump 84, 85	packed decimal transfer instructions 119
load and move 103 to 107	pop instructions 107
load full pointer 40	procedure call and return
miscellaneous 114 to 116	instructions 79, 83
miscellaneous arithmetic	process control floating point
operations 125, 126	instructions 101
miscellaneous floating point 101	processor control instructions 133, 136
multiply 122	protection model instructions 88, 96
multiply and divide 63 to 66	push instructions 108
packed decimal transfer 119	real transfer instructions 117, 118
pop 107	rotate instructions 108, 111
pop stack into word 41	segment register instructions 40, 41
procedure call 79	statements
procedure call and return 79 to 83	assignment 19
processor control 133 to 136	empty 19
processor control floating point 101	machine operation 19
protection model 88 to 96	modifying 19
push 108	pseudo operation 19
push stack into word 41	string instructions 73, 78
real transfer 117, 118	subtraction instructions 120, 122
return 79	SunOS vs. Intel, mnemonics 36, 136
rotate 108 to 111	notational coventions 36
string 73 to 78	symbols 20
subtraction 120 to 122	syntax rules 22, 24
transcendental 130, 131	transcendental instructions 130, 131
integer transfer instructions 118, 119	types 19, 21
interrupt instructions 86, 87	values 19, 21
iumn instructions 8/ 85	

assembler command line 151	sh_addr 141
assembler command line options 152	sh_addralign 142
assembly language 17	sh_entsize 142
<i>y b b</i>	sh_flags 141
C	sh_info 142
C	sh_link 142
cc language driver 151	sh_name 141
command line options	sh_offset 141
- 152	sh_size 141
-l 152	sh_type 141
-o 152	
-P 153	ELF string table 149
-Q 153	ELF symbol table 147
-s 153	st_info 148
-U 153	st_name 148
-V 153	st_other 148
. 100	st_shndx 148
D	st_size 148
D	st_value 148
default output file 137	expression
dis program 154	absolute 23
disassembling object code 154	relocatable 23
F	F
E	
ELF header	f77 language driver 151
ELF header e_ehsize 140	f77 language driver 151 fbe command 151
ELF header e_ehsize 140 e_entry 139	f77 language driver 151
ELF header e_ehsize 140 e_entry 139 e_flag 139	f77 language driver 151 fbe command 151 .file 30
ELF header e_ehsize 140 e_entry 139 e_flag 139 e_ident 139	f77 language driver 151 fbe command 151
ELF header e_ehsize 140 e_entry 139 e_flag 139 e_ident 139 e_machine 139	f77 language driver 151 fbe command 151 file 30
ELF header e_ehsize 140 e_entry 139 e_flag 139 e_ident 139 e_machine 139 e_phentsize 140	f77 language driver 151 fbe command 151 file 30
ELF header e_ehsize 140 e_entry 139 e_flag 139 e_ident 139 e_machine 139 e_phentsize 140 e_phnum 140	f77 language driver 151 fbe command 151 .file 30 G .globl 30
ELF header e_ehsize 140 e_entry 139 e_flag 139 e_ident 139 e_machine 139 e_phentsize 140 e_phnum 140 e_phoff 139	f77 language driver 151 fbe command 151 .file 30 G .globl 30 H
ELF header e_ehsize 140 e_entry 139 e_flag 139 e_ident 139 e_machine 139 e_phentsize 140 e_phnum 140	f77 language driver 151 fbe command 151 .file 30 G .globl 30
e_ehsize 140 e_entry 139 e_flag 139 e_ident 139 e_machine 139 e_phentsize 140 e_phnum 140 e_phoff 139 e_shentsize 140 e_shnum 140	f77 language driver 151 fbe command 151 .file 30 G .globl 30 H
e_ehsize 140 e_entry 139 e_flag 139 e_ident 139 e_machine 139 e_phentsize 140 e_phnum 140 e_phoff 139 e_shentsize 140 e_shnum 140 e_shnum 140 e_shnum 140	f77 language driver 151 fbe command 151 .file 30 G .globl 30 H hyphen (-) 151
e_ehsize 140 e_entry 139 e_flag 139 e_ident 139 e_machine 139 e_phentsize 140 e_phnum 140 e_phoff 139 e_shentsize 140 e_shnum 140 e_shnum 140 e_shoff 139 e_shoff 139 e_shstrndx 140	f77 language driver 151 fbe command 151 .file 30 G .globl 30 H hyphen (-) 151
e_ehsize 140 e_entry 139 e_flag 139 e_ident 139 e_machine 139 e_phentsize 140 e_phnum 140 e_phoff 139 e_shentsize 140 e_shnum 140 e_shnum 140 e_shoff 139 e_shstrndx 140 e_type 139	f77 language driver 151 fbe command 151 .file 30 G .globl 30 H hyphen (-) 151 I -I option 152
e_ehsize 140 e_entry 139 e_flag 139 e_flag 139 e_ident 139 e_machine 139 e_phentsize 140 e_phnum 140 e_phoff 139 e_shentsize 140 e_shnum 140 e_shnum 140 e_shoff 139 e_shstrndx 140 e_type 139 e_version 139	f77 language driver 151 fbe command 151 .file 30 G .globl 30 H hyphen (-) 151 I -I option 152 instructions
e_ehsize 140 e_entry 139 e_flag 139 e_ident 139 e_machine 139 e_phentsize 140 e_phnum 140 e_phoff 139 e_shentsize 140 e_shnum 140 e_shnum 140 e_shoff 139 e_shstrndx 140 e_type 139	f77 language driver 151 fbe command 151 .file 30 G .globl 30 H hyphen (-) 151 I -I option 152 instructions addition
e_ehsize 140 e_entry 139 e_flag 139 e_flag 139 e_ident 139 e_machine 139 e_phentsize 140 e_phnum 140 e_phoff 139 e_shentsize 140 e_shnum 140 e_shnum 140 e_shoff 139 e_shstrndx 140 e_type 139 e_version 139	f77 language driver 151 fbe command 151 .file 30 G .globl 30 H hyphen (-) 151 I -I option 152 instructions addition fadd() 120
e_ehsize 140 e_entry 139 e_flag 139 e_flag 139 e_ident 139 e_machine 139 e_phentsize 140 e_phnum 140 e_phoff 139 e_shentsize 140 e_shnum 140 e_shoff 139 e_shstrndx 140 e_type 139 e_version 139 ELF section 145	f77 language driver 151 fbe command 151 .file 30 G .globl 30 H hyphen (-) 151 I -I option 152 instructions addition

arithmetic logical	conversion
adc() 50	cbtw() 67
add() 49	cltd() 68
and() 60	cwtd() 68
bound() 59	cwtl() 68
cmp() 52	coprocessor
dec() 54	fwait() 73
inc() 53	wait() 73
neg() 58	decimal arithmetic
not() 58	aaa() 70
or() 61	aad() 72
sal() 55	aam() 72
sar() 55	aas() 71
sbb() 52	daa() 69
shl() 55	das() 69
shld() 56	division
shr() 55	fdiv() 123
shrd() 57	fdivr() 123
sub() 51	fdivrp() 123
test() 54	fidiv() 123
xor() 62	fidivr() 124
bit	exchange
bsf() 96	cmpxchg() 99
bsr() 97	xadd() 113
bt() 97	xchg() 113
btc() 98	flag
btr() 98	clc() 47
bts() 99	cld() 48
byte	cli() 47
bswap() 113	cmc() 46
setcc() 111	lahf() 44
comparison	popf() 45
fcom() 127	pushf() 46
fcomp() 127	sahf() 45
fcompp() 127	stc() 47
ficom() 128	std() 49
ficomp() 128	sti() 48
ftst() 129	floating point comparison
fxam() 129	fucom() 102
constant	fucomp() 102
fldl2e() 131	fucompp()' 103
fldl2t() 132	1400mPP
fldlg2() 132	
fldln2() 132	
fldpi() 133	
fldz() 133	
11020 100	

floating point constant	load full pointer
fld1() 100	lds() 40
fld12+() 100	les() 40
fld12e() 100	lfs() 40
fldlg2() 100	lgs() 40
fldln2() 101	lss() 40
fldpi() 100	miscellaneous
fldz() 101	hlt() 116
floating point transcendental	invd() 114
fcos(100	invlp() 114
fs 100	lock() 115
fsin(100	nop() 116
I/O	wbinvd() 114
in() 42	miscellaneous arithmetic o 126
ins() 42	miscellaneous arithmetic ope 125
out() 43	miscellaneous arithmetic oper 126
outs() 43	miscellaneous arithmetic operations 125
integer transfer	miscellaneous floating point
fild() 118	fprem 101
fist() 119	multiply
fistp() 119	fimul() 122
interrupt	fmul() 122
int() 86	fmulp() 122
into() 86	multiply and divide
iret() 87	div() 65
jump	idiv() 66
jcc() 85	imul() 63
jcxz() 84	imulb() 63
jmp() 85	mul() 64
ljmp() 85	packed decimal transfer
loop() 84	fbld() 119
loope() 84	fbst() 119
loopne() 84	pop
loopnz() 84	popa() 107
loopz() 84	pop stack into word
load and move	pop() 41
lea() 103	procedure call and return
mov() 104 to 106	call() 80
movsb() 106	enter() 82
movsbwl() 106	lcall() 79
movw() 104	leave() 83
movzwl() 107	lret() 81
	ret() 81

processor control	rotate
fclex() 135	rcl() 108
fdecstp() 135	rcr() 109
ffree() 136	rol() 110
fincstp() 136	ror() 111
finit() 133	string
fnclex() 135	cmps() 74
fninit() 133	lods() 76
fnop() 134	movs() 74
fnsave() 134	rep() 78
fnstcw() 134	repnz() 78
fnstenv() 134	repz() 78
fnstsw() 134	scas() 77
frstor() 135	stos() 75
fsave() 134	xlat() 78
fstcw() 134	subtraction
fstenv() 134	fisubr() 122
fstsw() 134	fisubrp() 121
wait() 135	fsub() 120
processor control floating point 101	fsubr() 121
protection model	fsubrp() 121
arpl() 96	subp() 121
lar() 93	transcendental
lgdt() 92	f2xm1() 130
lidt() 92	fptan() 130
lldt() 89	fyl2x() 131
lmsw() 93	fyl2xp1() 131
lsl() 94	invoking, as command 151
ltr() 90	myoking, as command 101
sgdt() 91	_
sidt() 91	L
sldt() 88	language drivers 151
smsw() 92	.local 31
str() 89	
verr() 90	M
verw() 90	
push	-m option 152
pusha() 108	machine instruction syntax 24, 25
push stack into word	derived type information 25
push() 41	destination operand 24
-	register name 24
real transfer	source operand 24
fld() 117 fet() 117	multiple files, on as command line 151
fst() 117	multiple sections 145
fstp() 118	multiple strings, in string table 149
fxch() 118	

N	.section 31
.nonvolatile 31	section header 141
notational conventions	sections 145
condition codes 38	statements
control register 37	append comment 19
distance of relative jump 38	assignment 19
immediate pointer 38	empty 19
immediate value 37	label prefix 19
memory operand 37	machine operation 19
J I	pseudo operation 19
0	string tables 149
0	strings
operands	multiple references in string table 149
byte register 25	unreferenced in string table 149
operations, general pseudo 29	strings, multiple in string table 149
.align val 29	sub-strings in string table
.bcd val 29	references to 149
.bss 29	symbol 32
.bss tag, bytes 29	symbol tables 147
.byte val 29	symbol types
.comm name, expr 29	absolute 20
.data 29	attribute 21
.double val 30	bss 21
.even 30	data 21
options	object file sections 21
command line 152	text 21
	undefined 20
P	symbol, reserved
-	.bss 20
-P option 152	.data 20
predefined non-user sections 146	.fini 20
predefined user sections 145	.init 20
Programming Utilities - SunOS 5.0 14	.text 20
pseudo-operations 29	
	U
Q	
-Q option 153	-U option 153
y option 100	
D.	V
R	-V option 153
relocatable files 137	volatile 32
relocation tables 147	.voidile ob

S	W
	.weak 32
-s option 153	