# 6.828 Lecture Notes: x86 and PC architecture

#### **Outline**

- PC architecture
- x86 instruction set
- gcc calling conventions
- PC emulation

#### PC architecture

- A full PC has:
  - an x86 CPU with registers, execution unit, and memory management
  - CPU chip pins include address and data signals
  - memory
  - disk
  - keyboard
  - display
  - o other resources: BIOS ROM, clock, ...
- We will start with the original 16-bit 8086 CPU (1978)
- CPU runs instructions:

```
for(;;) {
          run next instruction
}
```

- Needs work space: registers
  - four 16-bit data registers: AX, BX, CX, DX
  - each in two 8-bit halves, e.g. AH and AL
  - very fast, very few
- More work space: memory
  - CPU sends out address on address lines (wires, one bit per wire)
  - Data comes back on data lines
  - or data is written to data lines
- Add address registers: pointers into memory
  - SP stack pointer
  - o BP frame base pointer
  - SI source index
  - DI destination index
- Instructions are in memory too!
  - IP instruction pointer (PC on PDP-11, everything else)
  - increment after running each instruction
  - can be modified by CALL, RET, JMP, conditional jumps
- Want conditional jumps
  - FLAGS various condition codes
    - whether last arithmetic operation overflowed
    - ... was positive/negative

- ... was [not] zero
- ... carry/borrow on add/subtract
- ... etc.
- whether interrupts are enabled
- direction of data copy instructions
- JP, JN, J[N]Z, J[N]C, J[N]O ...
- Still not interesting need I/O to interact with outside world
  - Original PC architecture: use dedicated I/O space
    - Works same as memory accesses but set I/O signal
    - Only 1024 I/O addresses
    - Accessed with special instructions (IN, OUT)
    - Example: write a byte to line printer:

- Memory-Mapped I/O
  - Use normal physical memory addresses
    - Gets around limited size of I/O address space
    - No need for special instructions
    - System controller routes to appropriate device
  - Works like ``magic'' memory:
    - Addressed and accessed like memory, but ...
    - ... does not behave like memory!
    - Reads and writes can have "side effects"
    - Read results can change due to external events
- What if we want to use more than 2^16 bytes of memory?
  - 8086 has 20-bit physical addresses, can have 1 Meg RAM
  - the extra four bits usually come from a 16-bit "segment register":
  - CS code segment, for fetches via IP
  - SS stack segment, for load/store via SP and BP
  - DS data segment, for load/store via other registers
  - ES another data segment, destination for string operations
  - virtual to physical translation: pa = va + seq\*16
  - e.g. set CS = 4096 to execute starting at 65536
  - tricky: can't use the 16-bit address of a stack variable as a pointer
  - a far pointer includes full segment:offset (16 + 16 bits)

- tricky: pointer arithmetic and array indexing across segment boundaries
- But 8086's 16-bit addresses and data were still painfully small
  - 80386 added support for 32-bit data and addresses (1985)
  - o boots in 16-bit mode, boot. S switches to 32-bit mode
  - registers are 32 bits wide, called EAX rather than AX
  - operands and addresses that were 16-bit became 32-bit in 32-bit mode, e.g.
     ADD does 32-bit arithmetic
  - prefixes 0x66/0x67 toggle between 16-bit and 32-bit operands and addresses: in 32-bit mode, MOVW is expressed as 0x66 MOVW
  - the .code32 in boot.S tells assembler to generate 0x66 for e.g. MOVW
  - 80386 also changed segments and added paged memory...
- Example instruction encoding


```
b8 cd ab 16-bit CPU, AX <- 0xabcd

b8 34 12 cd ab 32-bit CPU, EAX <- 0xabcd1234

66 b8 cd ab 32-bit CPU, AX <- 0xabcd
```

## x86 Physical Memory Map

- The physical address space mostly looks like ordinary RAM
- Except some low-memory addresses actually refer to other things
- Writes to VGA memory appear on the screen
- Reset or power-on jumps to ROM at 0xfffffff0 (so must be ROM at top...)



#### **x86 Instruction Set**

- Intel syntax: op dst, src (Intel manuals!)
- AT&T (gcc/gas) syntax: op src, dst (labs, xv6)

- uses b, w, I suffix on instructions to specify size of operands
- Operands are registers, constant, memory via register, memory via constant
- Examples:

AT&T syntax

movl %eax, %edx

edx = eax;

register mode

movl \$0x123, %edx

edx = 0x123;

immediate

movl 0x123, %edx

edx = \*(int32\_t\*)0x123;

direct

movl (%ebx), %edx

edx = \*(int32\_t\*)ebx;

indirect

movl 4(%ebx), %edx

edx = \*(int32\_t\*)(ebx+4);

displaced

- Instruction classes
  - data movement: MOV, PUSH, POP, ...
  - o arithmetic: TEST, SHL, ADD, AND, ...
  - ∘ i/o: IN, OUT, ...
  - o control: JMP, JZ, JNZ, CALL, RET
  - string: REP MOVSB, ...
  - system: IRET, INT
- Intel architecture manual Volume 2 is the reference

## gcc x86 calling conventions

• x86 dictates that stack grows down:

#### **Example instruction** What it does

 pushl %eax
 subl \$4, %esp movl %eax, (%esp)


 popl %eax
 movl (%esp), %eax addl \$4, %esp

 call 0x12345
 pushl %eip (\*) movl \$0x12345, %eip (\*)

 ret
 popl %eip (\*)

- (\*) Not real instructions
- GCC dictates how the stack is used. Contract between caller and callee on x86:
  - at entry to a function (i.e. just after call):
    - %eip points at first instruction of function
    - %esp+4 points at first argument
    - %esp points at return address
  - after ret instruction:
    - %eip contains return address
    - %esp points at arguments pushed by caller
    - called function may have trashed arguments
    - %eax (and %edx, if return type is 64-bit) contains return value (or trash if function is void)
    - %eax, %edx (above), and %ecx may be trashed
    - %ebp, %ebx, %esi, %edi must contain contents from time of call
  - Terminology:

- %eax, %ecx, %edx are "caller save" registers
- %ebp, %ebx, %esi, %edi are "callee save" registers
- Functions can do anything that doesn't violate contract. By convention, GCC does more:
  - each function has a stack frame marked by %ebp, %esp



- %esp can move to make stack frame bigger, smaller
- o %ebp points at saved %ebp from previous function, chain to walk stack
- function prologue:

or

```
pushl %ebp
movl %esp, %ebp
enter $0, $0
```

enter usually not used: 4 bytes vs 3 for pushl+movl, not on hardware fast-path anymore

function epilogue can easily find return EIP on stack:

1eave

```
movl %ebp, %esp
popl %ebp
```

leave used often because it's 1 byte, vs 3 for movl+popl

• Big example:

or

C code

```
int main(void) { return f(8)+1; }
int f(int x) { return g(x); }
int g(int x) { return x+3; }
```

o assembler

```
mov1 %esp, %ebp
                        body
        push1 $8
        call _f
        addl $1, %eax
                        epilogue
        mov1 %ebp, %esp
        pop1 %ebp
        ret
_f:
                        prologue
        pushl %ebp
        mov1 %esp, %ebp
                        body
        push1 8(%esp)
        call _g
                        epilogue
        mov1 %ebp, %esp
        pop1 %ebp
        ret
_g:
                        prologue
        push1 %ebp
        mov1 %esp, %ebp
                       save %ebx
        pushl %ebx
                        body
        mov1 8(%ebp), %ebx
        add1 $3, %ebx
        mov1 %ebx, %eax
                        restore %ebx
        pop1 %ebx
                        epilogue
        mov1 %ebp, %esp
        pop1 %ebp
        ret
```

Super-small  $_{g}$ :

```
_g:
    mov1 4(%esp), %eax
    add1 $3, %eax
    ret
```

- Shortest f?
- Compiling, linking, loading:
  - Preprocessor takes C source code (ASCII text), expands #include etc, produces C source code
  - Compiler takes C source code (ASCII text), produces assembly language (also ASCII text)
  - Assembler takes assembly language (ASCII text), produces . file (binary, machine-readable!)
  - o Linker takes multiple '. o's, produces a single program image (binary)
  - Loader loads the program image into memory at run-time and starts it executing

### **PC** emulation

- The Bochs emulator works by
  - o doing exactly what a real PC would do,

- o only implemented in software rather than hardware!
- Runs as a normal process in a "host" operating system (e.g., Linux)
- Uses normal process storage to hold emulated hardware state: e.g.,
  - Stores emulated CPU registers in global variables

```
int32_t regs[8];
#define REG_EAX 1;
#define REG_EBX 2;
#define REG_ECX 3;
...
int32_t eip;
int16_t segregs[4];
```

Stores emulated physical memory in Boch's memory

```
char mem[256*1024*1024];
```

Execute instructions by simulating them in a loop:

```
for (;;) {
    read_instruction();
    switch (decode_instruction_opcode()) {
    case OPCODE_ADD:
        int src = decode_src_reg();
        int dst = decode_dst_reg();
        regs[dst] = regs[dst] + regs[src];
        break;
    case OPCODE_SUB:
        int src = decode_src_reg();
        int dst = decode_dst_reg();
        regs[dst] = regs[dst] - regs[src];
        break;
    ...
    }
    eip += instruction_length;
}
```

• Simulate PC's physical memory map by decoding emulated "physical" addresses just like a PC would:

```
#define KB
                         1024
#define MB
                         1024*1024
#define LOW MEMORY
                         640*KB
#define EXT MEMORY
uint8 t low mem[LOW MEMORY];
uint8 t ext mem[EXT MEMORY];
uint8_t bios_rom[64*KB];
uint8 t read byte(uint32 t phys addr) {
        if (phys addr < LOW MEMORY)
                 return low_mem[phys_addr];
        else if (phys addr \geq 960*KB && phys addr \langle 1*MB)
                 return rom_bios[phys_addr - 960*KB];
        else if (phys_addr \geq 1*MB && phys_addr \langle 1*MB+EXT_MEMORY) {
                 return ext mem[phys addr-1*MB];
        else ...
void write_byte(uint32_t phys_addr, uint8_t val) {
        if (phys_addr < LOW MEMORY)
                 low mem[phys addr] = val;
```

- Simulate I/O devices, etc., by detecting accesses to "special" memory and I/O space and emulating the correct behavior: e.g.,
  - Reads/writes to emulated hard disk transformed into reads/writes of a file on the host system
  - Writes to emulated VGA display hardware transformed into drawing into an X window
  - Reads from emulated PC keyboard transformed into reads from X input event queue