## **Checking Your Home for Lead, continued**

In preparing for renovation, repair, or painting work in a pre-1978 home, Lead-Safe Certified renovators (see page 12) may:

- Take paint chip samples to determine if lead-based paint is
  present in the area planned for renovation and send them to an
  EPA-recognized lead lab for analysis. In housing receiving federal
  assistance, the person collecting these samples must be a certified
  lead-based paint inspector or risk assessor
- Use EPA-recognized tests kits to determine if lead-based paint is absent (but not in housing receiving federal assistance)
- Presume that lead-based paint is present and use lead-safe work practices

There are state and federal programs in place to ensure that testing is done safely, reliably, and effectively. Contact your state or local agency for more information, visit epa.gov/lead, or call **1-800-424-LEAD** (5323) for a list of contacts in your area.<sup>3</sup>

8

<sup>&</sup>lt;sup>3</sup> Hearing- or speech-challenged individuals may access this number through TTY by calling the Federal Relay Service at 1-800-877-8399.