MM_ManualChange
Wire your Raspberry Pi like the chart below.
Run MM_ManualChange.py through the Pi Terminal.
Follow Terminal instructions.

| G11 | G13 | G12 | GND | | | Vc |

(Red Line)

ADC0832

Connect Vc to one of these
nodes to get an R reading

Rk = 10kΩ   R1 = 220Ω

R2 = 1kΩ

R3 = 10kΩ

R4 = 500Ω

R5 = 2kΩ

R6 = 11kΩ

(Blue Line)