

# PCap04

# **Capacitance-to-Digital Converter**

### **General Description**

PCap04 is a capacitance-to-digital converter (CDC) with integrated digital signal processor (DSP) for on-chip data post-processing. Its front end is based on ams PICOCAP principle.

This conversion principle offers outstanding flexibility with respect to power consumption, resolution and speed. Further, PCap04 covers a wide capacitance input range from a few femtofarads up to several hundreds of nanofarads. It is easy to configure the PCap04 for different capacitance measurement tasks, i.e. single as well as differential sensors in both, grounded or floating connection. The on-chip DSP allows to implement sensor algorithms like linearization and temperature compensation, with data output in a digital (SPI or IIC) or analog (PDM/PWM) way.

Ordering Information and Content Guide appear at end of datasheet.

#### **Key Benefits & Features**

The benefits and features of PCap04, Capacitance-to-Digital Converter are listed below:

Figure 1: **Added Value of Using PCap04** 

Benefits	Features
High flexibility: Easy adaption to various applications - ultra low power, high resolution or high speed - just by configuration	<ul> <li>Up to 6 capacitors grounded, 3 capacitors floating</li> <li>Capacitance range 1pF to 100nF</li> <li>Internal reference 1pF to 31pF</li> <li>Integrated guard driver</li> </ul>
High resolution or high speed	<ul> <li>Up to 8aF at 2.5Hz and 10pF base capacitance</li> <li>Up to 50kHz sample rate</li> <li>Up to 20-bit resolution</li> </ul>
On-chip DSP for sensor algorithms, signal post-processing including linearization and temperature compensation	<ul> <li>32-bit DSP</li> <li>3k ROM code, 1k NVRAM</li> <li>96 x 32 bit RAM</li> <li>SPI / IIC interface</li> <li>PDM / PWM outputs, GPIO</li> </ul>
On-chip and external temperature measurement capability	<ul> <li>Supply voltage 2.1/3.0V to 3.6V</li> <li>Operating current down to 3μA</li> <li>PCap04-Bxxx -40°C to 85°C</li> <li>PCap04-Axxx -40°C to 125°C</li> <li>QFN24 or die (1.588mm x 1.46mm)</li> </ul>



### **Applications MEMS Sensors**


The PCap04 applications include:

- · Position sensors
- Pressure sensors
- Force sensors
- Proximity sensor
- Acceleration sensors
- Inclination sensors
- · Humidity sensors
- Dewpoint sensors
- Tilt sensors
- Angle sensors
- Wireless applications
- · Level sensors

#### **Block Diagram**

The functional blocks of this device are shown below:

Figure 2: Functional Blocks of PCap04



Page 2

Document Feedback


[v1-03] 2018-Apr-04



### **Pin Assignments**

PCap04 will be available in QFN24 package or as pure die.


Figure 3: Pin Diagram of PCap04 Die



#### Note(s)

1. Die dimensions: 1.588 mm x 1.46 mm (w/ seal) with pad pitch 120 µm, pad opening is 85 µm x 85 µm. Thickness 290µm.

Figure 4: Pin Diagram of PCap04 QFN24



ams Datasheet Page 3
[v1-03] 2018-Apr-04 Document Feedback



# **Pin Description**

Figure 5: Pin Description of PCap04

Pin Number				
Die	24-Pin QFN	Pin Name	Description	If Not Used
1	24	PC2	CDC port	open
2	1	PC3	CDC port	open
3		GND_H		GND
4	2	GND		GND
5		VDD18_H		VDD18
6	3	VDD18 <sup>(1)</sup>	Core supply voltage	VDD18
7	4	VDD33 <sup>(2)</sup>	I/O supply voltage	VDD33
8	5	PT1	RDC port (temperature sensor)	open
9	6	PTOREF	RDC port (temperature sensor or external reference)	open
10	7	PTOUT (3)	Discharge capacitor for RDC	open
11		n.c.	No pad	
12		n.c.	No pad	
13	8	GND		
14/15		n.c.	No pad	
16		n.c.	Always open	
17	9	SSN_PG0	Serial select line. Otherwise, general purpose I/O port	open
18	10	MISO_PG1	Master in/Slave out when SPI is used. Otherwise, general purpose I/O port	open
19	11	PG5	General purpose I/O port	open
20	12	PG2	General purpose I/O port	open
21		GND		GND
22		GND_ifc		GND
23	13	IIC_EN	Serial interface select, 0 = SPI enable 1 = IIC enable	
24	14	VDD33		VDD33



Pin l	Number	Pin Name	Name Description		
Die	24-Pin QFN	PIII Naiile	Description	If Not Used	
25	15	MOSI_SDA	Master out/Slave in when SPI is used. Otherwise, serial data for IIC		
26		n.c.	Always open		
27		n.c.	Always open		
28	16	SCK_SCL	Serial clock for SPI/IIC		
29	17	PG3	General purpose I/O port	open	
30	17	PG4	General purpose I/O port	open	
31/32		n.c.	No pad		
33	19	PCAUX	Auxiliary port - For external compensation capacitance or - External discharge resistor - Guarding output	open	
34	20	PC4	CDC port	open	
35	21	PC5	CDC port	open	
36		n.c.	Always open	open	
37	22	PC0	CDC port	open	
38	23	PC1	CDC port	open	

#### Note(s):

- 1. Connect buffer capacitor ≥ 4.7μF
- 2. Connect buffer capacitor  $\geq 10 \mu F$
- 3. Connect 10nF C0G
- 4. Center pad is internally connected to GND. No wires other than GND are allowed underneath.
- 5. It is recommended to not use the center pad. Too much solder paste could reduce solder quality.
- 6. Suitable socket: e.g. Plastronics 32QN50S15050D.



### **Pad Coordinates**

Figure 6: Pad Coordinates of PCap04

Pad Number	Description	X-POS (μm)	Y-POS (μm)
1	PC2	260.0	59.5
2	PC3	380.0	59.5
3	GND_H	488.0	59.5
4	GND	608.0	59.5
5	VDD18_H	728.0	59.5
6	VDD18	848.0	59.5
7	VDD33	968.0	59.5
8	PT1	1088.0	59.5
9	PTOREF	1208.0	59.5
10	PTOUT	1328.0	59.5
11	n.c.	No pad	No pad
12	n.c.	No pad	No pad
13	GND	1528.5	501.0
14/15	n.c.	No pad	No pad
16	n.c.	No pad	No pad
17	SSN_PG0	1528.5	965.0
18	MICO_PG1	1528.5	1085.0
19	PG5	1528.5	1205.0
20	PG2	1333.0	1400.5
21	GND	1213.0	1400.5
22	GND_ifc	1093.0	1400.5
23	IIC_EN	973.0	1400.5
24	VDD33	853.0	1400.5
25	MOSI_SDA	733.0	1400.5
26	n.c.	No pad	No pad
27	n.c.	No pad	No pad
28	SCK_SCL	374.7	1400.5



Pad Number	Description	X-POS (μm)	Y-POS (µm)
29	PG3	254.7	1400.5
30	PG4	59.5	1205.0
31/32	n.c.	No pad	No pad
33	PCAUX	59.5	859.9
34	PC4	59.5	739.8
35	PC5	59.5	619.8
36	n.c.	No pad	No pad
37	PC0	59.5	379.8
38	PC1	59.5	259.8

#### Note(s):

<sup>1.</sup> Pad coordinates are center/center (x/y-direction), relative to die origin die dimensions:  $1.588 \, \text{mm} \times 1.46 \, \text{mm}$  (with seal,  $15 \, \mu \text{m}$  each side) with pad pitch  $120 \, \mu \text{m}$ , pad opening is  $85 \, \mu \text{m} \times 85 \, \mu \text{m}$ 



# **Absolute Maximum Ratings**

Stresses beyond those listed under Absolute Maximum Ratings may cause permanent damage to the device. These are stress ratings only. Functional operation of the device at these or any other conditions beyond those indicated under Electrical Characteristics is not implied. Exposure to absolute maximum rating conditions for extended periods may affect device reliability.

Figure 7:
Absolute Maximum Ratings

Symbol	Parameter	Min	Max	Units	Comments
	1	Electrical Pa	rameters		
V <sub>DD</sub> / V <sub>GND</sub>	Supply Voltage to Ground	- 0.3	4.0	V	
V <sub>IN</sub>	Input Pin Voltage to Ground	-0.3	4.0	V	
I <sub>SCR</sub>	Input Current (latch-up immunity) @125°C	±1	00	mA	JEDEC JESD78D Nov 2011
	Continuou	s Power Dis	sipation (T <sub>A</sub>	= 70°C)	
P <sub>T</sub>					
	E	lectrostatic	Discharge		
ESD <sub>HBM</sub>	Electrostatic Discharge HBM	± 1	000	V	JS-001-2014
	Temperature	e Ranges an	d Storage Co	onditions	
T <sub>A</sub>	Operating Ambient Temperature PCap04-Bxxx PCap04-Axxx	-40 - 40	85 125	°C °C	
R <sub>THJA</sub>	Junction to Ambient Thermal Resistance		28	°C/W	
Тյ	Operating Junction Temperature PCap04-Bxxx PCap04-Axxx	85 125		°C °C	
T <sub>STRG</sub>	Storage Temperature Range	-55	150	°C	

Page 8ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



Symbol	Parameter	Min	Max	Units	Comments
T <sub>BODY</sub>	Maximum Package Body Temperature during Reflow		260	°C	IPC/JEDEC J-STD-020 The reflow peak soldering temperature (body temperature) is specified according to IPC/JEDEC J-STD-020 "Moisture/Reflow Sensitivity Classification for Non-hermetic Solid State Surface Mount Devices." The lead finish for Pb-free leaded packages is "Matte Tin" (100% Sn)
RH <sub>NC</sub>	Relative Humidity (non-condensing)	5	85	%	
MSL	Moisture Sensitivity Level		3		Maximum floor life time of 168h
t <sub>STRG—DOF</sub>	Storage Time for DOF/die or wafers on foil		3	months	Refers to indicated date of packing
T <sub>STRG_DOF</sub>	Storage Temperature for DOF/die or wafers on foil	17	28	°C	
RH <sub>OPEN-DOF</sub>	Relative Humidity for DOF/die or wafers on foil in open package		15	%	Opened package
RH <sub>UNOPEN</sub> _	Relative Humidity for DOF/die or wafers on foil in sealed package	40	60	%	Sealed bag
t <sub>STRG</sub> WP	Storage Time for WP/wafers or die in waffle pack		6	months	17-28°C 40-60% relative humidity storage in original Ultrapack boxes
t <sub>STRG</sub> _WP	Storage Time for WP/wafers or die in waffle pack		2	years	19-25°C <15% relative humidity storage in closed cabinet with dry air
t <sub>STRG</sub> WP	Storage Time for WP/wafers or die in waffle pack		5	years	19-25°C <5% relative humidity storage in closed cabinet with dry air
<sup>t</sup> strg-wp	Storage Time for WP/wafers or die in waffle pack		10	years	19-25°C <5% relative humidity storage in closed cabinet and closed Ultrapak box with safeguarded Nitrogen atmosphere



# **Electrical Characteristics**

Characteristics indicate conditions for which the device is guaranteed to be functional. For details on the test conditions see the notes at the table footer.

Figure 8: Electrical Characteristics of PCap04

Symbol	Parameter	Conditions	Min	Тур	Max	Unit
V <sub>DD</sub>	Supply Voltage <sup>(4)</sup>	Relative to GND Power-down: VDD has to be <0.05V before power-up	2.1		3.6	V
V <sub>DD</sub>	Supply Voltage	NVRAM recall -Bx: -40°C to 85°C -Ax: -40°C to 125°C	2.5		3.6	V
V <sub>DD</sub>	Supply Voltage	NVRAM store -25°C to 60°C	3.0		3.6	V
V <sub>IO_DIGITAL</sub>	Digital Ports Input Voltage <sup>(4)</sup>	Relative to GND	- 0.6	3.3	V <sub>DD</sub> + 0.6 ≤ 3.6	V
V <sub>IO_DIGITAL</sub>	Digital Ports Input Switching Levels <sup>(2)</sup>	HIGH to LOW LOW to HIGH	0.7 * V <sub>DD</sub>		0.3 * V <sub>DD</sub>	V
V <sub>OH</sub>	Digital Ports Output Voltage (2)	HIGH	V <sub>DD</sub> - 0.4		V <sub>DD</sub> + 0.1	V
V <sub>OL</sub>	Digital Ports Output Voltage (2)	LOW	-0.1		0.4	V
I <sub>leakH</sub>	Digital Ports Leakage <sup>(2)</sup>	IIC_EN=V <sub>DD</sub> HIGH	-0.1		1.0	μΑ
I <sub>leakPU</sub>	Digital Ports Leakage <sup>(2)</sup>	Internal pull-ups	-2.8		-5.2	μΑ
I <sub>leakL</sub>	Digital Ports Leakage <sup>(2)</sup>	IIC_EN=V <sub>DD</sub> LOW	-1.0		0.1	μΑ
I <sub>ddq</sub>	Static Supply Current <sup>(2)</sup>	-40°C 35°C 85°C 125°C		1.28 1.6 4.26 22.5	- 5 18 50	μΑ
R <sub>P</sub>	Precharge Resistance <sup>(2)</sup>	R_C_PCHG0 R_C_PCHG1	7 126	10 180	13 234	kOhm
R <sub>D</sub>	Discharge Resistance <sup>(2)</sup>	R_DCHG0 R_DCHG1 R_DCHG2 R_DCHG3	7 21 63 126	10 30 90 180	13 39 117 234	kOhm

Page 10ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



Symbol	Parameter	Conditions	Min	Тур	Max	Unit
C <sub>ref0</sub> C <sub>ref1</sub> C <sub>ref2</sub> C <sub>ref3</sub> C <sub>ref4</sub>	Internal Reference (5)			0.4 1.4 3.4 7.4 15.4		pF
C <sub>R</sub>	Internal RDC Discharge Cap (2)	PTOUT n.c.	65	94	122	pF
I <sub>C_G7</sub>	Driver 7 Driver Low <sup>(3)</sup>	$PC0 = V_{DD}$ $PC0 = V_{DD} * 0.05$ $PCAUX = V_{DD}$		-3.5 -9		mA
V <sub>GUARD0</sub> V <sub>GUARD1</sub> V <sub>GUARD2</sub> V <sub>GUARD3</sub>	Gain Guarding Opamp <sup>(3)</sup>	PC0 = 1.0V		1.00 1.01 1.02 1.03		V
R <sub>R_DIS_SEN</sub>	RDC Temperature Sensor (2) (6)	-40 °C 35°C 85 °C 125 °C	- 1120 1200 1360	1047 1330 1572 1688	- 1680 1800 2040	Ohm
R <sub>R_DIS_REF</sub>	RDC Reference (2)		1100	1476	1690	Ohm
C <sub>R</sub>	RDC Internal Capacitance <sup>(2)</sup>		65	94	122	pF
f <sub>OLF0</sub> f <sub>OLF1</sub> f <sub>OLF2</sub> f <sub>OLF3</sub>	OLF Frequency <sup>(2)</sup>	High temperature minimum values, low temperature maximum values	3.6 25 47.6 92.8	10 60 100 200	16.5 96.4 171.4 305	kHz
f <sub>OHF</sub>	OHF Frequency <sup>(2)</sup>		1.36	2	2.6	MHz
	NVRAM Data Retention <sup>(4) (7)</sup> PCap04-Bxxx PCap04-Axxx	3.0V to 3.6V 85°C 125°C	20 20			Years
	NVRAM Endurance (4) (7) PCap04-Bxxx PCap04-Axxx	25°C 85°C 25°C 125°C	10 <sup>4</sup> 10 <sup>3</sup> 10 <sup>5</sup> 10 <sup>4</sup>			Cycles

#### Note(s):

- 1. 100% production tested
- $2.\ 100\%\ production\ tested\ at\ 85^\circ C\ (-Bxxx)/125^\circ C\ (-Axxx)\ wafer\ sort\ and\ guaranteed\ by\ design\ and\ characterization\ at\ specified\ temperatures.$

ams Datasheet Page 11
[v1-03] 2018-Apr-04 Document Feedback



- 3. Sample tested only
- 4. Parameter is guaranteed by design and characterization testing.
- 5. Parameter is a typical value only
- 6. 100% production tested at 25°C and guaranteed by design and characterization for industrial temperature range
- 7. **Important:** We guarantee the data for data retention and endurance only under the assumption, that the customer does not change the registers 62 and 63 and NVRAM adr 654 to 959 (Unique ID). In addition, it is mandatory to follow the given procedure for ERASE NVRAM as described in section NVRAM and ROM precisely. Otherwise, we do no longer guarantee the data retention time and endurance cycles.

Figure 9: Total Current I [ $\mu$ A] as a Function of Conversion Rate (CONV\_TIME) and Resolution (C\_AVRG) in Triggered Mode

					1[	ıA]				
LP Oscillator	CONV_	Measure		C_AVRG (RMS Resolution [Bits])						
Freq. [kHz]	TIME	Rate [Hz]	1	4	16	64	256	1024		
			(13.6)	(14.6)	(15.6)	(16.6)	(17.8)	(18.6)		
50	10000	2.5	2.3	2.5	2.7	4.6	11.8	44.0		
50	2500	10	2.8	3.3	4.6	12.2	43.8			
50	1250	20	3.3	4.2	7.9	23.9				
50	625	40	4.6	6.0	14.0					
50	250	100	8.3	12.0	32.2					
50	125	200	14.3	22.3						
50	50	500	32.6	53.8						
50	25	1000	63.9							
50	12	2080	90							
200	24	4160	156							
200	12	9320	305							

#### Note(s):

1. Temperature measurement in addition to capacitive measurement will add between  $2\mu A$  and  $10\mu A$  approximately, depending on speed. Total consumption values below  $30~\mu A$  may be obtained only when driving the on-chip 1.8 volts core supply generator in an energy-saving mode; ultimate microampere savings also demand to slow down the DSP. Typical data.

Page 12

Document Feedback

[v1-03] 2018-Apr-04



#### **CDC Characteristics**

Figure 10: **Electrical Characteristics** 

	Floating Fully Compensated			Grounded Internally Compensated		
Rate	RMS Noise	Eff. Res	solution	RMS Noise	Eff. Res	solution
[Hz]	[aF]	[Bi	ts]	[aF]	[Bi	ts]
		10pF Base	1pF Span		10pF Base	1pF Span
2.5	8	20.2	16.9	9	20.1	16.8
5	12	19.7	16.4	13	19.6	16.3
10	19	19.0	15.7	19	19.0	15.7
25	28	18.4	15.1	26	18.5	15.2
100	56	17.4	14.1	52	17.5	14.2
250	91	16.7	13.4	78	17.0	13.7
1000	156	16.0	12.7	148	16.0	12.7
2000	218	15.5	12.2	192	15.6	12.3
4000	328	14.9	11.6	272	15.1	11.8
8000				385	14.6	11.3

#### Note(s):

Both, sensor and reference are connected "floating" or "grounded", as indicated. In floating mode compensation mechanisms for both internal and external stray capacitances are activated, in grounded mode only the internal compensation is active.

Figure 11: **Voltage-Dependent Offset Error (PSRR)** 

Base /Gain	Mode	2.4V	2.7V	3.0V	3.3V	3.6V
10 pF	Single-ended, internal compensation	< 1fF	< 1fF	OfF	< 1fF	< 1fF
150 pF		< 1fF	< 1fF	OfF	< 1fF	< 1fF
10 pF	Floating, full compensation	< 1fF	< 1fF	OfF	< 1fF	< 1fF
150 pF		< 1fF	< 1fF	OfF	< 1fF	< 1fF

ams Datasheet Page 13 **Document Feedback** [v1-03] 2018-Apr-04

 $<sup>1.</sup> Typical \ capacitive \ noise \ and \ resolution \ vs. \ output \ data \ rate, 10 pF \ base + 1 pF \ span, fast \ settle, MR1, V = 3.0V. \ Span \ means \ the \ maximum$ variation of the sensor capacitance in the application. The table gives the root mean-square (RMS) noise in aF as a function of output data rate in Hz, measured at 3.0V supply voltage using the maximum possible sample size for in-chip averaging at the minimum possible cycle time. Bit values are calculated as a binary logarithm of noise over the span (BITs = In(span/noise)/In(2)). The measurements have been done with the PCap04 evaluation board, with fixed COG ceramic capacitors, configuration for maximum resolution.



Figure 12: Voltage-Dependent Gain Error (PSRR)

Base /Gain	Mode	2.4V	2.7V	3.0V	3.3V	3.6V
10pF / 4.7pF	Single-ended, internal	1.9fF	0.9fF	OfF	- 0.7fF	- 1.2fF
150pF / 47pF	compensation	- 22fF	- 10fF	OfF	0.7fF	20fF
10pF / 4.7pF	Floating, full	0.6fF	6fF	OfF	- 0.7fF	- 1.5fF
150pF / 47pF	compensation	- 11fF	- 11fF	OfF	8fF	19fF

Figure 13:
Temperature-Dependent Offset and Gain Error

Error Type	Capacitance [pF]	Mode	Temperature Range	Typ. Drift
	10	Single-ended, internal		2.5fF
Offset drift	150	compensation	-10°C to 85°C	9fF
Offset difft	10	Floating, full compensation		1.5fF
	150	Troating, ruil compensation		12fF
	10 + 4.7	Single-ended, internal		42fF = 94ppm/K
Gain drift	150 + 47	compensation		69fF = 15ppm/K
Gairtaint	10 + 4.7	Floating, full compensation		8fF = 18ppm/K
	150 + 47	Troating, ruii compensation		96fF = 22ppm/K

### **RDC Characteristics**

Figure 14:
Resolution RDC Unit

Measurement Conditions	R2/Rref Typ.	RMS Noise R2/Rref	Typical RMS Noise Temperature <sup>(1)</sup>
No averaging, 2 fake measurements	0.899	31.7ppm	12.2mK
16-fold averaging, 8 fake measurements	0.897	20.2ppm	7.8mK
Measurement conditions	10nF @ PTOUT, 25°C		

#### Note(s):

1. After linearization in post-processing software

Page 14ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



Typical linearity error with internal Al-thermometer after linearization and conversion into temperature, assuming a linear relation between temperature and resistivity:

- $-20^{\circ}\text{C} < \text{Temp.} < 0^{\circ}\text{C} \rightarrow 290\text{mK}$
- $0^{\circ}\text{C} < \text{Temp.} < 80^{\circ}\text{C} \rightarrow 110\text{mK}$

ams Datasheet Page 15
[v1-03] 2018-Apr-04 Document Feedback



# **Timing Characteristics**

Figure 15:

**PCap04 Timing Characteristics** 

Symbol	Parameter	Conditions	Min	Тур	Max	Unit
t <sub>START</sub>	Start-Up Time		3.9		4.0	ms
t <sub>C</sub>	CDC Discharge Time	Measure range 1	0		20	μs
t <sub>R</sub>	RDC Discharge Time	Measure range 1	0		20	μs
f <sub>SPI</sub>	SPI Bus Frequency	Clock frequency	0		20	MHz
f <sub>I2C</sub>	I <sup>2</sup> C Bus Frequency	Data rate	0	100		kHz

Page 16ams DatasheetDocument Feedback[v1-03] 2018-Apr-04




#### **Detailed Description**

PCap04 is an integrated solution for digitizing capacitive and resistive sensors, including a DSP for data processing like linearization and temperature correction. A 6-channel CDC allows to handle grounded and floating sensors in single and differential mode. The capacitance range applicable is from a few pF to hundreds of nanofarads. The RDC unit is mainly intended for measuring temperature, by means of an internal sensor and reference or by means of external resistors like PT1000.

A 32-bit digital signal processor (DSP) in Harvard architecture is integrated to the PCap04. It is responsible for taking the information from the CDC and RDC measuring units, for processing the data and making them available to the user interface. Both, the CDC/RDC raw data as well as the data processed by the DSP are stored in the RAM. The program for the DSP is stored in the NVRAM. The DSP can collect various status information from a set of 64 I/O Bits and write back 16 of those. This way, the DSP can react on and also control the GPIO pins of PCap04. The DSP is internally clocked at approximately 60MHz. The internal clock is stopped through a firmware command, to save power. The DSP starts again upon a GPIO signal or an "end of measurement" condition.

In its simplest form, the DSP transfers the pure time measurement information from the CDC/RDC to the read registers without any further processing. The next higher step is to calculate the capacitance ratios including the information from the compensation measurements, as it is provided in **ams** standard firmware version PCap04\_standard\_v01.hex. Finally, **ams** provides a ready-made linearize firmware that performs a linearization via polynomial of third degree and temperature compensation via polynomial of second degree. Many functional blocks for the linearization firmware are implemented as ROM code. This way, the main firmware can be very compact and can fit into the 1k NVRAM.

Figure 16: CDC, RDC and DSP Embedding



ams Datasheet Page 17
[v1-03] 2018-Apr-04 Document Feedback



The content of the read registers will always depend on the firmware in use. With the standard firmware it will be the pure capacitance and resistance ratios. With the linearization firmware it might the linearized and calibrated result, e.g. a pressure given in Pascal or humidity given in percent.

The DSP is **ams** proprietary to cover low-power tasks as well as very high data rates. It is programmed in assembler. A user-friendly assembler software with a graphical interface, help text pop-ups as well as sample code sustain programming efforts.

Page 18ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



# **Register Description**

### **Configuration Registers**

The PCap04 offers 48 registers for configuring the hardware (CDC, RDC, clocks, PDM/PWM, DSP). All these 48 registers are of one byte size. Additional four registers are used as special function registers. The 48<sup>th</sup> register contains nothing but one single bit, the RUNBIT, which enables/disables the front-end

All configurations are written simultaneously to registers and to the RAM Part of NVRAM and can be read back.

#### **Register Overview**

Figure 17: **Register Overview** 

Addr	Name	<d7></d7>	<d6></d6>	<d5></d5>	<d4></d4>	<d3></d3>	<d2></d2>	<d1></d1>	<d0></d0>
				Configurat	ion Registe	ers			
0	CFG0	120	:_A		OLF_I	FTUNE		OLF_0	CTUNE
1	CFG1	OX_DIS		OX_DIV4	OX_ AUTOST OP_DIS	OX_STOP		OX_RUN	
2	CFG2	RDCHG_	INT_SEL1	RDCHG_	INT_SEL0	RDCHG_ INT_EN		RDCHG_ EXT_EN	
3	CFG3		AUX_ PD_DIS	AUX _ CINT	RDCHG	S_OPEN	RDCHG _ PERM _ EN	RDCHG_ EXT_ PERM	RCHG _ SEL
4	CFG4	C_REF _ INT		C_ COMP_ EXT	C_ COMP_ INT			C_ DIFFERE NTIAL	C_ FLOATIN G
5	CFG5	CY_PRE_ MR1_ SHORT		C_PORT_ PAT		CY_ HFCLK_ SEL	CY_ DIV4_DIS	CY_PRE_ LONG	C_DC_ BALANCE
6	CFG6					C_PO	RT_EN		
7	CFG7			•	C_AVR	G<7:0>			
8	CFG8					(	_AVRG<12:8	>	
9	CFG9			1	CONV_T	IME<7:0>			
10	CFG10		CONV_TIME<15:8>						
11	CFG11		CONV_TIME<22:16>						
12	CFG12				DISCHARGE	_TIME<7:0>			

ams Datasheet Page 19 **Document Feedback** 



Addr	Name	<d7></d7>	<d6></d6>	<d5></d5>	<d4></d4>	<d3></d3>	<d2></d2>	<d1></d1>	<d0></d0>	
13	CFG13	C_STAR	TONPIN C_TRIG_SEL				GE_TIME :8>			
14	CFG14				PRECHARGE	E_TIME<7:0>				
15	CFG15				C_F	AKE			PRECHARGE_TIME <9:8>	
16	CFG16				FULLCHARGI	E_TIME <7:0>				
17	CFG17				C_REF_SEL			DISCHAR <9	GE_TIME :8>	
18	CFG18	C_G_OP_ RUN	C_G_OP_ EXT			C_G	_EN			
19	CFG19	C_G_(	DP_VU	C_G_0	P_ATTN		C_G	_TIME		
20	CFG20	R_CY						C_G_OP_TR		
21	CFG21				R_TRIG_PF	REDIV<7:0>				
22	CFG22			R_TRIG_SEL		R_A	VRG	R_TRIG_PR	EDIV <9:8>	
23	CFG23	R_POI	RT_EN	R_PORT_ EN_IMES	R_PORT_ EN_IREF				TONPIN	
24	CFG24			TDC_ TDC_ TDC_CHAN_EN ALUPER NOISE_ MOPEN DIS			TDC_MUF	PU_SPEED		
25	CFG25			TDC_MI	JPU_NO					
26	CFG26			TDC_Q	HA_SEL			TDC_ NOISE_ CY_DIS		
27	CFG27	DSP_MC	)FLO_EN			DSP_S	SPEED	PG1x PG3	PG0x PG2	
28	CFG28				WD	_DIS				
29	CFG29		DSP_STA	RTONPIN			DSP_	_FF_IN		
30	CFG30	PG5_ INTN_EN	PG4_ INTN_EN				DSP_S1	ΓART_EN		
31	CFG31	PI1_ TOGGLE_ EN	PIO_ TOGGLE_ EN	PIO_	RES	PIO_ PDM_SEL PIO_CLK_SEL				
32	CFG32		PI1_RES PI1_ PDM_SEL			PI1_CLK_SEL				
33	CFG33		PG_DIR_IN				PG	_PU		
34	CFG34	INT_ TRIG_BG	DSP_ TRIG_BG	BG_ PERM	AUTO START					

Page 20
Document Feedback



Addr	Name	<d7></d7>	<d6></d6>	<d5></d5>	<d4></d4>	<d3></d3>	<d2></d2>	<d1></d1>	<d0></d0>
35	CFG35		CDC_GAIN_CORR<7:0>						
36	CFG36					-			
37	CFG37					-			
38	CFG38				BG_	TIME			
39	CFG39		PULSE	SEL1			PULSE	_SEL0	
40	CFG40				C_SEN	SE_SEL			
41	CFG41		R_SENSE_SEL						
42	CFG42		ALARM1 _SEL ECT		ALARM0 _SEL ECT	EN_ ASYNC_ RD	HS_ MODE_ SEL	R_ MEDIAN_ EN	C_ MEDIAN_ EN
47	CFG47								RUNBIT
48	CFG48						MEM_	LOCK	
49	CFG49				SERIAL_NU	MBER<7:0>			
50	CFG50				SERIAL_NUI	MBER<15:8>			
54	CFG54				MEM	_CTRL			
62	CFG62	CHARGE_PUMP<7:0>							
63	CFG63				CHARGE_P	UMP<15:8>			



Addr	Name	<d7></d7>	<d6></d6>	<d5></d5>	<d4></d4>	<d3></d3>	<d2></d2>	<d1></d1>	<d0></d0>
	Read Registers								
0		7							0
1	RES0	15							8
2	NEOU	23							16
3		31							24
4		7							0
5	DEC1	15							8
6	RES1	23							16
7		31							24
8		7							0
9	RES2	15							8
10	KE32	23							16
11		31							24
12		7							0
13	RES3	15							8
14	KESS	23							16
15		31							24
16		7							0
17	DEC 4	15							8
18	RES4	23							16
19		31							24
20		7							0
21	DECE	15							8
22	RES5	23							16
23		31							24
24		7							0
25	DECC	15							8
26	RES6	23							16
27		31							24



Addr	Name	<d7></d7>	<d6></d6>	<d5></d5>	<d4></d4>	<d3></d3>	<d2></d2>	<d1></d1>	<d0></d0>
28		7							0
29	RES7	15							8
30	NE37	23							16
31		31							24
32	STATUS_0	POR_ FLAG_ WDG	POR_ FLAG_ CONFIG	IR_ FLAG_ COLL	AUTOBO OT		RDC_ READY	CDC_ ACTIVE	RUNBIT
33	STATUS_1					RDC_ERR	MUP_ ERR	ERR_ OVFL	COMB_ ERR
34	STATUS_2		C_ PORTERR _INT	C_ PORTERR 5	C_ PORTERR 4	C_ PORTERR 3	C_ PORTERR 2	C_ PORTERR 1	C_ PORTERR 0

#### Note(s):

- $1. \ Register \ 35 \ to \ 42 \ depend \ on \ the \ firmware. \ The \ values \ given \ are \ true \ for \ the \ standard \ firmware.$
- 2. The content of the results registers depend on the firmware.

ams Datasheet Page 23 Document Feedback



# **Detailed Configuration Register Description**

### Configuration Register 0 (Address 0x0)

Figure 18: Register 0

Bit	Bit Name	Settings	Bit Description
7:6	I2C_A	0 to 3	Complement to the I <sup>2</sup> C-address
5:2	OLF_FTUNE	0 : Minimum 7 : Typ., recommended 15 : Maximum	Fine-tune the low-frequency clock
1:0	OLF_CTUNE	0:10kHz 1:50kHz 2:100kHz 3:200kHz	Coarse-tune the low-frequency clock

# Configuration Register 1 (Address 0x1)

Figure 19: Register 1

Bit	Bit Name	Settings	Bit Description
7	OX_DIS	Default: 0	Disable the OX clock
5	OX_DIV4	0 : No division; f_ox = 2MHz 1 : Division by 4; f_ox = 0.5MHz	OX clock frequency : Raw freq./ 4
4	OX_AUTOSTOP_DIS	Default: 0	ams internal bits
3	OX_STOP	Default : 0	ams internal bits
2:0	OX_RUN	0 : Generator off 6 : OX latency = 1 / fOLF 3 : OX latency = 2 / fOLF 2 : OX latency = 31 / fOLF 1 : OX runs permanently	Control the permanency or the latency of the OX generator. Latency means an oscillator settling time before a measurement starts

Page 24ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



# Configuration Register 2 (Address 0x2)

Figure 20: Register 2

Bit	Bit Name	Settings	Bit Description
7:6	RDCHG_INT_SEL1	0 : 180kΩ	Same, but for ports PC4 – PC5
5:4	RDCHG_INT_SEL0	1 : 90kΩ 2 : 30kΩ (default) 3 : 10kΩ	Choice of one out of 4 on-chip discharge resistors for the CDC ports PC0 – PC3 plus internal port PC6
3	RDCHG_INT_EN	0 : Off 1 : Internal on (default)	Enable internal discharge resistors
1	RDCHG_EXT_EN	0 : Off (default) 1 : External on	Enable external discharge resistor switching on PCAUX during discharge phase (High-Z during pre- and full-charge phase) Note: AUX_PD_DIS (PCAUX pull down disable): 1

# Configuration Register 3 (Address 0x3)

Figure 21: Register 3

Bit	Bit Name	Settings	Bit Description
6	AUX_PD_DIS	0 : Pull-down active 1 : Pull-down disabled	Disable pull-down at PCAUX
5	AUX_CINT	0 : Normal (default) 1 : Aux during c-internal active	Activates auxiliary Port PCAUX during internal c-reference conversion only
4:3	RDCHG_OPEN	2 : Recommended	ams internal bits
2	RDCHG_PERM_EN	0 : Off (default) 1 : On	Keep the chip-internal discharge resistor permanently connected.
1	RDCHG_EXT_PERM	0 : Off (default) 1 : On	Activates auxiliary Port PCAUX permanently for a) permanently discharge or b) to add an offset capacitance to every charge/discharge cycle  Note: AUX_PD_DIS (PCAUX pull down disable): 1
0	RCHG_SEL	0 : 180kΩ 1 : 10kΩ (default)	Choice of one out of 2 on-chip charging resistors for the CDC, permitting to limit the charging current, avoiding transients

ams Datasheet Page 25 [v1-03] 2018-Apr-04 Document Feedback



# Configuration Register 4 (Address 0x4)

Figure 22: Register 4

Bit	Bit Name	Settings	Bit Description
7	C_REF_INT	0: External reference at PC0/GND or PC0/PC1) 1: Internal reference	Use on-chip reference capacitor at CDC special ports PC6
5	C_COMP_EXT	0 : Idle 1 : Active; must be avoided when C_FLOATING==0	Activate the compensation mechanism for off-chip parasitic capacitances
4	C_COMP_INT	0 : ldle 1 : Active	Activate the compensation mechanism for on-chip parasitic capacitances and gain compensation
1	C_DIFFERENTIAL	0 : Ordinary 1 : Differential	Select between single or differential sensors
0	C_FLOATING	0 : Grounded 1 : Floating	Select between grounded or floating sensors

# Configuration Register 5 (Address 0x5)

Figure 23: Register 5

Bit	Bit Name	Settings	Bit Description
7	CY_PRE_MR1_SHORT	0 : Normal (recommended) 1 : Reduced	Reduce delays between internal clock paths
5	C_PORT_PAT	0: Normal 1: Alternating order of ports	The order of the measured ports will be reversed after each sequence. If C_PORT_PAT is activated then C_AVRG + C_FAKE should be an even number
3	CY_HFCLK_SEL	0:OLF 1:OHF	Clock source for the CDC
2	CY_DIV4_DIS	0:Off 1:On	Quadruple the clock period (only in combination with CY_HFCLK_ SEL == 1)
1	CY_PRE_LONG	0 : Off, recommended 1 : On	Adds safety delay between internal clock paths
0	C_DC_BALANCE	0 : Off ("single HiZ) 1 : DC free ("both HiZ)	Only for differential floating mode (other modi are DC free), changes port control to eliminate DC at Capacity sense

#### Note(s):

 $1.\,CY\_HFCLK\_SEL\ and\ CY\_DIV4\_DIS\ are\ combined\ in\ the\ evaluation\ software\ as\ 'Cycle\ Clock\ Select'$ 

Page 26ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



# Configuration Register 6 (Address 0x6)

#### Figure 24: Register 6

Bit	Bit Name	Settings	Bit Description
5:0	C_PORT_EN	0x00 : All off, the CDC will not work 0x01 : Only port PC0 is activated etc. 0x3F : All ports activated	Enables bitwise the CDC ports from PC0 to PC5, bit #0 for port PC0, #1 for PC1 etc.

# Configuration Register 7:8 (Address 0x7, 0x8)

Figure 25: Register 7:8

Bit	Bit Name	Settings	Bit Description
12:0	C_AVRG	0, 1: Sample size = 1 2: Sample size = 2 3: Sample size = 3 8191: Maximum sample size	Sample size for averaging (calculating the mean value) over CDC measurements

### Configuration Register 11:9 (Address 0x9;0xA;0xB)

#### Figure 26: Register 11:9

Bit	Bit Name	Settings	Bit Description
22:0	CONV_TIME	Concerning CDC, a particular period for triggering the measurements $T_{conv./seq} = 2 * CONV_{LODE}$ TIME[] / folf	Conversion trigger period or: sequence period (in stretched mode)

ams Datasheet Page 27 Document Feedback



# Configuration Register 12 (Address 0xC)

#### Figure 27: Register 12

Bit	Bit Name	Settings	Bit Description
7:0 & Reg.13: 1:0	DISCHARGE_TIME	OLF: $T_{discharge} = (DISCHARGE\_TIME + 1) * T_{cycleclock}$ OHF: $T_{discharge} = (DISCHARGE\_TIME + 0) * T_{cycleclock}$ 1023 : Off	Sets CDC discharge time T <sub>discharge</sub> . Time interval reserved for discharge time measurement.

### Configuration Register 13 (Address 0xD)

#### Figure 28: Register 13

Bit	Bit Name	Settings	Bit Description
7:6	C_STARTONPIN	0 : PG0, 1 : PG1, 2 : PG2, 3 : PG3	Selection of the GPIO port that permits triggering a CDC start
4:2	C_TRIG_SEL	0 : Continuous 1 : Read triggered 2 : Timer triggered 3 : Timer triggered (stretched) 4 : n.d. 5 : Pin triggered 6 : Opcode triggered (7 : continuous_exp, not recommended)	CDC Trigger Mode
1:0 & Reg12: 7:0	DISCHARGE_TIME	See Register 12	See Register 12

### Configuration Register 14 (Address 0xE)

### Figure 29: Register 14

Bit	Bit Name	Settings	Bit Description
7:0 & Reg.15: 1:0	PRECHARGE_TIME	OLF:  T <sub>precharge</sub> = (PRECHARGE_TIME + 1) * T <sub>cycleclock</sub> OHF & FULLCHARGE_TIME = 1023:  T <sub>precharge</sub> = (PRECHARGE_TIME + 2) * T <sub>cycleclock</sub> OLF & FULLCHARGE_TIME!= 0x3FF:  T <sub>precharge</sub> = (PRECHARGE_TIME + 1) * T <sub>cycleclock</sub> 1023: Off	Sets CDC discharge time T <sub>precharge</sub> . Time interval reserved for discharge time measurement.

Page 28ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



# Configuration Register 15 (Address 0xF)

Figure 30: Register 15

Bit	Bit Name	Settings	Bit Description
5:2	C_FAKE	0 : None 1 : 1 fake  15: 15 fakes	Number of "fake" or "warm-up" measurements for the CDC, performed just before the "real" ones; the "fake" values do not count
1:0 & Reg14: 7:0	PRECHARGE_TIME	See Register 14	See Register 14

# Configuration Register 16 (Address 0x10)

#### Figure 31: Register 16

Bit	Bit Name	Settings	Bit Description
7:0 & Reg.17: 1:0	FULLCHARGE_TIME	OLF:  T <sub>fullcharge</sub> = (FULLCHARGE_TIME + 1) *T <sub>cycleclock</sub> OHF:  T <sub>fullcharge</sub> = (FULLCHARGE_TIME + 2) *T <sub>cycleclock</sub>	Sets CDC discharge time  t <sub>fullcharge</sub> .  Time interval reserved for discharge time measurement.

# Configuration Register 17 (Address 0x11)

#### Figure 32: Register 17

Bit	Bit Name	Settings	Bit Description
1:0 & Reg.16: 7:0	FULLCHARGE_TIME	See Register 16	See Register 16
6:2	C_REF_SEL	0: Minimum 1: Approx.1pF 31: Maximum (approx. 31pF)	Setting the on-chip reference capacitor for the CDC <b>Note:</b> Step width varies from 0.3pF to 1.5pF

ams Datasheet Page 29 Document Feedback



# Configuration Register 18 (Address 0x12)

Figure 33: Register 18

Bit	Bit Name	Settings	Bit Description
7	C_G_OP_RUN	Guard: OP Mode	0 : Permanent 1 : Pulsed (set OP to sleep mode between conversions)
6	C_G_OP_EXT	Guard: Activate external OP	0 : Internal OP 1 : External OP, PG3 as C_G_MUX_SEL
5:0	C_G_EN	Guard Enable, for each port	b'xxxxx1: Activates port PC0 b'xxxx1x: Activates port PC1 b'xxx1xx: Activates port PC2 b'xx1xxx: Activates port PC3 b'x1xxx: Activates port PC4 b'1xxxxx: Activates port PC5

Page 30  $ams\, Datasheet$ **Document Feedback** [v1-03] 2018-Apr-04



# Configuration Register 19 (Address 0x13)

Figure 34: Register 19

Bit	Bit Name	Settings	Bit Description
7:6	C_G_OP_VU	Guard: OP gain (from Sense Port to Guard)	0:x1.00 1:x1.01 2:x1.02 3:x1.03
5:4	C_G_OP_ATTN	Guard: OP attenuation	0:0.5aF 1:1.0aF 2:1.5aF 3:2.0aF
3:0	C_G_TIME	Guard: Time during Precharge to switch Guard Port from "direct connected" to OP	t : C_G_TIME * 500ns

# Configuration Register 20 (Address 0x14)

Figure 35: Register 20

Bit	Bit Name	Settings	В	it Descriptio	on
	R_CY	Cycle-time for the RDC Precharge/Charge/ Discharge, depending on OLF frequency	OLF f	R_CY=0	R_CY=1
			10kHz	100μs	200µs
7			50kHz	20μs	40µs
			100kHz	10µs	20μs
			200kHz	20μs	40μs
2:0	C_G_OP_TR	Guard OP current trim	0 :  7 : Recomme	nded	

ams Datasheet Page 31
[v1-03] 2018-Apr-04 Document Feedback



# Configuration Register 21 (Address 0x15)

Figure 36: Register 21

Bit	Bit Name	Settings	Bit Description
7:0 & Reg22: 1:0	R_TRIG_PREDIV	0, 1 : Every signal triggers 2 : Every 2 <sup>nd</sup> signal triggers 3 : Every 3 <sup>rd</sup> signal triggers 1023 : Maximum factor	Pre-divider, permits to make less temperature measurements than capacitance measurements. This is a factor between measurement rates of CDC over RDC. It is used also as OLF clock divider if OLF is used as trigger source.

# Configuration Register 22(Address 0x16)

Figure 37: Register 22

Bit	Bit Name	Settings	Bit Description
6:4	R_TRIG_SEL	0 : Off 1 : Timer triggered 3 : Pin triggered 5 : CDC asynchronous (recommended) 6 : CDC synchronous	Trigger source selection for the RDC 5 & 6: triggered by the end of CDC conversion
3:2	R_AVRG	0 : Not averaged 1 : 4-fold averaged 2 : 8-fold averaged 3 : 16-fold averaged	Sample size for the mean value calculation (averaging) in the RDC part
1:0 & Reg21: 7:0	R_TRIG_PREDIV	0, 1 : Every signal trigger 2 : Every 2 <sup>nd</sup> signal triggers 3 : Every 3 <sup>rd</sup> signal triggers 1023 : Maximum factor	Pre-divider, permits to make less temperature measurements than capacitance measurements. This is a factor between measurement rates of CDC over RDC. It is used also as OLF clock divider if OLF is used as trigger source.

Page 32ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



# Configuration Register 23 (Address 0x17)

#### Figure 38: Register 23

Bit	Bit Name	Settings	Bit Description
7:6	R_PORT_EN	'bx0 : Disabled 'bx1 : Activates port PTOREF 'b0x : Disabled 'b1x : Activates port PT1	Port activation for the RDC part
5	R_PORT_EN_IMES	0 : Disabled 1 : Enabled	Port activation for internal aluminum temperature sensor
4	R_PORT_EN_IREF	0 : Disabled 1 : Enabled	Port activation for internal reference resistor
3	-	-	-
2	R_FAKE	0: 2 fake cycles per average value 1: 8 fake cycle per average value	Number of "fake" or "warm-up" measurements for the RDC, performed just before the "real" ones; the "fake" values do not count
1:0	R_STARTONPIN	0:PG0 1:PG1, 2:PG2 3:PG3	Selection of the GPIO port that permits triggering a RDC start

# Configuration Register 24 (Address 0x18)

#### Figure 39: Register 24

Bit	Bit Name	Settings	Bit Description
7:6	-	-	-
5:4	TDC_CHAN_EN	Mandatory : 3	ams internal bits
3	TDC_ALUPERMOPEN	Mandatory : 0	ams internal bits
2	TDC_NOISE_DIS	Mandatory: 0	ams internal bits
1:0	TDC_MUPU_SPEED	Mandatory : 3	ams internal bits

ams Datasheet Page 33 Document Feedback



# Configuration Register 25 (Address 0x19)

Figure 40: Register 25

Bit	Bit Name	Settings	Bit Description
7:2	TDC_MUPU_NO	Mandatory : 1	ams internal bits
1:0	-	-	-

# Configuration Register 26 (Address 0x1A)

Figure 41: Register 26

Bit	Bit Name	Settings	Bit Description
7:2	TDC_QHA_SEL	Mandatory : 20	ams internal bits
1	TDC_NOISE_CY_DIS	Mandatory : 1	ams internal bits
0	-	-	-

### Configuration Register 27 (Address 0x1B)

Figure 42: Register 27

Bit	Bit Name	Settings	Bit Description
7:6	DSP_MOFLO_EN	0:Off 3:On	Enable the mono-flop (anti-bouncing filter)" in the GPIO pulse line.
5:4	-	-	-
3:2	DSP_SPEED	0 : Fastest 1 : Fast 2 : Slow, recommended 3 : Slowest	DSP speed
1	PG1xPG3	0 : Pulse output at PG3 1 : Pulse output at PG1	Switch PG1/PG3 wiring to/from DSP
0	PG0xPG2	0 : Pulse output at PG2 1 : Pulse output at PG0	Switch PG0/PG2 wiring to/from DSP

Page 34 ams Datasheet **Document Feedback** [v1-03] 2018-Apr-04



# Configuration Register 28 (Address 0x1C)

#### Figure 43: Register 28

Bit	Bit Name	Settings	Bit Description
7:0	WD_DIS	0x5A: Watchdog disabled (off) 0x00 (recommended) / else: Watchdog enabled	Watchdog Disable, to disable Watchdog 0x5A has to be written to this register. The watchdog period is between 9s and 15s

# Configuration Register 29 (Address 0x1D)

#### Figure 44: Register 29

Bit	Bit Name	Settings	Bit Description
7:4	DSP_STARTONPIN	Bitwise PG0 to PG3	Pin mask for starting the DSP - This mask permits assigning one or more GPIO pins to start the DSP
3:0	DSP_FF_IN	Bitwise DSP_IN_0 to DSP_IN_3	Pin mask for flip-flop activation

# Configuration Register 30 (Address 0x1E)

#### Figure 45: Register 30

Bit	Bit Name	Settings	Bit Description
7	PG5_INTN_EN	0 : PG5 normal operation 1 : PG5 <== INTN	Route INTN Signal to PG5
6	PG4_INTN_EN	0 : PG4 normal operation 1 : PG4 <== INTN	Route INTN Signal to PG4
5:3	-	-	-
2:0	DSP_START_EN	'bxxx1 : Trigger by end of CDC 'bxx1x : Trigger by end of RDC (recommended) 'bx1xx : Trigger by timer	DSP Trigger Enable

ams Datasheet Page 35 Document Feedback



# Configuration Register 31 (Address 0x1F)

Figure 46: Register x

Bit	Bit Name	Settings	Bit Description
7	PI1_TOGGLE_EN	0 : Normal operation 1 : Toggle flip flop active	Activates toggle flip flop at Pulse Interface 1 Output especially for PDM to create 1:1 duty factor
6	PI0_TOGGLE_EN	0 : Normal operation 1 : Toggle flip flop active	Activates toggle flip flop at Pulse Interface 0 Output especially for PDM to create 1:1 duty factor
5:4	PIO_RES	0:10 bit 1:12 bit 2:14 bit 3:16 bit	Resolution of the pulse-code interfaces
3	PIO_PDM_SEL	0:PWM 1:PDM	Pulse Interface 0 PWM / PDM switch
2:0	PIO_CLK_SEL	0:Off 1:OLF/1 2:OLF/2 3:OLF/4 4:OX/1 5:OX/2 6:OX/4 7:n.d.	Pulse Interface 0 Clock Select

Page 36ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



# Configuration Register 32 (Address 0x20)

Figure 47: Register 32

Bit	Bit Name	Settings	Bit Description
7:6	-	-	-
5:4	PI1_RES	0:Off 1:OLF/1 2:OLF/2 3:OLF/4 4:OX/1 5:OX/2 6:OX/4 7:n.d.	Pulse Interface 1 Clock Select
3	PI1_PDM_SEL	0:PWM 1:PDM	Resolution of the pulse-code interfaces
2:0	PI1_CLK_SEL	0:10 bit 1:12 bit 2:14 bit 3:16 bit	Pulse Interface 1 PWM / PDM switch

# Configuration Register 33 (Address 0x21)

## Figure 48: Register 33

Bit	Bit Name	Settings	Bit Description
7:4	PG_DIR_IN	0:Output 1:Input	Toggles general-purpose port direction between input and output #4: PG0 #5: PG1 #6: PG2 #7: PG3
3:0	PG_PU	0 : Pull-up disabled 1 : Pull-up active	Activates protective pull-up resistors at general-purpose ports #0: PG0 #1: PG1 #2: PG2 #3: PG3

ams Datasheet Page 37 Document Feedback



# Configuration Register 34 (Address 0x22)

Figure 49: Register 34

Bit	Bit Name	Settings	Bit Description
7	INT_TRIG_BG	0 : Disabled 1 : Enabled	End of Reading triggers Bandgap
6	DSP_TRIG_BG	0 : Disabled 1 : Enabled	Bandgap refresh is triggered by the DSP bit setting
5	BG_PERM	1 : Bandgap permanent enabled 0 : Bandgap pulsed	Activate Bandgap permanently. With BG_PERM = 1 the current consumption rises by approx. 20µA
4	AUTOSTART	0 : Disabled 1 : CDC trigger after Power On	For standalone operation, triggers CDC after Power On
3:0	-	Mandatory : 7	ams internal bit

# Configuration Register 35 (Address 0x23)

Figure 50: Register 35

Bit	Bit Name	Settings	Bit Description
7:0	CDC_GAIN_CORR[7:0]	Recommended 1.25 ==> 0x40	Firmware defined configuration of the gain correction factor.  Bits 0 to 7 of 8fpp  0:0  n:1 + n/256

# Configuration Register 36 (Address 0x24)

Figure 51: Register 36

Bit	Bit Name	Settings	Bit Description
7:0	-		Not used

Page 38 ams Datasheet [v1-03] 2018-Apr-04



# Configuration Register 37 (Address 0x25)

Figure 52: Register 37

Bit	Bit Name	Settings	Bit Description
7:0	-		Not used

# Configuration Register 38 (Address 0x26)

Figure 53: Register 38

Bit	Bit Name	Settings	Bit Description
7:0	BG_TIME	0: Recommended	Firmware defined

# Configuration Register 39 (Address 0x27)

Figure 54: Register 39

Bit	Bit Name	Settings	Bit Description
7:4	PULSE_SEL1	0 to 5: Res0 to Res5 (C05 /Cref @PCap04_standard) 6: Res6 (PT1/Ref @PCap04_ standard) 7: Res7 (Alu/Ref @PCap04_ standard)	Firmware defined, select source for Pulse IF 1
3:0	PULSE_SEL0	0 to 5 : Res0 to Res5 (C05 /Cref @PCap04_standard) 6 : Res6 (PT1/Ref @PCap04_ standard) 7 : Res7 (Alu/Ref @PCap04_ standard)	Firmware defined, select source for Pulse IF 0

# Configuration Register 40 (Address 0x28)

Figure 55: Register 40

Bit	Bit Name	Settings	Bit Description
7:0	C_SENSE_SEL	PCap04_linearize firmware only, select C ratio for linearization 05 : C0 to 5 / Cref	Firmware defined

ams Datasheet Page 39
[v1-03] 2018-Apr-04 Document Feedback



# Configuration Register 41 (Address 0x29)

Figure 56: Register 41

Bit	Bit Name	Settings	Bit Description
7:0	R_SENSE_SEL	PCap04_linearize firmware only, select R ratio for temperature determination	Firmware defined

# Configuration Register 42 (Address 0x30)

Figure 57: Register 42

Bit	Bit Name	Settings	Bit Description
7	-		
6	ALARM1_SELECT	PCap04_linearize firmware only	Firmware defined. Select source of alarm signals at PG0 and PG1
5	-	Polarity Select 0 : Z; 1 : Theta	Active High
4	ALARM0_SELECT	ĺ	
3	EN_ASYNC_READ	1 : Active	Values in result registers Res0 to Res7 are only updated if the previous value has been read
2	HS_ MODE_SEL	0 : Mandatory	ams internal bit
1	R_ MEDIAN_EN	PCap04_linearize firmware only	Enable median filters for ci/ri in linearize
0	C_ MEDIAN_EN		firmware

# Configuration Register 47 (Address 0x2F)

Figure 58: Register 47

Bit	Bit Name	Settings	Bit Description
7:1	Not used		
0	RUNBIT	0 : Off = the chip system is idle and protected 1 : On = the protection is removed, and the system may run	On/off switch for front-end and DSP: It should be "off" during programming and any registry modification, thus protecting the chip from any undesirable/unspecified states

Page 40ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



# Configuration Register 48 (Address 0x30)

## Figure 59: Register 48

Bit	Bit Name	Settings	Bit Description
7:4	Not used		
3:0	MEM_LOCK	'bxxx1: NVRAM range `d0 to 703 'bxx1x: NVRAM range `d704 to 831 'bx1xx: NVRAM range `d832 to 959 'b1xxx: NVRAM range `d960 to 1007 and NVRAM range `d1022 to 1023	Data secure function to safe parts of NVRAM from reading and writing via SIF

# Configuration Register 49 (Address 0x31)

## Figure 60: Register 49

Bit	Bit Name Settings		Bit Description
7:0	SERIAL_NUMBER[7:0]	Free disposal for customer. Could only be written as far as the byte is zero. Afterwards it could just be cleared by an complete Erase	Lower byte reserved for serial number

# Configuration Register 50 (Address 0x32)

## Figure 61: Register 50

Bit	Bit Name Settings		Bit Description	
7:0	SERIAL_NUMBER[15:8]	Free disposal for customer. Could only be written as far as the byte is zero. Afterwards it could just be cleared by an complete Erase	Higher byte reserved for serial number	

ams Datasheet Page 41 Document Feedback



# Configuration Register 51 to 53: ams internal Registers, 0x00 mandatory

## Configuration Register 54 (Address 0x36)

Figure 62: Register 54

Bit	Bit Name	Settings	Bit Description
7:0	MEM_CTRL	0x2d: NVRAM store enable 0x59: NVRAM recall enable 0xb8: NVRAM erase Register is reset automatically after following SIF activity	Memory control

Configuration Register 55 to 61: ams internal Registers, 0x00 mandatory

Configuration Register 62 (Address 0x3e)

Figure 63: Register 62

Bit	Bit Name	Settings	Bit Description
7:0	CHARGE_PUMP[7:0]	Individual, device-specific setting. Not allowed to be changed	Lower byte of NVRAM charge pump trim

## Configuration Register 63 (Address 0x3f)

Figure 64: Register 63

Bit	Bit Name	Bit Name Settings	
7:0	CHARGE_PUMP[15:8]	Individual, device-specific setting. Not allowed to be changed	Higher byte of NVRAM charge pump trim

Important Note: We guarantee the data for data retention and endurance only under the assumption, that the customer does **not** change the registers 62 and 63. In addition, it is mandatory to follow the given procedure for ERASE NVRAM as described in section NVRAM and ROM precisely. Otherwise, **we do no longer guarantee** the data retention time and endurance cycles.

Page 42ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



# **Read Registers**

PCap04 has 35 byte of RAM for read access, combined as quadruples of 4 byte.

Figure 65: Read Registers

Addr	Name	<d7></d7>	<d6></d6>	<d5></d5>	<d4></d4>	<d3></d3>	<d2></d2>	<d1></d1>	<d0></d0>
0		7							0
1	RES0	15							8
2	NESO	23							16
3		31							24
4		7							0
5	RES1	15							8
6	ILST	23							16
7		31							24
8		7							0
9	RES2	15							8
10	NL32	23							16
11		31							24
12		7							0
13	RES3	15							8
14	NESS	23							16
15		31							24
16		7							0
17	RES4	15							8
18	NE34	23							16
19		31							24
20	DECE	7							0
21		15							8
22	RES5	23							16
23		31							24



Addr	Name	<d7></d7>	<d6></d6>	<d5></d5>	<d4></d4>	<d3></d3>	<d2></d2>	<d1></d1>	<d0></d0>
24		7							0
25	RES6	15							8
26	NESO	23							16
27		31							24
28		7							0
29	RES7	15							8
30	NL37	23							16
31		31							24
32	STATUS_0	POR_ FLAG_ WDG	POR_ FLAG_ CONFIG	IR_ FLAG_ COLL	AUTOBO OT		RDC_ READY	CDC_ ACTIVE	RUNBIT
33	STATUS_1					RDC_ ERR	MUP_ ERR	ERR_ OVFL	COMB_ ERR
34	STATUS_2		C_ PORTER R_INT	C_ PORTER R5	C_ PORTER R4	C_ PORTER R3	C_ PORTER R2	C_ PORTER R1	C_ PORTER R0

The read registers are made of 7 result registers. Addresses 32 to 34 contain the status register.

Page 44ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



# **Result Registers**

The content of the results registers depend on the firmware. The following describes the result registers as they are used by the standard firmware.

Figure 66: **Result Registers** 

Name	Length	Format	Bit Description							
Name	Lengui		Grounded C	Differential C						
Res0			Ratio C0 / Cref	Ratio C1 / C0						
Res1		E.g. C0 = Unsigned fixed-point number: 5 bits integer 27 bits fractional Min = 0x0 = = 0.0000000 Max = 0xFFFFFFFF = = 31.9999995	Ratio C1 / Cref	C3 / C2						
Res2			C2 / Cref	C5 / C4						
Res3	32 bits		_	_	_	_	_	27 hits fractional	C3 / Cref	
Res4	32 DILS		C4 / Cref	Zero						
Res5			C5 / Cref	Zero						
Res6				PT1/PTref	PT1/PTref					
Res7			PTinternal/PTref	PTinternal/PTref						

The user is free to assign any data to the results registers in his own firmware.

# **Status Registers**

Figure 67: STATUS\_0 (Address 32)

Bit	Bit Name	Bit Description
7	POR_Flag_Wdog	A watchdog overflow has been detected and has provoked a power-on reset. Perhaps the firmware has hung up in an unwanted endless loop or, more likely, a CDC/RDC trigger signal has been lost.
6	POR_Flag_Config	One or more configuration bits toggled by interferences and has provoked a power-on-reset.
5	POR_CDC_DSP_COLL	If a CDC sequence is triggered while DSP is still active an Initial Reset is provoked.
4	AutoBoot busy	
3		
2	RDC ready	
1	CDC active	Warning: Traffic on interface may enhance noise in measurement
0	RUNBIT	The RUNBIT from write register 47 is mirrored here

ams Datasheet Page 45 [v1-03] 2018-Apr-04 Document Feedback



Figure 68: STATUS\_1 (Address 33)

Bit	Bit Name	Bit Description
7:4	n.c.	Test bits
3	RDC_Err	Some kind of error occurred when the RDC unit was busy
2	Mup_Err	A particular kind of TDC error occurred when the CDC unit was busy
1	Err_Ovfl	An overflow error occurred when the CDC unit was busy
0	Comb_Err	All error bits, from here onward, disjunctively combined (using bit-or)

Figure 69: STATUS\_2 (Address 34)

Bit	Bit Name	Port	Bit Description			
6	C_PortError Internal Reference	PC internal ref				
5	C_PortError5	PC5				
4	C_PortError4	PC4	In the CDC unit, one or several ports are affected by some error like a short-circuit to ground. May also be a charge/ discharge			
3	C_PortError3	PC3	resistivity too big, a capacitance too big, or an ill-defined  precharge/fullcharge/discharge time.			
2	C_PortError2	PC2	precharge/funcharge/discharge time.			
1	C_PortError1	PC1				
0	C_PortError0	PC0				

Page 46ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



# **Principles of Operation**

#### **Converter Frontend**

The device uses "discharge time measurement" as a principle for measuring either capacitances (CDC unit) or resistances (RDC unit). It addresses all ports (PC...,PT...) in time multiplex, the time measurement being done by means of a high-resolution TDC (time-to-digital converter).

### Capacitance-to-Digital Converter (CDC)

#### **Measuring Principle**


In PCap04, capacitance measurement is done by measuring discharge times of RC-networks. The measurements are ratiometric. This means that the capacitors are compared to a fixed reference or, like in differential sensors, to capacitors with change in opposite direction. Thanks to the short time intervals and special compensation methods, the ratio of discharge times is directly proportional to the ratio of capacitors. The discharge time is defined by the capacitor and the selected discharge resistor.

(EQ1) 
$$\frac{\tau_N}{\tau_{ref}} = \frac{C_N}{C_{ref}}$$
  $\tau = k \times R \times C$ 

#### **Connecting Sensors**

PCap04 can handle single and differential sensors in grounded or floating connection. PCap04 has integrated reference capacitors. They are programmable in a range from 1pF to 31pF in steps of 1pF.

Figure 70: Connecting Sensors




ams Datasheet Page 47
[v1-03] 2018-Apr-04 Document Feedback



#### **Discharge Resistors**

The PCap04 has two sets of discharge resistors already integrated. One resistor set (10k/30k/90k/180k ohm) is for measurements on port PC0 to PC3 and the internal reference port PC6. The other resistor set (10k/30k/90k/180k ohm) is for ports PC4 and PC5. This way, it is possible to measure different sensors with strongly deviated capacitance like pressure and humidity with one and the same chip. Parameters RCHG\_xxx select the resistors.

Figure 71: Integrated Discharge Resistors



The user can define which resistor he uses for the internal compensation measurement. It is selected by **DSP\_RDCHG\_ COMP\_INT\_SEL** (0 = RCHG0 (default), 1 = RCHG1).

There is the possibility to use an external discharge resistor for handling big capacitances.

Page 48ams DatasheetDocument Feedback[v1-03] 2018-Apr-04




#### Cycle

In PCap04 the measurement principle is based on a three-step cycle.

- In the pre-charge phase the capacitor is charged up via a series resistor to a level close to Vdd. The resistor reduces the charge current and reduces the mechanical stress on the sensing capacitor. This can be necessary in some MEMS applications. Further, this is a measure to detect a short circuit and to limit the current even in such an error case.
- In full-charge phase, the capacitor is charged up finally to Vdd without any series resistor.
- Then, in the third step, the capacitor is discharged via the discharge resistor down to 0V. The CDC measures the time interval until a trigger level is reached. All this is called a single "cycle".

Figure 72: Single Cycle Timing




In applications that do not need the slow charge up but high conversion rate, it is possible to disable the pre-charge option and to start charge up directly without any series resistor.

ams Datasheet Page 49
[v1-03] 2018-Apr-04 Document Feedback




Figure 73: Single Cycle, Fast Charge



In both cases the capacitors are discharged for the full discharge time period and then connected to GND.

In case of a short circuit, the voltage never reaches the trigger level of the comparator. In such a case the measurement cycle is stopped, no low-resistive full-charge follows. This way the current in a short-circuit case is limited.

Figure 74:
Short Circuit Detection



Page 50ams DatasheetDocument Feedback[v1-03] 2018-Apr-04




#### Sequence

A "sequence" is made of a set of cycles, namely those for the various active ports as well as combinations of them as given by the compensation measurements. The number and kind of single cycles depend on the way of how the sensors are connected, the number of capacitors and the selected compensation options.

For **grounded** sensors, the sequence starts always with PC0 (reference) and then one or more of the other 5 ports. Normally, internal compensation is activated. So the sequence ends with the measurement Cint of the internal stray capacitance/delays. For compensating internal parasitic capacitance and the comparator delay the CDC measures the discharge time with all ports being off (Cint).

The following figure shows the sequence for a grounded sensor with internal compensation.

Figure 75: Sequence Grounded



**Sequence** for 1 reference and 1 sensor in grounded connection, compensated for internal capacitance


For **floating** sensors, the sequence starts always with PCO/PC1 (reference), followed by one to three pairs of ports for the sensors. Normally, both compensations (internal and external) are activated.

For compensation of external parasitic capacitances the CDC makes a measurement for each capacitor with both ports being opened. So, for each capacitor 3 measurements are made, e.g. PC0, PC1 and PC0+PC1. The sequence ends with the internal compensation measurement Cint. The following figures show the sequence for 1 floating sensor with full compensation.

ams Datasheet Page 51
[v1-03] 2018-Apr-04 Document Feedback



Figure 76: Sequence Floating




**Sequence** for 1 reference and 1 sensor in floating connection, fully compensated for parasitic capacitances

#### Conversion

Finally, the combination of various sequences and delays in between the sequences define a single "conversion". Once triggered, a conversion is automatically completed, including all fake measurements and all real measurements defined by sample size for averaging. At the end of a conversion the measurement results are ready for further processing and readout. The end of the conversion is indicated by flag to the DSP and also the RDC unit.

Figure 77:
Cycle-Sequence-Conversion



Page 52ams DatasheetDocument Feedback[v1-03] 2018-Apr-04




Various sources are available to trigger the CDC.

- Continuous mode: In this mode the CDC starts automatically after POR. The end of the DSP processing triggers directly the next measurement. This mode allows the fastest sample rate, but with the risc that communication will continue while the next measurement is started. Noise will increase.
- Read triggered mode: In this mode the very first measurement is triggered via SIF. When the measurement is completed the interrupt goes LOW. An external microcontroller can react on this and read the data. The end of the read via SIF triggers the next measurement. This mode allows fastest measurement without having the interface disturb the measurement.
- Timer triggered mode: In this mode the PCAP04 timer triggers the measurements. This is preferred in applications with low sample rate.
- Opcode or pin triggered mode: In this mode the external microcontroller has full control on when measurements are triggered. This might be valuable when the measurement needs to be synchronized with other tasks.

ams Datasheet Page 53 **Document Feedback** 



Figure 78: Conversion Modes



Page 54ams DatasheetDocument Feedback[v1-03] 2018-Apr-04




#### **CDC Compensation Options**

#### **Internal Compensation**

For the internal compensation measurement, both switches A1 and A0 are open. Only the internal parasitic capacitance and the comparator propagation delay will thus be measured.

It is recommended to have internal compensation active in any application.


Figure 79: Internal Compensation Measurement



#### **External Compensation**

With floating capacitors we have the additional option to compensate external parasitic capacitances against ground. On the PCB, the wire capacitance typically refers to ground. For long wires, it is recommended to use shields which should be grounded at their PCB side.

Figure 80: Shielded Cables




**How to connect** shielded cables for compensation of the external parasitic capacitances.

ams DatasheetPage 55[v1-03] 2018-Apr-04Document Feedback



Three measurements are necessary for each capacitor in case of floating sensors. This is shown in the Figure 81. First, the electrode at PC0 is loaded to VDD18. The discharge time is defined by the sensor capacitance, the parasitic capacitance of the connection, including the chip pad, and the internal capacitance. Second, the same measurement is done for the electrode at PC1. Third, both electrodes are set at VDD18. Therefore the field across the sensor is zero and has no impact. The discharge time includes only the connection and pad capacitance as well as the internal capacitance. Now it is possible to correct mathematically for the parasitic capacitance. This correction is covered by the **ams** firmware.

Figure 81: External Compensation



Floating capacitors, external compensation measurements, the three measurements that are made for each floating capacitor.

#### DC Balance

When driving floating sensors the sensors' supply is typically DC free.

With differential floating sensors symmetry would be broken. Therefore, PCap04 has the possibility to change the port controlling that the sensors are operated DC free (set by **C\_DC\_BALANCE**).

In applications with grounded sensors the sensors cannot be DC fee by principle.

Page 56

Document Feedback

[v1-03] 2018-Apr-04



#### **Gain Correction**

Comparable to classical A/D converters, the PCap04 shows a gain error. But in case of PCap04 the gain error is mainly given by internal parasitic capacitances and the propagation delay of the internal comparator. With internal compensation being active this delay is subtracted from the original measurement. The temperature drift can be approximated linearly and corrected mathematically just by a gain factor. In the standard firmware the gain correction factor could be set in register 35 with fpp 8. The correction factor depends on the discharge time and therefore the RC combination. It has to be evaluated individually for every single application. E.g., with 22pF and 30kOhm the correction factor is 1.25 (0x40).

CDC\_GAIN\_CORR = (gain\_corr-1)\*256

#### **Empirical method to find the right gain correction factor:**

Replace the sensor with a temperature stable capacitor of the same size (ceramic COG) as your reference capacitor. (Therefore: quotient = 1, gain = 0). Set the gain correction factor to 1.0. Put the system (PCapO4 on PCB) into a temperature chamber and measure the offset drift over temperature. Add an additional temperature stable capacitor to simulate your gain. Measure the gain drift. Increase the gain correction factor and measure the gain drift again. With a gain correction factor >1.0 the gain drift will decrease. If the gain correction factor is set too big then you will see a negative gain drift due to over compensation. The right gain correction factor is found, if the drift is reduced to what you measured at the initial offset drift measurement. Write back the new CDC\_GAIN\_CORR value into register 35.

#### **CDC Important Parameters**

#### Cycle Clock

The basic period t<sub>cycle</sub> that defines the cycle time can be derived from the low frequency oscillator or the high frequency oscillator. Parameters **CY\_HFCLK\_SEL** selects in between the two, parameter **CY\_DIV4\_DIS** select between the original 2MHz or a 0.5MHz generated by a divider by 4.

Figure 82: Configuration of Cycle Clock

CY_HFCLK_SEL	CY_DIV4_DIS	Cycle Time Base
0	0	$t_{cycle} = t_{OLF}$ ; $t_{OLF} = period low-frequency oscillator$
1	0	$t_{cycle} = 4*t_{OHF}$ ; $t_{OHF} = period high-frequency oscillator.$
1	1	$t_{cycle} = t_{OHF}$ ; $t_{OHF} = period high-frequency oscillator.$

ams Datasheet Page 57
[v1-03] 2018-Apr-04 Document Feedback



# Cycle Time

The pre-charge, full-charge and discharge times of a single cycle are defined in multiples of t<sub>cycle</sub>. Those are selected by:

Figure 83: Cycle Time Configuration

Reg.	Configuration Parameter	Description
14,15	PRECHARGE_TIME	Time to charge via resistor for current limitation. Depends on the cycle clock and, with OHF, on the FULLCHARGE_TIME. $1023 = \text{No pre-charge phase}$ $\text{OLF: 0 to } 1022: T_{precharge} = (\textbf{PRECHARGE\_TIME} + 1) * t_{cycle}$ $\text{OHF \& FULLCHARGE\_TIME} = 1023:$ $0 \text{ to } 1022: T_{precharge} = (\textbf{PRECHARGE\_TIME} + 2) * t_{cycle}$ $\text{OHF \& FULLCHARGE\_TIME}! = 1023:$ $0 \text{ to } 1022: T_{precharge} = (\textbf{PRECHARGE\_TIME} + 1) * t_{cycle}$
16,17	FULLCHARGE_TIME	Time for final charge without current limitation. Depends on the cycle clock. $1023 = \text{No full-charge phase} \\ \text{OLF: 0 to } 1022: T_{fullcharge} = (\textbf{FULLCHARGE\_TIME} + 1) * t_{cycle} \\ \text{OHF: 0 to } 1022: T_{fullcharge} = (\textbf{FULLCHARGE\_TIME} + 2) * t_{cycle}$
12,13	DISCHARGE_TIME	Time to discharge the capacitor. Depends on the cycle clock. OLF: 0 to 1023: $T_{discharge} = (\textbf{DISCHARGE\_TIME} + 1) * t_{cycle}$ OHF: 0 to 1023: $T_{discharge} = (\textbf{DISCHARGE\_TIME} + 0) * t_{cycle}$

Page 58ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



# Sequence

The length of a sequence depends on the kind and number of sensors, the selected compensation methods and the averaging sample size. The following parameters affect the sequence:

Figure 84: Sequence Configuration

Reg.	Configuration Parameter	Description
6	C_PORT_EN	Bitwise enable of the capacitance ports PC0 to PC5 0: Port disabled 1: Port active
4	C_REF_INT	Switches between external and internal reference capacitors. Cannot be used with differential sensors.  0: External, PC0 or PC0 & PC1  1: Internal, PC6
4	C_DIFFERENTIAL	Switches between single and differential sensors 0: Single 1: Differential
4	C_FLOATING	Switches between grounded and floating sensors 0: Grounded 1: Floating
4	C_COMP_INT	Turns on compensation of internal capacitances/delays 0: Off 1: On, recommended
4	C_COMP_EXT	Turns on compensation of external parasitic capacitances. Available only with floating sensors.  0: Off 1: On, recommended
5	C_DC_BALANCE	Changes Port Control for Differential Floating Mode 0 : Off (single HighZ) 1 : DC-Free (both HighZ)

ams Datasheet Page 59
[v1-03] 2018-Apr-04 Document Feedback



#### Conversion

The duration of a full conversion has a lower limit given by the number of fake measurements, the averaging and eventually an inter-sequence delay:

Figure 85: Conversion Configuration

Reg.	Configuration Parameter	Description
15	C_FAKE	Number of fake measurements (cycles with results being ignored) 0: No dummy cycles 1: 1 dummy cycle 15: 15 dummy cycles
7, 8	C_AVRG	Sample size for averaging within one conversion.  0:= No averaging  8191: Maximum sample size

The Start of the next conversion depends on the selection of the measurement trigger:

Figure 86: Conversion Configuration

Reg.	Configuration Parameter	Description						
13	C_TRIG_SEL	First trigger selection for CDC trigger 0: Continuous 1: Read triggered 2: Timer triggered 3: Timer triggered (stretched) 4: n.d. 5: Pin triggered 6: Opcode triggered (7: continuous_exp, not recommended)						
13	C_STARTONPIN	Selects the GPIO that triggers the CDC measurement						
9, 10, 11	CONV_TIME	Sets the conversion time in multiples of twice the period of the low-frequency clock. $t_{conv} = 2 * \textbf{CONV\_TIME} * t_{ofl}$						

Page 60ams DatasheetDocument Feedback[v1-03] 2018-Apr-04




#### Guarding

Depending on the sensor topology it may be necessary to add an active shield to suppress disturbing capacitances. The guard electrode is an additional metal area behind the sensing electrode, which is kept at the same potential as the sensing electrode. So all material in between the sensing electrode and the guard electrode are potential-free and therefore have no capacitive effect. It eliminates material-depending temperature drifts of the sensor PCB. Further, things behind the shield are separated from the senor by the potential-free zone.

In PCap04 the driver for the guard is integrated. This amplifier needs to have a low-capacitive input to not disturb the measurement path. Gain is ideally one. The gain can be set > 1 (overcompensation) by means of C\_G\_OP\_VU so that in combination with an external voltage divider it is possible to match the port and wire resistance. The guard is connected to pin PCAUX (other functions of this pin are then not available). In-active ports are also switched to guard so that there is no additional capacitance seen between guard and inactive ports.

Figure 87:
Guarding with Floating Capacitors



ams Datasheet Page 61
[v1-03] 2018-Apr-04 Document Feedback



Figure 88:
Guarding with Grounded Capacitors





Figure 89: Port Voltages with Guarding



With guarding, also ports are set to VDD18, even the ones that are not measured. This ensures that electric fields between those ports and the active port are zero. Internally, those ports are not connected to the time measuring path but to the guard driver. If the guard electrode is so big that it cannot be driven by the internal amplifier it is possible to add an external one. An external analog multiplexer will be needed, too. The external amplifier is connected to PCAUX. The SEL port of the multiplexer is connected to PG3.

Page 62ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



Figure 90: Guarding with External Amplifier




Figure 91: Important Parameters are Set in Register 18:

Reg.	Configuration Parameter	Description
18	C_G_EN[5:0]	Individual guard enable for each port PC0 to PC5
18	C_G_OP_RUN	0 : Permanent: Guarding OP is permanent activated (additional power consumption) 1 : Pulsed: Guarding OP set to sleep mode between CDC conversions
19	C_G_OP_ATTN	Capacitive attenuation of guarding OP: 0:0.5pF 1:1.0pF 2:1.5pF 3:2.0pF
19	C_G_OP_VU	OP Gain (from sense port to guard) 0:1.00 1:1.01 2:1.02 3:1.03
20	C_G_OP_TR	Trim power consumption and driving strength of guarding OP 0: Min 7: Max.
18	C_G_OP_EXT	Switch between internal guarding OP and an optional external OP 0: Internal OP 1: External OP, PG3 as <b>C_G_MUX_SEL</b>
19	C_G_TIME	$t_{pp1} = t_{OHF} \cdot C_G TIME$

ams Datasheet Page 63
[v1-03] 2018-Apr-04 Document Feedback



- **C\_G\_EN**[5:0] guarding is activated individually for each port PC0 to PC5. One or more ports can be enabled. The guard output (PCAUX) drives voltage the enabled ports are enabled.
- **C\_G\_TIME** controls the pre-charge phase. Because internal circuits the pre-charge phase is divided into two phases:
  - Pre-charge phase 1: PCAUX is directly connected with active PC.
  - Pre-charge phase 2: PCAUX is driven by OP, V\_ PCAUX=gain\_guardOP·V\_PCactive.PCAUX is driven by OP until finishing current port cycle.

**Attention:** For guarding, the internal OX/OHF is mandatory:

- OX RUN > 0, OX DIS = 0; OX STOP = 0; OX DIV4 = 0;
- CY HFCLK SEL = 1;

#### RDC Resistance-to-Digital Converter

#### **Measuring Principle**

In PCap04 resistance measurement is also done by measuring discharge times. The measurements are ratiometric. This means, the temperature-sensitive resistances are compared with a fixed reference. The ratio of discharge times is directly proportional to the ratio of resistors. The discharge time is defined by the resistors and the load capacitance.

(EQ2) 
$$\frac{\tau_N}{\tau_{ref}} = \frac{R_{\theta}}{R_{ref}}$$
  $\tau = k \times R \times C$ 

#### **Connecting Sensors**

The chip device has two on-chip resistor elements for the measurement of temperature, an aluminum strip with TK  $\approx 2800 ppm/K$  as a sensor and a poly-silicon resistor with TK "close to zero" as a reference. In the range 0°C to 100°C the aluminum sensor can be well approximated by a linear function of temperature.

As an alternative, it is possible to connect up to two external sensors. One of those can be used as external reference alternately. External and internal thermometers/reference may be mixed, e.g. an external PT1000 may be compared to the internal Poly-Si resistor.

The chip has an internal capacitor of about 94pF. In combination with the internal resistors the discharge time is about 500ns and the typical resolution of the resistance ratio is better than 13 bits. For precision measurements we recommend to connect an external capacitor of about 10nF. With 10nF the discharge time is in the order of 20  $\mu$ s and the resolution in the order of 15 bits.

Discharge time must not exceed 20 $\mu$ s. For the capacitor, C0G ceramics yields best performance, while X7R material yields fair results.


Page 64

Document Feedback

[v1-03] 2018-Apr-04



Figure 92: Connecting Temperature Sensors



#### Note(s):


1. The RDC measurement is based on an AC principle. Long cables with their parasitic capacitance and resistance will disturb and it is recommended to have short cables (≤ 0.5m), ideally twisted and shielded.

#### Cycle & Conversion

In PCap04 the resistance measurement is running in three phases, like in capacitance measurement:

Pre-charge – Full-charge – Discharge. The timing is based on the internal low-frequency oscillator (OLF). The duration of full and discharge phases can be 1 or 2 periods of this reference. The conversion starts with 2 or 8 fake measurements to improve the stability of data. For each single conversion the averaging can be selected with sample size 1, 4, 8 or 16.

Figure 93: RDC Conversion



**RDC Conversion:** R\_AVRG = 1, Reference and sensor, 2 fake measurements

ams Datasheet Page 65
[v1-03] 2018-Apr-04 Document Feedback



#### Trigger

Various sources can trigger the RDC. The trigger rate can be set to a divider of the CDC trigger rate by means of parameter R\_TRIG\_PREDIV (1 to 1023).

Parameter R\_TRIG\_SEL defines the various possibilities to trigger a resistance measurement:

- Serial Interface command, PIN or DSP (Figure 64)
- Timer triggered, based on the OLF (Figure 64)
- CDC end of conversion
  - Asynchronous: The DSP is triggered by the RDC end of conversion. If RDC rate is less than CDC rate the DSP is triggered directly from the CDC for inactive RDC conversions (Figure 95).
  - Synchronous: The DSP is triggered by the RDC end of conversion. Assuming that RDC rate is less than the CDC rate, the inactive RDC conversions are replaced by a delay (Figure 96).

Figure 94: RDC Timing, Triggered by Timer, SIF or Pin





Figure 95:
RDC Timing, Triggered by DSP in Asynchronous Mode



R\_TRIG\_PREDIV = 3, R\_TRIG\_SEL = 3'b101, DSP\_START\_EN: CDC\_TRIG\_EN = 0, RDC\_TRIG\_EN = 1


Page 66

Document Feedback

[v1-03] 2018-Apr-04



Figure 96: **RDC Timing, Triggered by DSP in Synchronous Mode** 



**R\_TRIG\_PREDIV** = 3, R\_TRIG\_SEL = 3'b110, DSP\_START\_EN: CDC\_TRIG\_EN = 1, RDC\_TRIG\_EN = 0

## **RDC Important Parameters**

## Cycle Clock

The base frequency for the temperature measurement is the low frequency oscillator (OLF). A further bit, **R\_CY**, specifies whether 1 or 2 periods define the length of the three phases.

Figure 97: **Cycle Clock Configuration** 

OLF Frequency	t <sub>precharge</sub> = t <sub>fullcharge</sub> = t <sub>discharge</sub>							
<u> </u>	R_CY = 0	R_CY = 1						
10 kHz	100μs	200μs						
50 kHz	20μs	40µs						
100 kHz	10μs	20μs						
200 kHz	20μs	40µs						

ams Datasheet Page 67 **Document Feedback** 



#### Sequence

The major settings for the sequence are the number of ports, the fakes, the reference and averaging.

Figure 98: Sequence Configuration

Reg.	Configuration Parameter	Description				
23	R_PORT_EN	Enable ports PTOREF, PT1				
23	R_PORT_EN_IREF	Enable the internal reference resistor				
23	R_PORT_EN_IMES	Enable the internal temperature sensor				
22	R_AVRG	Set averaging for T measurement				
23	R_FAKE	Set number of fake measurements				

#### Conversion

Figure 99: RDC Trigger Configuration

Reg.	Configuration Parameter	Description							
22	R_TRIG_SEL	Selection of trigger source for RDC unit							
21, 22	R_TRIG_PREDIV	Pre-divider to set the RDC rate as fraction of the CDC rate but also to the <b>OLF_CLK</b> when <b>OLF_CLK</b> is selected as RDC Trigger 0 = 1 : RDC conversion with each CDC conversion 2 : RDC conversion every second CDC conversion  1023 : Maximum setting							
23	R_STARTONPIN	Select Pin for pin triggered							

#### **RDC** Results, Ratios

PCap04\_standard and PCap04\_linearize firmware are determining ratios between sense ports and reference ports.

If the internal reference port is activated (**R\_PROT\_EN\_IREF**: 1) for all other ports (internal sense, PT0 and PT1) the internal reference is automatically selected for ratios.

If **R\_PORT\_EN\_IREF**: 0, external port PT0/Ref is selected as reference value for all other ports (internal sense, PT1)

Page 68ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



## Interfaces (Serial & PDM/PWM)

#### Serial Interfaces (SIF)

Two types of serial interfaces are available for communication with a microcontroller and for programming the device: SPI and IIC. Only one interface is available at a time, selected by pin IIC\_EN. On both interfaces, the PCap04 can operate as slave only.

Figure 100: Serial Interface Selection

Pin	Description
IIC_EN = GROUND	4-wire SPI interface General-purpose I/O pins PG0 and PG1 are not available
IIC_EN = VDD	2-wire I <sup>2</sup> C interface All general-purpose I/O pins are available

IIC\_EN may not be floating. Connect IIC\_EN to VDD if there is no need for a controller interface.

The serial interfaces allow read access to the read registers (results and status), read/write access to the configuration registers and read/write access to the NVRAM (explicitly the SRAM part of the NVRAM).

All commands for write or read to memory or configuration / read registers may use explicit addressing or address auto-increment.

ams Datasheet Page 69
[v1-03] 2018-Apr-04 Document Feedback



## Opcodes

## Figure 101: Opcodes

Description	Byte 2							Byte 1					Byte 0				
wr_mem (NVRAM)	1	0	1	0	0	0		add<90> <sup>(2)</sup>							data<70>		
rd_mem (NVRAM)	0	0	1	0	0	0		add<90> <sup>(2)</sup>							data<70>		
Write configuration	1	0	1	0	0	0	1	1	1	1		ac	dd<5	0>	(2)		data<70>
Read configuration	0	0	1	0	0	0	1	1	1	1 1 add<50> <sup>(2)</sup>				data<70>			
Read result (RAM)	0	1		ado	d<5	.0>(2	) (3)	data<70>									
POR (Power-on Reset)	1	0	0	0	1	0	0	0									
Initialize	1	0	0	0	1	0	1	0									
CDC Start conversion	1	0	0	0	1	1	0	0									
RDC Start conversion	1	0	0	0	1	1	1	0									
dsp_trig	1	0	0	0	1	1	0	1									
nv_store (1)	1	0	0	1	0	1	1	0									
nv_recall (1)	1	0	0	1	1	0	0	1									
nv_erase (1)	1	0	0	1	1	1	0	0									
Test read	0	1	1	1	1	1	1	0	0	0	0	1	0	0	0	1	

#### Note(s):

- 1. Set MEM\_CTRL before using nv\_store, nv\_recall or nv\_erase
- 2. Auto-incremental write/read is supported by both, SPI and  $I^2C$
- 3. Address range for Read result is 0 to 24 (8 x 32bit result registers and 3 x 8 bit status registers)

Page 70 ams Datasheet [v1-03] 2018-Apr-04



The serial interface is tested most easily by performing a test read:

Write opcode 0x7e to SIF and read 1 byte. Compare this byte to following patterns:

- 0x11 : Expected value, read cycle performed correctly
- 0x88 : Failure: there is a big/little-endian swap
- 0xEE: Failure: during read cycle all bits are inverted
- 0x77 : Failure: inverted bits and bit/little-endian swap

#### **Synchronous Read**

For best results it is recommended to read all values from the result registers synchronized by the INTN signal. The INTN signal can be routed to PG4 or PG5 by **PG4\_INTN\_EN** and **PG5\_INTN\_EN** at Register 30. The INTN signal is low active, which means the negative edge of INTN signals new values are available at Res0 to Res7. The INTN is set back to High by a positive edge at SSN (SPI) or a stop condition (I<sup>2</sup>C).

#### **Asynchronous Read**

If it is not possible to read synchronously as described above for any reason, asynchronous read (**EN\_ASYNC\_RD**) has to be enabled in register 42. In this mode values in result registers Res0 to Res7 are only updated if the previous value has been read (INTN is reset to High by a positive edge of SSN or a stop condition).

#### I<sup>2</sup>C Compatible Interface

The present paragraph outlines the PCap04 device specific use of the I<sup>2</sup>C interface. The external I<sup>2</sup>C master begins the communication by creating a start condition, a falling edge on the SDA line while SCL is HIGH. It stops the communication by a stop condition, a rising edge on the SDA line while SCK is high. Data bits are transferred with the rising edge of SCK.

On I<sup>2</sup>C buses, every slave holds an individual 7-bit device address with 5 fixed and 2 configurable bits. This address has always to be sent as the first byte after the start condition, the eighth bit indicating the direction of the following data transfer (R=read=1 and W=write=0).

Figure 102: Address Byte

MSB							LSB
0	1	0	1	0	A1	A0	R/W
		Fixed	Vari	able	key		


ams Datasheet Page 71
[v1-03] 2018-Apr-04 Document Feedback



## I<sup>2</sup>C Timing

The address byte is followed by the opcode and eventually the payload. Each byte is followed by an acknowledge bit (= 0, when a slave acknowledges).

Figure 103: I<sup>2</sup>C Typical Sequence




#### I<sup>2</sup>C Write

During write transactions, the master alone sends data, the addressed slave just sends the acknowledge bits. The master first sends the slave address plus the write bit. Then it sends the PCap04 specific opcode including the register address in the slave. Finally it sends the payload ("Data").

Incremental writing is possible, means, for a consecutive set of data only the start address has to be sent and a various number of data could be sent in one row.

Figure 104: I<sup>2</sup>C Write Procedure



**Example:** Write 0xFF as a datum to the SRAM at address 0x147.


Page 72ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



#### I<sup>2</sup>C Read

During read transactions, the direction of communication has to be commuted. Therefore, the master creates again a start condition (resp. restart: start without stop condition in between) and sends the slave address plus the read bit to switch into read mode. Figure 105 shows an example with op code "read from SRAM".

Figure 105: I<sup>2</sup>C Read Procedure



**Example:** Read from SRAM address 0x147, we find 0xFF having been programmed before.

After arrival of the first (or any) data byte, the master may either signal

- Not-Acknowledge = N = 1 to indicate "end read", "stop sending" to the slave, or
- Acknowledge = A = 0 to indicate "continue in automatic address-increment mode" and thus receive many bytes in a row. As one can see, automatic address increment is particularly useful and efficient with the I<sup>2</sup>C interface.

#### **SPI Interface**

Clock Polarity, Clock Phase and Bit Order: The following choices are necessary for successful operation.

Figure 106: SPI Settings

SPI - Parameter	Description Setting			
CPOL	Clock polarity	0		
СРНА	Clock phase	1		
Mode	SPI Mode	1		
DORD	Bit sequence order	0, MSB first		

ams Datasheet Page 73
[v1-03] 2018-Apr-04 Document Feedback



# SPI Timing

Figure 107: SPI Write





Figure 108: SPI Read





Page 75

# Figure 109: SPI Timing

Name	Symbol	VDD=2.2V	VDD=3.0V	VDD=3.6V	Units
Serial clock frequency	f <sub>SPI-bus</sub>	10	17	20	MHz
Serial clock pulse width HI state	t <sub>pwh</sub>	50	30	25	ns
Serial clock pulse width LO state	t <sub>pwl</sub>	50	30	25	ns
SSN enable-to-valid latch	t <sub>sussn</sub>	10	8	7	ns
SSN pulse width between write cycles	t <sub>pwssn</sub>	50	30	25	ns
Data setup time prior to clock edge	t <sub>sud</sub>	7	6	5	ns
Data hold time after clock edge	t <sub>hd</sub>	5	4	3	ns
Data valid after clock edge	t <sub>vd</sub>	40	26	16	ns



#### **GPIO** and PDM/PWM

This section is about the general purpose ports and their use as Pulse-Density / Pulse Width Modulated outputs (PDM/PWM). PCap04 is very flexible with assignment of the various GPIO pins to the DSP inputs/outputs. The following table shows the 6 general purpose ports and their possible assignment.

Figure 110: General Purpose Port Assignment

External Port Name	Description	Direction In or Out
	SSN (in SPI-Mode), serial select	In
DC0	DSPØ or DSP2, I/O for the DSP	In <sup>(1)</sup> / Out
PG0	FF0 or FF2, I/O for the DSP with Flip-Flop	In <sup>(1)</sup>
	Pulse0, PDM or PWM output	Out
	MISO (in SPI-Mode)	Out
PG1	DSP1 or DSP3, I/O for the DSP	In <sup>(1)</sup> / Out
FGI	FF1 or FF3, I/O for the DSP with Flip-Flop	In <sup>(1)</sup>
	Pulse1, PDM or PWM output	Out
	DSPØ or DSP2, I/O for the DSP	In <sup>(1)</sup> / Out
PG2	FF0 or FF2, I/O for the DSP with Flip-Flop	In <sup>(1)</sup>
	Pulse0, PDM or PWM output	Out
	DSP1 or DSP3, I/O for the DSP	In <sup>(1)</sup> / Out
PG3	FF1 or FF3, I/O for the DSP with Flip-Flop	In <sup>(1)</sup>
1 03	Pulse1, PDM or PWM output	Out
	C_G_MUX_SEL output	Out
PG4	DSP4 (output only)	Out
1 07	INTN	Out
PG5	DSP5 (output only)	Out
1 03	INTN	Out


#### Note(s):

1. These ports provide an optional debouncing filter and an optional pull-up resistor.

Page 76ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



Figure 111: GPIO Assignment




ams Datasheet Page 77
[v1-03] 2018-Apr-04 Document Feedback



#### **Debouncing Filter**

There is a possibility to activate a 40ms debounce filter ("monoflop") for the ports in case these are used as push button inputs. This might be useful especially in case the DSP is started by the pins (signals FF0, FF2). Figure 112 shows the effect of the monoflop filter.

Figure 112: Port Trigger Timing



#### PDM and PWM

There is a possibility to generate two pulse density modulated output signals. In general, PDM is preferred because of better noise behavior. The output is based on the content of RAM registers PI0\_REF, PI1\_REF (DSP write addresses 109, 110. Width 16 bit each). The content of those RAM cells depends on the firmware. The description in this datasheet is based on the standard firmware, which writes the capacitance ration to PI0\_REF, the Resistance ratio to PI1\_REF.

The pulse interfaces can be switched on individually. The resolution can be programmed from 10 to 16 bit. There is a broad range of clock signals that can be selected as base for the pulse interfaces, derived from the 50kHz low-frequency oscillator or the 2MHz internal oscillator. The output pins may be PG0 or PG2 and PG1 or PG3.

The PDM signal can be converted into an analog voltage by means of a simple RC-filter. A first-order filter made of  $220k\Omega$  / 100nF is sufficient. By the choice or the resistor and capacitor values the user can optimize for reaction time vs. ripple.

Filter configuration instructions:

The resistor should be  $\geq$  50kOhm. The internal DC resistance of the output buffer is typ.  $100\Omega$ 

Page 78

Document Feedback

[v1-03] 2018-Apr-04



- 1. Settling time (for PDM and PWM) If the output value changes, the settling time to reach 90% is 2.3 x Tau, Tau = R x C Example:  $200k\Omega$  x 100nF x 2.3 = 50ms The smaller is Tau the faster is the settling but the higher is the ripple.
- 2. Voltage Ripple

#### **Calculation Method:**

$$V_{DD} \cdot \left(1 - e^{-\frac{1}{f_0 \cdot R \cdot C}}\right) \text{ with } \left(f_0 \cdot \frac{1}{R \cdot C}\right)$$

$$v_{pp} = \frac{V_{DD}}{f_0 \cdot R \cdot C}$$

 $v_{pp}$  = ripple voltage (peak to peak)

$$f_0 = \text{for PWM}: \frac{1}{period} = f_{clk}/2^{PWMresolution|bit}$$

for PDM : 
$$\frac{1}{t_{pulsewidth}}$$

In the standard firmware, the result of measurement from capacitance or temperature is a 32-bit value. The DSP linearizes this 32-bit result to a value according to the resolution settings of the pulse interface. The parameters pi<n>\_result0, pi<n>\_ result1, pi<n>\_pulse0 and pi<n>\_pulse1 of the linear function are configurable in NVRAM, calibration space 800 to 822. The parameters are describing the edges for a simple scaling (1st order linearization), whereby pi<n>\_pulse0 is also the minimum clipping values and pi<n>\_pulse1 the maximum clipping value for the pulse output. Pi<n>\_pulse0 must be always smaller than pi<n>\_pulse1. For negative slopes just pi<n>\_result0 has to be larger than pi<n>\_result1. A 12-bit resolution thus limits the result value between 0 and 4096. For lower-bit resolutions, the range reduces accordingly.

The pulse\_out is determined like this:

$$pi_nout = \frac{pi_npulse1 - pi_npulse0}{pi_nresult1 - pi_nresult0} \cdot (result - pi_nresult0) + pi_npulse0$$

 $pi_n result1 > pi_n result0$ 

$$0 \le pi_n pulse 1 \le 2^{pulse \ resolution}$$


$$0 \le pi_n pulse 0 \le 2^{pulse \ resolution}$$

The following figure depicts how the result is processed to generate the pulsed output.

ams Datasheet Page 79
[v1-03] 2018-Apr-04 Document Feedback



Figure 113: PDM and PWM Pulse Generation



The following figure shows a sample linear function and its parameters graphically. In this graph, the result C1/C0 has been taken on the x-axis, assuming that this result is to be pulse modulated. A 12 bit resolution has been configured.

The settings for the PDM and PWM interface are made in configuration registers 27 and 29 to 33.

The lower limit (pi<n>\_pulse0) of the valid range corresponds to 0% modulation (all bits are 0), The upper limit (pi<n>\_pulse1) of the valid range corresponds to 100% modulation (all bits are 1), and this is the maximum possible value of output. 12 bit resolution implies that this maximum value is 4095. For lower-bit resolutions, this maximum value will come down accordingly. In terms of voltage, the two limits correspond to 0V and VDD.


Page 80

Document Feedback

[v1-03] 2018-Apr-04



Figure 114: **PDM and PWM Linearization** 



# **Applications:**

- A typical case would be outputting capacitance results through PG0 and temperature results through PG1. Calculation and transfer to the output registers will be performed by firmware.
- Main applications will be that an analog interface is demanded by the final customer.
- Applications where the serial interface cannot be used due to speed limitations or other reasons.
- Finally, a temperature-coded pulse stream could be low-pass filtered and then directly used for temperature control.

Please note that the entire linearization task as described here is performed by firmware, especially the PCap04\_standard and PCap04\_linearization firmware.

ams Datasheet Page 81 **Document Feedback** 



#### **Oscillators**

PCap04 offers a low frequency oscillator (**OLF\_CLK**) and an integrated 2MHz high frequency oscillator (**OHF\_CLK**). **OLF\_CLK** is running all the time and cannot be turned off.

# **OLF\_CLK** is used for:

- · CDC cycle time
- RDC cycle time
- PDM/PWM time base
- Watchdog for Standalone Applications

The **OHF\_CLK** can be used alternatively for

- CDC cycle time
- PDM/PWM time base

The **OLF\_CLK** can be trimmed for various typical frequencies:

Figure 115: OLF Trimming

OLF_CTUNE	OLF_FTUNE	OLF Frequency
3 : (10kHz)	1	5kHz
3 : (10kHz)	7	10kHz
2 : (50kHz)	0	28kHz
2 : (50kHz)	3	48kHz
1 : (100kHz)	4	100kHz
0 : (200kHz)	5	200kHz

**Note(s):** The internal oscillators are not very precise and stable. The frequency varies from chip to chip, with temperature and voltage.

- Variation over batch ± 20%
- Variation with temperature ± 5%,
- Variation with voltage. VDD ± 2%

The **OHF\_CLK** can be switched off, turned on with delay before further tasks like measurement follow, or turned on continuously:

OX\_RUN[2:0]0: Generator off

 $6: OX latency = 1 / f_{OLF}$ 

 $3: OX latency = 2 / f_{OLF}$ 

 $2: OX latency = 31 / f_{OLF}$ 

1: OX runs in permanence

By means of **OX\_DIV4** it can be divided by 4 to generate 500 kHz,

Page 82

Document Feedback

[v1-03] 2018-Apr-04




# **DSP & Memory**

This section describes the 32bit-DSP of the PCap04.

A 32-bit digital signal processor (DSP) in Harvard architecture was integrated to the PCap04. It is responsible for taking the information from the CDC and RDC measuring units, for processing the data and making them available to the user interface. Both, the CDC/RDC raw data as well as the data processed by the DSP are stored in the RAM. The program for the DSP is stored either in the NVRAM. The DSP can collect various status information from a set of 64 I/O Bits and write back 16 of those. This way the DSP can react on and also control the GPIO pins of PCap04. The DSP is internally clocked at approximately 60MHz. The internal clock is stopped through a firmware command, to save power. The DSP starts again upon a GPIO signal or an "end of measurement" condition.

In its simplest form, the DSP transfers the pure time measurement information from the CDC/RDC to the read registers without any further processing. The next higher step is to calculate the capacitance ratios including the information from the compensation measurements, as it is provided in **ams**' standard firmware version PCap04\_standard\_v01.hex. Finally, **ams** provides a ready-made linearize firmware that performs a linearization via polynomial of third degree and temperature compensation via polynomial of second degree. Many functional blocks for the linearization firmware are implemented as ROM code. This way, the main firmware can be very compact and can fit into the 1k NVRAM.

Figure 116: DSP Embedding



ams Datasheet Page 83
[v1-03] 2018-Apr-04 Document Feedback




The content of the read registers will always depend on the firmware in use. With the standard firmware it will be the pure capacitance and resistance ratios. With the linearization firmware it might the linearized and calibrated result, e.g. a pressure given in Pascal or humidity given in percent.

The DSP is **ams** proprietary to cover low-power tasks as well as very high data rates. It is programmed in Assembler. A user-friendly assembler software with a graphical interface, help text pop-ups as well as sample code sustain programming efforts.

# **DSP & Environment**

The DSP reads the RDC and CDC raw data from the RAM, processes then and writes the results back to the RAM. The program is stored in the NVRAM. It may use subroutines that are available from the ROM. The DSP reacts on flags and controls flags. It controls the GPIO and accordingly the PDM/PWM interface.

Figure 117: DSP Environment



The DSP is designed in Harvard architecture for 32 bit wide parallel data processing. It is coupled to a 128 x 32 bit RAM, 96 x 32 bit thereof freely accessible. In read access, the DSP can get the MEM\_DATA from address space 112 to 120, the CDC- and

Page 84

Document Feedback

[v1-03] 2018-Apr-04



RDC-frontend control from address space 121 to 124. By write access the DSP provides the output data to the PDM/PWM interfaces (addresses 109, 110).

A detailed description of the RAM is given is section 2.1. The DSP operates with two accumulators A and B and has direct access to the RAM, which can be seen as a third accumulator. The RAM address pointer is of 7 bit size, and there is a 6-fold stack for RAM addresses.

The program counter has 12 bit and there is an 8-fold stack for the program counter.

Finally, the DSP can get a lot of information from the 64 I/O bits. The read information covers the ALU status, trigger information, some of the configuration bits and the information about the status of the GPIOs. 16 of those bits can be used as outputs, setting the GPIOs and also some internal information. The DSP can read these bits by means of instruction jcd (conditional jump) and set those bits by means of instructions bitS/bitC (bit Set/Clear).

The ALU flags overflow, carry, equal/not equal and pos./neg. are used directly as condition for the jcd instructions and are also mirrored in the I/O bits.

#### **RAM Structure**

The RAM plays a key role. It is made of 128 words with size of maximum 32 bit. The DSP has free write and read access to registers address 0 to 96 of those words, all 32 bits wide. The RAM space addresses 97 to 104, 109 to 111 and 115 and higher has different meaning for read and write operations.

The main data in the read section are the raw data as they come from the CDC and the RDC. Also the parameters are in the RAM as part of the configuration registers and they are set via the serial interface or copied from the NVRAM.

The DSP reads the raw data, does the data processing and writes back the results into the write section of the RAM. From there, the user can read the final results through the serial interface.

Some of the RAM cells are dedicated to special functions and will be described in the following in detail.

ams Datasheet Page 85
[v1-03] 2018-Apr-04 Document Feedback



# Figure 118: RAM Structure in Detail

	RAM: DSP Read			RAM: DSP Write		te
Addr	Description	Bits		Addr	Description	Bits
127	Reserved					-
126	PORTINFO	24				
124	R_ADD_PTR	2				
123	C_ADD_PTR	4				
122	TDC_STOP	27				
121	TDC_START	27				
120	MEM_DATA_u08b	32				
119	MEM_DATA_u16b	32				
118	MEM_DATA_u24b	32				
117	MEM_DATA_s08b	32				
116	MEM_DATA_s16b	32				
115	MEM_DATA_s24b	32				
114	MEM_DATA (wr & 4Byte rd)				32	
113	MEM_ADD					10
112	MEM_CTRL					16
				111	TIMERO	16
				110	PI1_REF	16
				109	PIO_REF	16
108	DPTR3	1				7
107	DPTR2					7
106	DPTR1					7
105	DPTR0					7
				104	RES7	32
103	rad_stack_6b	6		103	RES6	32
102	rad_stack_12b	12		102	RES5	32
101	rad_stack_18b	18		101	RES4	32
100	rad_stack_24b	24		100	RES3	32

Page 86ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



	RAM: DSP Read			RAM: DSP Write		
Addr	Description	Bits		Addr	Description	Bits
99	rad_stack_30b	30		99	RES2	32
98	rad_stack_32b	32		98	RES1	32
97	2 last_RAM_address	32		97	RES0	32
96 Flags & extended GPIO's				32		
95	95 (free) User RAM			32		
				32		
0	0 (free) User RAM			32		

# Registers 0 to 95, User RAM

This is normal RAM space without any special functions. It is readable and writable via instruction rad.

# Example:

Add content of RAM address 12 and 13 and write the result into RAM address 13

rad 12

move a, r

rad 13

add r, a

ams Datasheet Page 87
[v1-03] 2018-Apr-04 Document Feedback



# Register 96, Flags & Internal Control Signals

# Figure 119: Flags

Bit	Flag Name	Default (after Reset)	Description
0	FIRSTART_N	0	Indicates first DSP-Trigger until set to 1 by firmware
12	Free to use	0	
3	RDCHG_COM_INT_SEL	0	0 : Use RDCHG_IN_SEL0 1 : Use RDCHG_IN_SEL1
			For internal compensation
4	Free to use	0	
	FLAG_CDC_INV	0	Temporary parameter to ROM routine _ROM_ cdc 0: Determine inverse ratios reference/sense 1: Determine ratios sense/reference
5	SIGNED_VALUE_NV	0	Temporary parameter to ROM routines _ROM_NVblock_copy_32bROM_NVblock_copy_24bROM_NVblock_copy_16bROM_NVblock_copy_08b_ 0: Treat data from NVRAM as unsigned 1: Treat data from NVRAM as signed
67	Reserved	0	Temporarily used flags within ROM routines
8	RST_RDC	Pulsed	Temperature reset. This flag has to be set 1, after each RDC measurement. Otherwise a new RDC measurement is not possible. This flag is set back to 0 automatically
915	Reserved		
1631	Free to use	Unknown	

# DSP Read Register 97

This register is there to get the N-th power of 2. The exponent N needs to be written to the RAD stack. The result can be read from register 81. In the assembler, the necessary three instructions are merged into one:

load2exp a, 10;  $a = 2^{10} = 1024$ 

A very simple and efficient method to set an accumulator = 1 is

load2exp b, 0 ;  $b = 2^0 = 1$ 

Page 88ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



#### **DSP Read Registers 98 to 103**

These registers contain the content of the RAM address stack. The 32 bit data is made of the 6 last 6-bit RAM addresses. This address can be used to load 32 bit constants from the program memory into the data space. The necessary instructions are merged into one single instruction by the assembler. (Hint: The assembler accepts negative values as well as decimal and hexadecimal numbers. Depending on the constant to be load, the assembler converts this instruction into 3 to 8 operations)

load a, 1715956 ; a = 1715956

is the same as

; 0x06 \* 2<sup>18</sup> rad 0x06

;+ 0x22 \* 2<sup>12</sup> rad 0x22

 $;+ 0x3b * 2^6$ rad 0x3b

rad 0x34 ;+ 0x34 = 1715956

rad 100 ; rad\_stack\_24b

move a, r

#### DSP Read/Write Registers 105 to 108, Data Pointer

These registers may be used for indirect addressing. They are 7 bits wide.

Load a register with the address you want to manipulate:

load a, <myaddress></myaddress>	load a, <myaddress></myaddress>
rad DPTR0	rad 105
move r, a	move r, a

Load a RAM address pointer with content of DPTR0:

rad \_at\_DPTR0; now ram address pointer is set to content of DPTR0

**Hint**: In the <pcap\_standard.h> "\_at\_DPTR0" to "\_at\_DPTR3" are set to values of 284 to 287. These are no valid RAM addresses but just indicators to the assembler to generate the corresponding opcodes.

ams Datasheet Page 89 **Document Feedback** 



Example direct memory address: Copy a memory block from one address to another:

sub_dma: not b	; initialize loop counter	; DPTR1 : source_address; DPTR0 : destination address; b: length of dma
inc b	; with - <length></length>	
sub_dma_loop:	;	
rad _at_DPTR1	; copy a : @DPTR1	
move a, r		
rad _at_DPTR0	; copy @DPTR0 : a	
move r, a		
rad DPTR0	; increment destination	
inc r	; address	
rad DPTR1	; increment source add	
inc r	;	
inc b	; increment loop	
	; counter	
jNEsub_dma_loop	; loop body	
jrt		

# DSP Read Register 126, PORTINFO (PORTERR<7...0>, PORTMASK<7...0>)

The low 8 bits mirror the port enable setting as defined by configuration parameter C\_PORT\_EN in register 12.

Bits 8 to 17 are error flags for the capacitance ports including the internal reference ports.

#### DSP Write Registers 97 to 104, RES00...RES07

These are the result registers to which the DSP has to write the output data so that the user can read those through the SPI/IIC interface as Res 0 to Res 7.

All addresses are 32 bit wide.

**!!! Attention:** These Registers are write only! The DSP cannot read from these Registers **!!!** 

```
DSP Write Registers 109, 110, PIO_REF...PI1_REF
```

These registers contain the data that is used to generate the PWM/PDM output signals. After the DSP has calculated and scaled the output data, it writes those into these two registers. The data are 16 bit wide.

#### DSP Write Register 111, TIMER0

The DSP has a 16-bit timer based on the OLF clock. This timer may be used to generate long delays while the DSP is halted. Bit #3 (timer) in DSP\_START\_EN must be set!

By writing a value to Register 111 the timer starts to count up from 0 each OLF-clock cycle until the written value has been reached. Then a DSP\_START\_TRIG is generated.

If the DSP is not halted the TIMERO\_IRQ\_N Flag could be tested anyway.

Page 90
Document Feedback
[v1-03] 2018-Apr-04



#### Example 1 (without halting DSP):

```
; 50*20µs (@50kHz)
CONST
           wait_time_1ms 50
load a, wait_time_1ms
rad TIMER0
move r, a
timer_wait_loop:
jcd TIMER0_IRQ_N, timer_wait_loop
```

#### Example 2 (with halting DSP, DSP run on internal oscillator):

```
CONST
          wait_time_1ms 50
                                ; 50*20µs (@50kHz)
ORG 0
jcd TIMER0_IRQ_N, Skip_Timer0_process
    jsb Triggered_by_Timer0
Skip_Timer0_process:
load a, wait time
rad TIMER0
move r, a
stop
Triggered_by_Timer0:
                              ; subroutine
```

ADD, MEM DATA

DSP Read/Write Registers 112 to 120, MEM\_CTRL, MEM\_

Those registers are used by ROM routines for the transfer of data between NVRAM and RAM. It is possible to transfer data between NVRAM and accumulators a and b, from 1 to 4 bytes, signed and unsigned.

- MEM\_CTRL: defines the operation. The four options are
  - MEM\_STORE: write to NVRAM
  - MEM RECALL: read from NVRAM
  - · MEM WE: enable writing
  - MEM\_WR\_PROTECT: protect against arbitrary writing
- MEM\_ADD: defines the target address in the NVRAM
- MEM\_DATA\_xxx: registers for write or read data. Data that shall be written into NVRAM data need to be in RAM address 114. Data that have been read from NVRAM can be found in addresses 114 to 120, depending on the format.

ams Datasheet Page 91 [v1-03] 2018-Apr-04 **Document Feedback** 



These calls are used e.g. to copy constants and calibration data from the NVRAM to the RAM.

```
Example: Copying the NV_C_sens_sel register to RAM
```

```
load a, NV_C_sens_sel ; mem_add : NV_C_sens_sel rad mem_add move r, a jsb _ROM_memory_rd_a_u08b__ ; A contains content of NV_C_sens_sel rad RAM_C_sens_sel move r, a
```

These registers may be used by the DSP to change the configuration on the fly. Important note: After writing to the NVRAM it is necessary to do an ini\_reset. Therefore the DSP has to do the following sequence of setting flags DSP\_6 and DSP\_7.

# ; Initreset

bitC 7 bitC 6

bitS 6

bitC 6

bitS 6

DSP Read Registers 121 to 124, TDC\_START, TDC\_STOP, C\_ADD\_PTR, R\_ADD\_PTR

ams internal data, used by ROM routine \_\_tdc\_dispatch\_\_

Page 92ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



#### **NVRAM** and ROM

The total program memory is made of 1k NVRAM and 3k ROM. The NVRAM holds configuration data, 960 byte of user code and some special registers. The ROM holds useful mathematical routines that make programming very efficient.

#### **NVRAM Structure**

The user space is split in three sections. The reason is that the NVRAM can be read/write protected by section. A big section of 704 byte is for program code, two smaller sections of 128 byte may be used for calibration data or additional firmware.

Figure 120: NVRAM Organization

Address		NVRAM (1k)	Memory Lock	
Decimal	Hexadecimal	Contents	Length [Byte]	Settings
1023 to 1022	3FF to 3FE	CHARGE_PUMP	2	MEM_LOCK<3>
1021 to 1011	3FD to 3F3	Reserved	11	
1010 to 1009	3F2 to 3F1	S/N customer	2	
1008	3F0	MEM_LOCK	1	
1007 to 960	3EF to 3C0	Configuration Registry	48	MEM_LOCK<3>
959 to 832	3BF to 340	User Space (FW/CAL1)	128	MEM_LOCK<2>
831 to 704	33F to 2C0	User Space (FW/CAL0)	128	MEM_LOCK<1>
703 to 0	2BF to 0	User Space (FW)	704	MEM_LOCK<0>

The NVRAM consists of two parts: a volatile SRAM and a non-volatile memory (FLASH). There is a store/recall method to copy (store) the complete SRAM content to FLASH or to recall it from FLASH back to SRAM.

Different methods of operation apply:

#### • Stand Alone:

Configuration data, firmware and calibration values are stored once to non-volatile memory and autoboot is selected. After a power-on the device starts immediately with the measurement.

#### Pre-Configured:

Configuration data, firmware and calibration values are stored once to nonvolatile memory, RUNBIT and autoboot are disabled. After power-on, the device is programmed and configured, but in idle mode, waiting for instructions.

#### • Pure Slave:

Configuration data, firmware and calibration values are written to the SRAM (volatile memory) after each power on by an external  $\mu C$ .

ams Datasheet Page 93
[v1-03] 2018-Apr-04 Document Feedback



#### **NVRAM Access**

There are three commands available to handle the NVRAM, Store, Recall & Erase, each one protected to avoid accidental trigger during communication over the serial interface. It is mandatory to send first an activation code to register 54 (MEM\_CTRL). This is followed by the according opcode (|| = termination of SIF, e.g. setting SSN = HIGH):

Store SRAM content into NVRAM: Activation code in MEM\_CTRL:

0x2D

Store NVRAM opcode: 0x96

(Send via SIF: 0xA3F62D | 0x96,

wait minimum 12 ms)

Recall from NVRAM into SRAM: Activation in MEM\_CTRL: 0x59

Recall from NVRAM opcode: 0x99

(Send via SIF: 0xA3F659 | 0x99)

Erase NVRAM: Read trim bits adr 1022&1023 and

Unique ID from adr 954 to 959 Activation in MEM\_CTR: 0xB8 Erase NVRAM opcode: 0x9C

(Send via SIF: 0xA3F6B8 | 0x9C,

wait minimum 12ms)

Write back trim bits adr 1022&1023 and Unique ID to adr 954 to 959
Activation code in MEM\_CTRL: 0x2D

Store NVRAM opcode: 0x96

**Important Note:** We guarantee the data for data retention and endurance only under the assumption, that the customer does **not** change the registers 62 and 63 and NVRAM adr 954 to 959 (Unique ID). In addition, it is mandatory to follow the given procedure for ERASE NVRAM as described in section NVRAM and ROM precisely. Otherwise, **we do no longer guarantee** the data retention time and endurance cycles.

#### **ROM Structure**

The limitation in size for the NVRAM is compensated by having many functions integrated hard-wired in 3k ROM. The ROM routines range from simple shift functions over filters to polynomial linearization of 4<sup>th</sup> degree. This allows to keep the user code very compact.

The assembler comes with header file PCap04\_ROM\_ addresses\_standard.h that lists the jump-in addresses for the various ROM routines. For details see section Sample Code / Libraries.

#### **DSP Inputs & Outputs**

The DSP has access to 64 bits of information on ALU status, start trigger, configuration, input / output pins.

Page 94

Document Feedback

[v1-03] 2018-Apr-04



This information can be interpreted by means of instructions jcd or conditional jump.

Instruction conditional jump looks like:

jcd p1,p2: if p1 ==1 then jump to p2, p1 = flag number 16 of those bits can be set by the DSP, e.g. to set a GPIO or to select between RDC and CDC data. The bits are controlled by means of instructions bitS / bitC (bit Set/bit Clear).

Figure 121: DSP Inputs / Outputs

Bit Name	Description	Туре	Read Bit #	Write Bit #
DSP_OUT<70>	Status feedback of the 8 general DSP outputs (Write bits 0 to 7).	IN	56 to 63	
SIF_TRIGGERED_N (1)	Flag = LOW indicates that a falling edge at a pin or an SPI/IIC opcode has started the DSP. This flag is reset by a STOP instruction at the end of the firmware.	Start trigger	55	
PIN_TRIGGERED_N (1)	Flag = LOW indicates a GPIO has started the DSP		54	
TDC_TRIGGERED_R_N (1)	Flag = Low indicates that a single time-values from Resistance (Temperature) measurement are available and must be processed (done by ROM routine _ROM_tdc_dispatch)			
TDC_TRIGGERED_C_N (1)	Flag = LOW indicates that time-values from Capacitance measurement are available and must be processed (done by ROM routine _ ROM_tdc_dispatch)	Start trigger	52	
INTN_TRIGGERED_N (1)	Flag = LOW indicates the DSP is started by rising edge of INTN-Signal	Start trigger	51	
TIMERO_IRQ_N (1)	Flag = LOW indicates the DSP is started by the internal timer	Start trigger	50	
RDC_TRIGGERED_N (1)	Flag = LOW indicates that an RDC measurement has started the DSP. Therefore, DSP_ STARTONTEMP has to be set (configuration register 8). This flag is reset by a STOP instruction at the end of the firmware.	Start trigger	49	
CDC_TRIGGERED_N (1)	Indicates the DSP is started by the end of the capacitance conversion.	Start trigger	48	

ams Datasheet Page 95
[v1-03] 2018-Apr-04 Document Feedback



Bit Name	Description	Туре	Read Bit #	Write Bit #
ALU_OFL_N		Status	47	
ALU_OFL		Status	46	
ALU_CAR_N		Status	45	
ALU_CAR	ALU flags for overflow, carry, equal and sign. The ALU flags are used by the jump instruction of	Status	44	
ALU_EQ / ALU_ZERO	the assembler	Status	43	
ALU_NE / ALU_ZERO_N		Status	42	
ALU_POS		Status	41	
ALU_NEG		Status	40	
FLAGREG_N[7:0]	Lower 8bits, inverted Flags from FLAGREG (register 96)	Flag	3239	
AWAKE_TRIGGERED_N	After setting RUNBIT to 1 the DSP is triggered immediately. This flag shows this trigger source. Used for initialize raw result registers before first measurement (used by ROM routine _ROM_tdc_dispatch)	Start Trigger	31	
TDC_RDY	Flag = Low indicates TDC-Ring oscillator is running	Status	28	
POR_CDC_DSP_COLL	Flag = Low indicates reset forced by a CDC / DSP collision	Status	27	
LAST_CYCLE_ACTIVE_N	Flag = Low indicates that this is the last CDC measurement in the current sequence (used for ROM routine _ROM_tdc_dispatch)	Status	26	
CYC_ACTIVE	Flag = bit 23 of status register. Indicates that the CDC frontend is active. (not negated)	Status	25	
POR_FLAG_WD	Flag = Low indicates a reset was forced by watchdog timeout	Status	24	
POR_FLAG_PARITY	Flag = Low indicates a reset was forced by one or more configuration bits toggled by interferences.	Status	23	
CONTINUOUS_N	Low : Continuous mode is activated	Config Reg	22	
AUTOSTART_N	Bit from configuration register	Config Reg	21	
C_REF_INT	Bit from configuration register	Config Reg	20	

Page 96ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



Bit Name	Description	Туре	Read Bit #	Write Bit #
TIMER_TRIG_DSP			19	
(TRUE)	Constant 1, usable for "goto" jcd TRUE, < jump_address>		18	
INT_TRIG_BG_N	Bit from configuration register	Config Reg	17	
CDC_TRIG_BG_N	Bit from configuration register	Config Reg	16	
C_COMP_EXT_N	Bit from configuration register	Config Reg	15	
C_COMP_IN_N	Bit from configuration register	Config Reg	14	
C_SINGLE / C_DIFFERENTIAL_N	Bit from configuration register	Config Reg	13	
C_GROUNDED / C_FLOATING_N	Bit from configuration register	Config Reg	12	
ERR_OVFLN	Flag = bit 16 of status register. Indicates an overflow or other error in the TDC.	Status	11	
COMB_ERRN	Flag = bit 16 of status register. This is a combined condition of all known error conditions.	Status	10	
CYC_ACTIVE_N	Flag = bit 23 of status register. Indicates that the CDC frontend is active. (negated)	Status	9	
SIF_RES_RD_BSY		Status	8	
RAM_BUSY	Indicates, NVRAM is busy	Status	7	
Interrupt_In	Port INTN will be reset by a positive edge on SSN (SPI) or a stop condition (I <sup>2</sup> C), whith this flag the current status of INTN can be detected	Status	6	
TEMPERR_N	Flag = bit 3 of status register 1. Indicates whether an error occurred during the temperature measurement.  0: Error, 1: No error	Status	5	
RDC_BUSY	Flag = bit 2 of status register. Indicates RDC unit is busy. 0: Measurement done, 1: Measurement running.	Status	4	
TRIG_BG	This parameter starts the Bandgap (to synchronize with measurement) (pulse, automatically set to 0)	Out		15
(MEM_PUSH)	Reserved, only usable by ROM routines	Out		14



Bit Name	Description	Туре	Read Bit #	Write Bit #
RST_CDC	CDC reset. This flag has to be set 1, after each CDC measurement. Otherwise, a new CDC measurement is not possible. This flag is set back to 0 automatically	Out		13
(MEM_RD)	Reserved, only usable by ROM routines	Out		12
Interrupt_Out	Sets the interrupt (pin PG4 or PG5, see register 30) (pulse, automatically set to 0)	Out		11
(PAGE)	Reserved, do not use	Out		10
TRIG_RDC	This bit starts a new RDC measurement. (pulsed, automatically set to 0)	Out		9
TRIG_CDC	This bit starts a new CDC measurement (pulsed, automatically set to 0)	Out		8
DSP_7	Those two outputs are used by the DSP for - Reset watchdog - INI_RESET by DSP (Pattern combination of both Outputs are used to prevent these actions triggered accidentally) ; Initreset	Out		7
DSP_6	bitC 7 bitC 6 bitS 6 bitC 6 bitS 6	Out		6
DSP_5	Sets the general purpose output pin PG5	Out		5
DSP_4	Sets the general purpose output pin PG4	Out		4
DSP_3	When the Pulse1 is switched OFF then this bit can be used to set and clear the general purpose output pin PG3. When the Pulse1 is ON then this bit must be cleared so that the Pulse1 output appears on PG3.	In/Out	3	3
DSP_2	When the Pulse0 is switched OFF then this bit can be used to set and clear the general purpose output pin PG2. When the Pulse0 is ON then this bit must be cleared so that the Pulse0 output appears on PG2	In/Out	2	2
DSP_1	Set or read the general purpose I/Os at pins PG0 & PG1. The assignment is programmable and	In/Out	1	1
DSP_0	shown in detail below.	In/Out	0	0

# Note(s):

Page 98ams DatasheetDocument Feedback[v1-03] 2018-Apr-04

<sup>1.</sup> A negative edge on those inputs start the DSP. The status of the start trigger is memorized till the next reset or stop of the DSP. The start trigger information can be read from inputs 48 to 55 by jcd.



# **ALU Flags**

Every ALU operation sets flags. The ALU has four flags: overflow, carry, equal and sign. The following table shows an overview:

# Figure 122: **ALU Flags**

Flag	Description	Format	Modified by Instructions:	Interpreted by Instructions:	Range
ON	No Overflow	signed	add, sub, mult,	jOvlC, jOvlS	$>= -2^{31}$ and $<= 2^{31} - 1$
0	Overflow	Signed	div	jovic, jovis	$< -2^{31}$ and $> 2^{31} - 1$
CN	No Carry <sup>(1)</sup>	unsigned	add, sub, mult,	jCarC, jCarS	< 2 <sup>32</sup>
С	Carry (1)	unsigned	div	jeure, jeurs	>= 2 <sup>32</sup>
Z	Equal / Zero	signed /	add, sub, mult,		== 0
ZN	Not Equal / Not Zero	unsigned	div, move, shiftL, shiftR	jEQ, jNE	!=0
S	Positive	signed	add, sub, mult, div, move, shiftL,	jPos, jNeg	>= 0
SN	Negative	signed	shiftR	jros, jiveg	< 0

#### Note(s):

E.g. for A - B: if 
$$A \ge B \rightarrow C = 1$$
; if  $A < B \rightarrow C = 0$ .

In other words, the carry C is actually the status of the carry of the addition operation A+ 2's complement (B).

ams Datasheet Page 99 **Document Feedback** 

<sup>1.</sup> During addition, the carry C is set when a carry-over takes place from the most significant bit, else C remains at 0. During subtraction, carry C is by default 1. Carry C is cleared only when the minuend < subtrahend.



# **DSPOUT - GPIO Assignment**

PCap04 is very flexible with assignment of the various GPIO pins to the DSP inputs/outputs. The following table shows the possible combinations.

Figure 123: Pin Assignment

External Port	Description	In/Out
	SSN (in SPI-Mode)	ln
PG0	DSP_x_0 or DSP_x_2	In <sup>(1)</sup> / Out
PGU	FF0 or FF2	In <sup>(1)</sup>
	Pulse0	Out
	MISO (in SPI-Mode)	Out
PG1	DSP_x_1 or DSP_x_3	In <sup>(1)</sup> / Out
FGI	FF1 or FF3	In <sup>(1)</sup>
	Pulse1	Out
	DSP_x_0 or DSP_x_2	In <sup>(1)</sup> / Out
PG2	FF0 or FF2	In <sup>(1)</sup>
	Pulse0	Out
	DSP_x_1 or DSP_x_3	In <sup>(1)</sup> / Out
PG3	FF1 or FF3	In <sup>(1)</sup>
. 33	Pulse1	Out
	C_G_MUX_SEL	Out
PG4	DSP_OUT_4 (output only)	Out
1 37	INTN	Out
PG5	DSP_OUT_5 (output only)	Out
. 33	INTN	Out


# Note(s):

1. These ports provide an optional debouncing filter and an optional pull-up resistor.

Page 100ams DatasheetDocument Feedback[v1-03] 2018-Apr-04




Figure 124: GPIO Assignment



ams Datasheet [v1-03] 2018-Apr-04



Figure 125: **Port Trigger Timing** 



There is a possibility to activate a 40ms debounce filter ("monoflop") for the ports in case these are used as inputs. This might be useful especially in case the DSP is started by the pins (signals FF0, FF2). Figure 125 shows the effect of the monoflop filter.

Page 102 ams Datasheet [v1-03] 2018-Apr-04



The settings for this are made in the following configuration registers:

Figure 126: Ports for Pulse Output

Reg	Parameter	Settings	Description
27	DSP_MOFLO_EN	Bit 6 for PG0 Bit 7 for PG1	Activates anti-bouncing filter in PG0 and PG1 lines
27	PG0xPG2	0 : PG0 1 : PG2	The pulse codes can be output at ports PG0 & PG1 or PG2 & PG3. In I <sup>2</sup> C mode they can be optionally given out on
27	PG1xPG3	0:PG1 1:PG3	PG2 and PG3, instead of PG0 and PG1.
29	DSP_FF_IN	Bit 0 : PG0 Bit 1 : PG1 Bit 2 : PG2 Bit 3 : PG3	Pin mask for latching flip-flop activation
30	PG4_INTN_EN	Bit 6	Activates INTN at port PG4
30	PG5_INTN_EN	Bit 7	Activates INTN at port PG5
33	PG_DIR_IN	0 : Output 1 : Input	Toggles outputs to inputs (PG3/bit7 to PG0/bit4).
33	PG_PU	Bit 0 : PG0 Bit 1 : PG1 Bit 2 : PG2 Bit 3 : PG3	Activates pull-up resistors in PG0 to PG3 lines; useful for mechanical switches.



# **DSP** Configuration

Configuration register 8 defines the DSP operation. Relevant bits are:

DSP\_SRAM\_SEL, DSP\_START, DSP\_STARTONOVL, DSP\_STARTONTEMP, DSP\_STARTPIN, DSP\_WATCHDOG\_LENGTH, DSP\_SPEED

Figure 127: DSP Configuration

Reg	Parameter	Settings	Description
27	DSP_SPEED	0: Fastest 1: Fast 2: Recommended 3: Low-current (slow)	Setting the DSP speed
29	DSP_STARTONPIN	0:FF0 1:FF1 2:FF2 3:FF3	Pin mask for DSP trigger
30	DSP_START_EN<20>		DSP trigger enable 'bxxx1 : Trigger by end of CDC 'bxx1x : Trigger by end of RDC (recommended) 'bx1xx : Trigger by timer 'b1xxx : Obsolete
34	DSP_TRIG_BG	0 : Disabled 1 : Enabled	Bandgap refresh is triggered by start of DSP determination.

Page 104ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



#### **DSP Start**

There are various options to trigger the DSP.

In slave operation:

• Trigger by external controller. This is done by sending opcode "CDC Start conversion" or "DSP\_TRIG".

In stand-alone operation:

- Trigger by pin. The trigger pin is selected between pins PG0 to PG3 by configuration parameters DSP\_STARTPIN and PG0\_X\_PG2/PG1\_X\_PG3. Signal FFx triggers the DSP. FFx has to be reset in the firmware by setting DSP\_x, e.g. BitS DSP 2
  - BitC DSP\_2
- · Trigger by the end of CDC

RDC

Timer

Or by an interrupt. The option is selected by configuration parameter DSP\_START\_EN.

(Hint: DSP is also triggered by

- Toggling RUNBIT from 0 to 1. This is indicated by Flag "AWAKE\_TRIGGERED\_N".
- After each CDC or RDC cycle. This is indicated by Flags TDC C TRIGGERED N and TDC R TRIGGERED N)

#### Watchdog

The watchdog is based on the OLF clock and counts always, even if the DSP is halted. If the DSP doesn't reset the Watchdog within 9s to 15s a power-on reset is generated => auto-boot. Status Flag POR FLAG Wdog is set.

The watchdog is implemented to handle situations where no CDC or RDC is running.

In applications as slave, the watchdog has to be disabled. This can be done by writing a 0x5A to WD\_DIS. If the watchdog is used disarm the watchdog in advance to any SIF-Communication.

#### System Reset

In case the PCap04 is operated as a slave, not in self-boot mode, it is necessary to do the following actions after applying power:

- 1. Send opcode Power-on Reset via the serial interface, opcode 0x88.
- 2. Write the firmware into the SRAM by means of opcode "Write to SRAM".
- 3. Write the configuration registers by means of opcode "Write Config". Register 47 with the RUNBIT has to be the last one in order.
- 4. Send a start command, opcode 0x8C

ams Datasheet Page 105 **Document Feedback** [v1-03] 2018-Apr-04



#### **Instruction Set**

The complete instruction set of the PCap04 consists of 29 core instructions that have unique op-code decoded by the CPU. Further, **ams** offers a set of libraries including common constant definitions and mathematical operations

The library family is intended to be continuously expanded and be a great help during software development.

Figure 128: **Instruction Set** 

Simple Arithmetic	Miscellaneous	RAM Access	Bitwise Operation
add	init	rad	not
sign	nop	clear	and
sub	rst	load	or
inc	stop	load2exp	xor
	wdr	mov push pop	

Complex Arithmetic	Shift & Rotate	Unconditional Jump	Bitwise
div	shiftL	goto jsb	bitC
mult	shiftR	jrt	bitS

Conditional Jump		
jcd	jEQ	jOfIC
jCarC	jNE	jOfIS
jCarS	jNeg	jPOS

Page 106 ams Datasheet [v1-03] 2018-Apr-04



# Instructions

and	Bitwise AND
Syntax:	and p1,p2
Parameters:	p1 = ACCU [a,b,r] p2 = ACCU [a,b,r] p1 != p2
Calculus:	p1:p1 & p2
Flags affected:	COSZ
Bytes:	1
Description:	Bitwise AND (conjunction)
Category:	Bitwise operation

add	Addition
Syntax:	add p1,p2
Parameters:	p1 = ACCU [a,b,r] p2 = ACCU [a,b,r]
Calculus:	p1:p1+p2
Flags affected:	COSZ
Bytes:	1
Description:	Addition of two registers
Category:	Simple arithmetic

bitC	Clear single bit
Syntax:	bitC p1
Parameters:	p1 = number 0 to 15
Calculus:	Set bit number p1 of the DSP output bits bit = 0
Flags affected:	-
Bytes:	1
Description:	Clear a single bit in the DSP output bits
Category:	Bitwise



bitS	Set single bit
Syntax:	bitS p1
Parameters:	p1 = number 0 to 15
Calculus:	Set bit number p1 of the DSP output bits bit = 1
Flags affected:	-
Bytes:	1
Description:	Set a single bit in the DSP output bits
Category:	Bitwise

clear	Clear register
Syntax:	clear p1
Parameters:	p1 = ACCU [a,b,r]
Calculus:	p1:0
Flags affected:	SZ
Bytes:	2
Description:	Clear addressed register to 0
Category:	RAM access

Page 108ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



div	Unsigned division
Syntax:	div
Parameters:	-
Calculus:	Single div code: b: (a/r), a: Remainder * 2 N div codes: b: (a/r)*2^(N-1), a: Remainder * (2^N)
Flags affected:	SZ
Bytes:	1
Description:	Unsigned division of two 32-bits registers. When the div opcode is used once, the resulting quotient is assigned to register 'b'. The remainder can be calculated from 'a'. When N div opcodes are used one after another, the result in b: $(a/r)*2^{(N-1)}$ . See also ROM routine div_xx.  Before executing the first division step, the following conditions must be satisfied: 'b' = 0, and $0<'a'<2*'r'$ .  If this condition is not satisfied, you can shift 'a' until this is satisfied. After shifting, if a -> $a*(2^{a})$ and $r->r*(2^{a})$ , then the resulting quotient b for N division steps is b: $(a/r)*2^{(1+ea-er-N)}$ a = Remainder * $(2^{N})$
Category:	Complex arithmetic

inc	Increment register
Syntax:	inc p1
Parameters:	p1 = ACCU [a,b,r]
Calculus:	p1:p1+1
Flags affected:	COSZ
Bytes:	1
Description:	Increment register
Category:	Simple arithmetic

ams DatasheetPage 109[v1-03] 2018-Apr-04Document Feedback



init	Init reset
Syntax:	Init
Parameters:	-
Calculus:	-
Flags affected:	COSZ
Bytes:	1
Description:	Initialization and reset. Sets back CDC, RDC and CPU. Copies configuration from NVRAM into configuration registers.
Category:	Miscellaneous

jCarC	Jump on Carry Clear
Syntax:	jCarC p1
Parameters:	p1 = jumplabel
Calculus:	if (carry == 0) PC : p1
Flags affected:	-
Bytes:	2
Description:	Jump on carry clear. Program counter will be set to target address if carry is clear. The target address is given by using a jumplabel. The conditional jump does not serve the stack. Therefore it is not possible to return by jrt.  If the target address is beyond the range of current address (PC) -128/+127 bytes, then the assembler software will substitute this opcode for the following optimization:  jCarS new_label  jsb p1  jrt  new_label:
Category:	Conditional jump

Page 110ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



jCarS	Jump on Carry Set
Syntax:	jCarS p1
Parameters:	p1 = jumplabel
Calculus:	if (carry == 1) PC : p1
Flags affected:	-
Bytes:	2
Description:	Jump on carry set. Program counter will be set to target address if carry is set. The target address is given by using a jumplabel. The conditional jump does not serve the stack. Therefore it is not possible to return by jrt. If the target address is beyond the range of current address (PC) -128/+127 bytes, then the assembler software will substitute this opcode for the following optimization:  jCarC new_label jsb p1 jrt new_label:
Category:	Conditional jump

jcd	Conditional Jump
Syntax:	jcd p1, p2
Parameters:	p1 = Flag or input port bit [630]. See section 2.3 for DSP Inputs. p2 = jumplabel
Calculus:	If (p1 == 1) PC: p2
Flags affected:	-
Bytes:	2
Description:	Program counter is set to target address if the bit given by p1 is set to one. The target address is given by using a jumplabel. The conditional jump does not serve the stack. Therefore it is not possible to return by jrt.  If the target address is beyond the range of current address (PC) -128/+127 bytes, then the assembler software will substitute this opcode for the following optimization:  jcd p1, new_label1
	<pre>jsb new_label2 jrt new_label1: jsb p2 jrt new_label2: ;</pre>
Category:	Conditional jump

ams DatasheetPage 111[v1-03] 2018-Apr-04Document Feedback



jEQ	Jump on Equal
Syntax:	jEQ p1
Parameters:	p1 = jumplabel
Calculus:	if (Z == 0) PC : p1
Flags affected:	-
Bytes:	2
Description:	Jump on equal resp. zero. Program counter will be set to target address if the foregoing result is zero. The target address is given by using a jumplabel. The conditional jump does not serve the stack. Therefore it is not possible to return by jrt. If the target address is beyond the range of current address (PC) -128/+127 bytes, then the assembler software will substitute this opcode for the following optimization: jNE new_label jsb p1 jrt new_label:
Category:	Conditional jump

jNE	Jump on Not Equal
Syntax:	jNE p1
Parameters:	p1 = jumplabel
Calculus:	if (Z == 1) PC : p1
Flags affected:	-
Bytes:	2
Description:	Jump on not equal resp. not zero. Program counter will be set to target address if the foregoing result is zero. The target address is given by using a jumplabel. The conditional jump does not serve the stack. Therefore it is not possible to return by jrt. If the target address is beyond the range of current address (PC) -128/+127 bytes, then the assembler software will substitute this opcode for the following optimization: jEQ new_label jsb p1 jrt new_label:
	reduced by one.
Category:	Conditional jump

Page 112ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



jNeg	Jump on Negative
Syntax:	jNeg p1
Parameters:	p1 = jumplabel
Calculus:	if (S == 1) PC : p1
Flags affected:	-
Bytes:	2
Description:	Jump on negative. Program counter will be set to target address if the foregoing result is negative (Bit 31 == 1). The target address is given by using a jumplabel.  If the target address is beyond the range of current address (PC) -128/+127 bytes, then the assembler software will substitute this opcode for the following optimization:  jPos new_label jsb p1 jrt new_label:
Category:	Conditional jump

jOvIC	Jump on Overflow Clear
Syntax:	jOvlC p1
Parameters:	p1 = jumplabel
Calculus:	if (O == 0) PC : p1
Flags affected:	-
Bytes:	2
Description:	Jump on overflow clear. Program counter will be set to target address if the overflow flag of the foregoing operation is clear. The target address is given by using a jumplabel. The conditional jump does not serve the stack. Therefore it is not possible to return by jrt.  If the target address is beyond the range of current address (PC) -128/+127 bytes, then the assembler software will substitute this opcode for the following optimization: jOflS new_label jsb p1 jrt new_label:
Category:	Conditional jump

Page 113 ams Datasheet Document Feedback



jOvIS	Jump on Overflow Set
Syntax:	jOvlS p1
Parameters:	p1 = jumplabel
Calculus:	if (O == 1) PC : p1
Flags affected:	-
Bytes:	2
Description:	Jump on overflow set. Program counter will be set to target address if the overflow flag of the foregoing operation is set. The target address is given by using a jumplabel. The conditional jump does not serve the stack. Therefore it is not possible to return by jrt. If the target address is beyond the range of current address (PC) -128/+127 bytes, then the assembler software will substitute this opcode for the following optimization: jOfIC new_label jsb p1 jrt new_label:
	In this case the stack will be loaded with p1, and therefore the stack capacity will be reduced by one.
Category:	Conditional jump

jPos	Jump on Positive
Syntax:	jPos p1
Parameters:	p1 = jumplabel
Calculus:	if (S == 0) PC : p1
Flags affected:	-
Bytes:	2
	Jump on positive. Program counter will be set to target address if the foregoing result is positive (Bit 31 == 0). The target address is given by using a jumplabel. The conditional jump does not serve the stack. Therefore it is not possible to return by jrt. If the target address is beyond the range of current address (PC) -128/+127 bytes, then the assembler software will substitute this opcode for the following optimization:
Description:	jNeg new_label
	jsb p1
	jrt
	new_label:
	In this case the stack will be loaded with p1, and therefore the stack capacity will be reduced by one.
Category:	Conditional jump

Page 114ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



jrt	Return from subroutine
Syntax:	jrt
Parameters:	-
Calculus:	PC : PC from jsub-call
Flags affected:	-
Bytes:	1
Description:	Return from subroutine. A subroutine can be called via 'jsb' and exited by using jrt. The program is continued at the next command following the jsb-call. You have to close a subroutine with jrt - otherwise there will be no jump back.  The stack is decremented by 1.
Category:	Unconditional Jump

goto	Unconditional relative Jump
Syntax:	goto p1
Parameters:	p1 = jumplabel
Calculus:	PC:p1
Flags affected:	-
Bytes:	2
Description:	Jump to jumplabel. Program counter will be set to target address. The target address is given by using a jumplabel. The goto command does not serve the stack. Therefore it is not possible to return by jrt.  If the target address is beyond the range of current address (PC) -128/+127 bytes, then the assembler software will substitute this opcode for the following optimization:  goto new_label1  jsb new_label2  jrt  new_label1:  jsb p2  jrt  new_label2:  ;
Category:	Unconditional Jump

Page 115 ams Datasheet Document Feedback



jsb	Unconditional Jump
Syntax:	jsb p1
Parameters:	p1 = jumplabel
Calculus:	PC : PC from jsub-call
Flags affected:	-
Bytes:	2
Description:	Jump to subroutine without condition. The programm counter is loaded by the address given through the jumplabel. The subroutine is processed until the keyword 'jrt' occurs. Then a jump back is performed and the next command after the jsub-call is executed. This opcode needs temporarily a place in the program counter stack (explanation see below).  The stack is incremented by 1.
Category:	Unconditional Jump

load	Load Accumulator
Syntax:	load p1,p2
Parameters:	p1 = ACCU [a,b] p2 = 632-bit integer number (positive/negative, decimal or hexadecimal)
Calculus:	p1 : p2
Flags affected:	SZ
Bytes:	38 (depending on p2)
Description:	Move constant to p1 (p1=ACCU, p2=NUMBER) The following instruction is not allowed: load r, NUMBER This instruction is a macro that is replaced by the following opcodes: rad NUMBER[23:18] rad NUMBER[17:12] rad NUMBER[11:6] rad NUMBER[5:0] rad rad_stack_24b move [a, b], r  Here the 24-bits number is split into four pieces, the symbol [xx:yy] indicates the individual bit range belonging to each piece. Please notice that the ram address pointer is changed during the operations, keep this in mind while coding.
Category:	RAM access

Page 116ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



load2exp	Load Accumulator with 2exp
Syntax:	load2exp p1,p2
Parameters:	p1 = ACCU [a,b] p2 = 6-bit number
Calculus:	p1:2^p2
Flags affected:	SZ
Bytes:	2
Description:	Move 2^(p2) to p1(p1=ACCU, p2=NUMBER) The following instruction is not allowed:
	load r, NUMBER
	This instruction is a macro that is replaced by the following opcodes:
	rad NUMBER[5:0]
	rad load2exp
	move [a, b], r
Category:	RAM access

mov	Move
Syntax:	mov p1,p2
Parameters:	p1 = ACCU [a,b,r] p2 = ACCU [a,b,r]
Calculus:	p1:p2
Flags affected:	SZ
Bytes:	1
Description:	Move content of p2 to p1 Assembler will understand also the old opcode move
Category:	RAM access

ams DatasheetPage 117[v1-03] 2018-Apr-04Document Feedback



mult	Multiply
Syntax:	mult
Parameters:	-
Calculus:	ab:(b*r)
Flags affected:	SZ
Bytes:	1
Description:	Unsigned multiplication of the content of ab and r registers. ab is the composition of the registers a and b, forming an 64-bits long register, where 'a' takes the most significant bits, and register 'b' takes the less significant ones. The result is stored in the composed register a and b. The register 'a' must be previously cleared.  This instruction only executes one multiplication step, to execute a full 32-bits multiplication, this instruction must be executed 32 times. This has the disadvantage of being tedious to code, but also has the advantage of executing only the amount of arithmetic needed, if you do not need a 32-bits multiplication but N, where N<32, then you have only to execute N multiplication steps in order to complete the full N-bits multiplication.  After one multiplication step, register 'a' contains ((a+(b[0]*r))>>1), and register 'b' contains { a[0], b[3:1] }. For example: lets denote the individual bits of register 'a' as a[31], a[30], a[29]a[2], a[1], a[0], and lets denote a range of bits of 'a' as: a[3:0], meaning the 4 less significant bits of register 'a'.  Then, after one multiplication step, a[30:0] = (a[31:0] + r[31:0] * b[0]) >> 1, where >> 1, means right shift by one position; the value of a[31] is zero, and b[31] = (a[0] + r[0] * b[0]), and b[30:0] = b[311]. The register r remains unchanged.
Category:	Complex arithmetic

nop	No operation
Syntax:	-
Parameters:	-
Calculus:	-
Flags affected:	-
Bytes:	1
Description:	Placeholder code or timing adjust (no function)
Category:	Miscellaneous

Page 118ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



not	Bitwise NOT
Syntax:	not p1
Parameters:	p1 = ACCU [a,b,r]
Calculus:	p1:~p1
Flags affected:	COSZ
Bytes:	1
Description:	Invert register (negation)
Category:	Bitwise operation

or	Bitwise OR
Syntax:	or p1,p2
Parameters:	p1 = ACCU [a,b,r] p2 = ACCU [a,b,r] p1 != p2
Calculus:	p1:p1 p2
Flags affected:	COSZ
Bytes:	1
Description:	Bitwise OR (disjunction)
Category:	Bitwise operation

рор	Remove address
Syntax:	рор
Parameters:	-
Calculus:	-
Flags affected:	-
Bytes:	1
Description:	Roll back ram-address stack
Category:	RAM access

ams DatasheetPage 119[v1-03] 2018-Apr-04Document Feedback



rst	Power On Reset
Syntax:	rst
Parameters:	-
Calculus:	-
Flags affected:	SZ
Bytes:	5
Description:	This is a symbolic opcode which is equivalent to the following instruction sequence:
	bitC 54
	bitC 55
	bitS 55
	bitS 54
	bitC 55
	The assembler understands also the old powerOnReset
Category:	Miscellaneous

push	Put data into stack memory	
Syntax:	push p1	
Parameters:	p1 = NUMBER [6-bit]	
Calculus:	-	
Flags affected:	-	
Bytes:	1	
Description:	Writes p1 to RAM address stack (range: 0 to 63). Commit constant value to ROM routines.  push 22; number of fractional digits for CDC ratios  push 4; Port Number for reference value (PC4)  jsb_ROM_CDC  Note: for advanced users only. Better use rad	
Category:	RAM access	

Page 120ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



rad	Set RAM Address Pointer		
Syntax:	rad p1		
Parameters:	p1 = NUMBER [7-bit]		
Calculus:	-		
Flags affected:	-		
Bytes:	2		
Description:	Set pointer to RAM address (range: 0 to 127) in the RAM address stack.  Note: Internally the RAM is made of 2 pages, 64 words each. The assembler translates the combination of a bitS/C and a push instruction into the rad instruction. rad 15 move r, b will move the content of b the address 15		
Category:	RAM access		

wdr	Clear watch dog timer			
Syntax:	wdr			
Parameters:	-			
Calculus:	-			
Flags affected: -				
Bytes:	5			
Clear watchdog timer. This is a symbolic opcode which is equivalent to the following instruction se bitC 54 bitC 55 bitS 54 bitS 55 bitC 54 The assembler understands also the old resetWDG opcode				
Category:	Miscellaneous			

Page 121 ams Datasheet Document Feedback



shiftL	Shift Left
Syntax:	shiftL p1
Parameters:	p1 = ACCU [a, b]
Calculus:	p1:p1<<1
Flags affected:	SZ
Bytes:	1
Description:	Shift p1 left> shift p1 register to the left, fill LSB with 0, MSB is placed in carry register
Category:	Shift and rotate

shiftR	Shift Right		
Syntax:	shiftR p1		
Parameters:	p1 = ACCU [a, b]		
Calculus:	p1: p1>> 1		
Flags affected:	SZ		
Bytes:	1		
Description:	Signed shift right of p1> shift p1 right, MSB is duplicated according to whether the number is positive or negative		
Category:	Shift and rotate		

Page 122ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



sign	Sign		
Syntax:	sign p1		
Parameters:	p1 = ACCU [a,b]		
Calculus:	If SF = 0 => p1 :  p1 , SF : S(p1) If SF = 1 => p1 : -  p1 , SF : S(p1)		
Flags affected:	S Z SF		
Bytes:	1		
Description:	The intention of this opcode is to take the absolute value of one parameter before multiplication or division and to restore the sign after this operation.  Assuming the Signum flag is zero, the absolute value of accumulator is taken and the sign from accumulator is stored to SF. At the second time this opcode is used the sign to p1 will be restored from SF  Zero is assumed to be positive.		
Category:	Simple arithmetic		

stop	Stop
Syntax:	stop
Parameters:	-
Calculus:	-
Flags affected:	-
Bytes:	1
Description:	Stop of the PCAP-Controller. The clock generator is stopped, the PCAP-Controller go to standby. A restart can be achieved by an external event like 'watchdog timer', 'external switch' or 'new capacitive measurement results'. Usually this opcode is the last command in the assembler listing.
Category:	Miscellaneous

ams DatasheetPage 123[v1-03] 2018-Apr-04Document Feedback



sub	Subtraction		
Syntax:	sub p1,p2		
Parameters:	p1 = ACCU [a,b,r] p2 = ACCU [a,b,r] p1 != p2		
Calculus:	p1: p1 – p2		
Flags affected:	COSZ		
Bytes:	1		
Description:	Subtraction of 2 registers. The following instructions are not allowed: sub a,a. sub b,b. sub r,r		
Category:	Simple arithmetic		

xor	Bitwise XOR		
Syntax:	xor p1,p2		
Parameters:	p1 = ACCU [a,b,r] p2 = ACCU [a,b,r] p1 != p2		
Calculus:	p1:p1 ^ p2		
Flags affected:	COSZ		
Bytes:	1		
Description:	Bitwise XOR (antivalence)		
Category:	Bitwise operation		

Page 124ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



#### **Instruction Details**

#### **Pointer**

```
; Copying the Cratio results to the persistent bank in RAM
  load b, 6
  load a, __sub_cdc_C0_Ratio_temp
  rad DPTR1
  move r, a
  load a, C0_Ratio_RAM
  rad DPTR0
  move r, a
 jsb
rad _at_DPTR0 to rad _at_DPTR3 are special instructions for indirect addressing. _at_DPTR0 to _at_DPTR3 are special
RAM addresses 284 and 287 that have been defined in the firmware.
RAM addresses 105 to 108 are used as data pointers, named DPTR0 to DTPTR3.
By means of
rad
       DPTR0
move r, a
an address is loaded into DPTR0. With
        _at_DPTR0
rad
the address in DPTR0 is loaded.
Example 1: copy sequentially RAM-content from one address-space to another
Load
        a, C0_ratio
        DPTR1
rad
move r, a
load
       a, RESO
       DPTR0
rad
move r, a
load
        b, 8
        __ROM_dma__ ; call ROM routine
jsb
Example 2: Copying the Rratio results to the persistent bank into RAM
 rad
       4
        rad
                rad_stack_6b
        move b, r
                a, __sub_rdc_R0_Ratio_temp; Source for copy
        load
        DPTR1
  rad
  move r, a
  rad
        R0_Ratio_RAM
                               ; Destination for copy
        rad
                rad_stack_6b
        move
                a, r
      DPTR0
  rad
  move r, a
  jsb
                _ROM_dma__
```

ams Datasheet Page 125 **Document Feedback** 



#### Transfer Constants with Push and Pop

```
Call of a subroutine:
push FPP_CRATIO
                        ; Stack - 1 ---> Number of fpp in the result
push C REF PORT NUMBER; Stack - 0 ---> Reference Port Number
                       ; Calling ROM routine for Ratio calculation
      ROM_cdc__
ROM cdc :
bitS PAGESEL_OUT
rad rad_stack_6b; (Stack - 0) contains Reference Port Number
move b, r
pop
rad __sub_cdc_RefPort
move r, b
                         ; Temporarily saving the Reference Port Number in RAM
pop
pop
rad rad_stack_6b; (Stack - 1) contains number of fractional digits in the
result (cdc_fpp)
move b, r
                        ; B = The number of fractional digits , Result_fpp
```

#### mult

The instruction "mult" is just a single multiplication step. To do a complete 32-bit multiplication this instruction has to be done 32 times. The multiplicands are in accumulators b and r. Every step takes the lowest bit of b. If it is one, r is added to accumulator a, else nothing is added. Thereafter a and b are shifted right. The lowest bit of a becomes the highest bit of b. Before the first step of the multiplication, a has to be cleared. The final result is spread over both accumulators a and b.

The use of mult is simplified by using the ROM routines mult\_ 01 to mult 32.

In many cases it will not be necessary to do the full 32 multiplication steps but much fewer. The necessary number of steps is given by the number of significant bits of b and also the necessary significant number of bits of the result.

But, if the multiplication steps are less than 32, the result might be spread between accumulators a and b. Doing an appropriate right shift of the multiplicand in r, and the appropriate number of multiplication steps, it is possible to ensure that the result is either fully in a or in b.

Page 126
Document Feedback
[v1-03] 2018-Apr-04



#### Handover of Constants by Push & Pop

A simple method to hand over constants with a value 0 to 63 is using push & pop instructions. The following shows an example for calling a subroutine.

#### Subroutine call:

```
push
        FPP_CRATIO;
                         Stack - 1 -> Number of fpp in the result
        C_REF_PORT_NUMBER; Stack - 0 -> Reference Port Number
push
jsb
                         Calling ROM routine for Ratio calculation
        _ROM_cdc__;
_ROM_cdc__:
        rad_stack_6b; (Stack - 0) contains Reference Port Number
        b, r
move
pop
rad
         __sub_cdc_RefPort
move
        r, b;
                 Temporarily saving the Reference Port Number in RAM
pop
pop
        rad_stack_6b;(Stack - 1) contains number of fractional digits in the result (cdc_fpp)
rad
move b,r; B = The number of fractional digits, Result_fpp
```

#### div

The instruction "div" is, like the multiplication, just a single step of a complete division. The necessary number of steps for a complete division depends on the accuracy of the result. The dividend is in accumulator a, the divisor is in accumulator r. Every division step contains following actions:

- leftshift b
- compare a and r. If a is bigger or equal to r then r is subtracted from a and One is added to b
- leftshift a

Start Conditions: 0 < a < 2\*r, b = 0

Again, multiple division steps are implemented in ROM library to be easily used by customers, calling div\_01 to div\_32. A call of function e.g. div\_24 out of this library will do a sequence of 24 division steps. The result is found in b, the remainder in a.

With N division steps the result in b:  $(a/r)+2^{(N-1)}$ , a: remainder\*2<sup>N</sup>.

ams Datasheet Page 127 **Document Feedback** 



#### Example 1: a = 2, r = 6, Integer division

Figure 129:

**Example: Division 2/6** 

Steps	a = 2	b	r = 6	
	000000000010	000000	00110	a < r, leftshift b, a
1	000000000100	000000	00110	a < r, leftshift b, a
2	000000001000	000000	00110	leftshift b, a >= r: a-=r, b+=1, leftshift a
3	000000000100	000001	00110	a < r, leftshift b, a
4	000000001000	000010	00110	leftshift b, a >= r: a-=r, b+=1, leftshift a
5	000000000100	000101	00110	

Quotient =  $b * 2^{(1-steps)} = 0.3125$ , Remainder =  $a * 2^{(-steps)} = 4 * 2^{-5} = 0.125$ 

The following two, more complex examples show a nice advantage of division over multiplication: The resolution in bit is directly given by the number of division steps. With this knowledge, assembly programs can be written very effectively. It is easy to use only the number of division steps that is necessary.

Example 2: A = 8.75, R = 7.1875, Fractional number division, A & R with 4 fractional digits each.

$$8.75/7.1875 = a*2^{expA} / r*2^{expR} = a*2^{-4} / r*2^{-4}$$

Figure 130:

Example: Division 8.75/7.1875

Steps	a = 140	b	r = 115	
	1000 1100	0000 0000	0111 0011	leftshift b, a >= r: a-=r, b+=1, leftshift a
1	0011 0010	0000 0001	0111 0011	a < r, leftshift b, a
2	0110 0100	0000 0010	0111 0011	a < r, leftshift b, a
3	1100 1000	0000 0100	0111 0011	leftshift b, a >= r: a-=r, b+=1, leftshift a
4	1010 1010	0000 1001	0111 0011	leftshift b, a >= r: a-=r, b+=1, leftshift a
5	0110 1110	0001 0011	0111 0011	a < r, leftshift b, a
6	1101 1100	0010 0110	0111 0011	leftshift b, a >= r: a-=r, b+=1, leftshift a
7	1101 0010	0100 1101	0111 0011	leftshift b, a >= r: a-=r, b+=1, leftshift a
8	1011 1110	1001 1011	0111 0011	

Page 128ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



Quotient = 
$$b * 2^{(1+expA-expR-steps)} = 155 * 2^{(1-4+4-8)} = 1.2109$$

Remainder = 
$$a*2^{(-steps-expR)} = 190*2^{-12} = 0.0463$$

Example 3: A = 20, R = 1.2, Fractional number division, R < A. A and R are shifted to left to display the fractional digits of R. Further, R has to be shifted to the left till it is bigger than A/2.

$$20/1.2 = a*2^{expA} / r*2^{expR} = a*2^{-4} / r*2^{-8}$$

Figure 131: Example 3: Division 20/1.2

Steps	a = 320	b	r = 307	
	0001 0100 0000	0000 0000 0000	0001 0011 0011	leftshift b, a >= r: a-=r, b+=1, leftshift a
1	0000 0001 1010	0000 0000 0001	0001 0011 0011	a < r, leftshift b, a
2	0000 0011 0100	0000 0000 0010	0001 0011 0011	a < r, leftshift b, a
3	0000 0110 1000	0000 0000 0100	0001 0011 0011	a < r, leftshift b, a
4	0000 1101 0000	0000 0000 1000	0001 0011 0011	a < r, leftshift b, a
5	0001 1010 0000	0000 0001 0000	0001 0011 0011	leftshift b, a >= r: a-=r, b+=1, leftshift a
6	0000 1101 1010	0000 0010 0001	0001 0011 0011	a < r, leftshift b, a
7	0001 1011 0100	0000 0100 0010	0001 0011 0011	leftshift b, a >= r: a-=r, b+=1, leftshift a
8	0001 0000 0010	0000 1000 0101	0001 0011 0011	a < r, leftshift b, a
9	0010 0000 0100	0001 0000 1010	0001 0011 0011	leftshift b, a >= r: a-=r, b+=1, leftshift a
10	0001 1010 0010	0010 0001 0101	0001 0011 0011	leftshift b, a >= r: a-=r, b+=1, leftshift a
11	0000 1101 1110	0100 0010 1011	0001 0011 0011	a < r, leftshift b, a
12	0001 1011 1100	1000 0101 0110	0001 0011 0011	

ams DatasheetPage 129[v1-03] 2018-Apr-04Document Feedback



Quotient =  $b * 2^{(1+expA-expR-steps)} = 2134 * 2^{(1-4+8-12)} = 16.6719$ 

The remainder is, as always, smaller than the denominator divided by 2steps e.g. in the present case, remainder  $< 1.2 / 2^{12}$  = 0,0003

Steps = 1 + expA - expB - expRes

#### **ROM Routines**

The following routines are implemented as ROM code:

Figure 132: ROM Routines

ROM Routine	Address	ROM Routine	Address
_ROM_Version	1024	_ROM_median	1804
_ROM_tdc_dispatch	1029	_ROM_rdc	1936
_ROM_cdc_cycle	1047	_ROM_rdc_inverse	1962
_ROM_rdc_cycle	1068	_ROM_cdc	2021
_ROM_cdc_initialize	1086		
_ROM_rdc_initialize	1111		
shiftR_B_32 to _00	1140		
shiftL_B_32 to _00	1173		
shiftR_A_32 to _00	1206	_ROM_memory_rd_a_32b toROM_memory_wr_08b	2470
shiftL_A_32 to _00	1239	_ROM_memory_store	2650
mult_32 to _00	1272	_ROM_memory_recall	2673
div_33 to _00	1305	_ROM_2PT_Calibration	2696
_ROM_div_variable	1339	_ROM_polynomial_3rd_degree	2825
_ROM_mult_variable	1396	sub_polynomial_load_coeffs	2874
_ROM_shift_a_variable	1452	_ROM_polynomial_4th_degree	2923
_ROM_shift_b_variable	1478	_ROM_pulse	2969
_ROM_dma	1504	_ROM_pulse_loaded_cal_vals	2990
_ROM_In	1520	_ROM_NVblock_copy_32b_to _ROM_NVblock_copy_08b_	3138
_ROM_log10	1547	_ROM_capacitance_polynomial	3236
_ROM_ld	1574	_ROM_capacitance_polynomial_4d	3437
_ROM_signed24_to_signed32	1648		

Page 130ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



# Handover parameters and RAM addresses for ROM routines

Figure 133: Parameters and RAM for Key ROM Routines

ROM Routine	Parameter	RAM Address
_ROM_cdc	sub_cdc_C0_Ratio_temp to sub_cdc_C5_Ratio_temp	58 63
_ROM_rdc _ROM_rdc_inverse	sub_rdc_R0_Ratio_temp to sub_rdc_R3_Ratio_temp	64 67
_ROM_mult_variable	sub_standard_multiplier	82
_ROM_div_variable	sub_standard_divisor	82

ams Datasheet Page 131 [v1-03] 2018-Apr-04 Document Feedback



In the following we give a detailed description of the ROM routines.

Hint: it is recommended to always include the following files:

#device PCap04v1
#include <pcap\_standard.h>
#include <PCap04\_ROM\_addresses\_standard.h>

to declare addresses to ROM routines.

\_ROM\_Version\_\_

Function:	This routine gives back the 8-bit version number of the ROM in the chip
Input parameters:	-
Output/Return value:	A-Accu : ROM version
Prerequisites	None
Dependency on other header files	None
Function call	jsb _ROM_version; address 0x400
Temporary memory usage	-
Example:	jsb _ROM_Version rad RES5 move r, a

\_ROM\_tdc\_dispatch\_\_

Function:	TDC library, to be called at the very beginning. Calls subroutines _ROM_cdc_ cycle or _ROM_rdc-cylcle and _tdc_awake, depending on the trigger
Input parameters:	-
Output/Return value:	-
Prerequisites	None
Dependency on other header files	None
Function call	jsb _ROM_tdc_dispatch
Temporary memory usage	-
Example:	org 0SOP: ; Start of program jsb _ROM_tdc_dispatch

Page 132ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



# \_ROM\_cdc\_cycle\_

Function:	<ol> <li>Calculates the Start-Stop difference in the TDC values of the capacitance measurement ports and accumulates this in the measurement value RAM register (depending on the C_ADD_PTR) respective to the port being measured.</li> <li>If the calculated discharge time is too large, then the result is replaced with 0xFFFFFFFF thus indicating overflow.</li> <li>The DSP stops if there are more measurements to be done. In case of a last measurement, the DSP returns to where the ROM routine was called from continues to execute the post processing firmware, if any.</li> </ol>
Input parameters:	-
Output/Return value:	The CDC discharge time measurement value is available in the respective RAM (88 - 95)
Prerequisites	This function has to be called after a measurement cycle at every capacitive port.
Dependency on other header files	None
Function call	<pre>push <msb(ram_startaddress)> push <lsb(ram startaddress)=""> jsb _ROM_cdc_cycle</lsb(ram></msb(ram_startaddress)></pre>
Temporary memory usage	DPTR0 is overwritten in this routine.
Example:	push 1 ; bit6 of starting address push M0; bit 50 of starting address jsb_ROM_cdc_cycle (not recommended, use_ROM_tdc_dispatch instead)

ams DatasheetPage 133[v1-03] 2018-Apr-04Document Feedback



## \_ROM\_Rdc\_cycle\_\_

Function:	<ol> <li>Calculates the Start-Stop difference in the TDC values of the temperature measurement ports and accumulates this in the measurement value RAM register (depending on the R_ADD_PTR) respective to the port being measured.</li> <li>If the calculated discharge time is too large, then the result is replaced with 0xFFFFFFF thus indicating overflow.</li> <li>If the end of an RDC measurement triggered the DSP, then this ROM routine call will stop the DSP after doing the above tasks. Else, the DSP returns to where the ROM routine was called and continues to execute the firmware.</li> </ol>
Input parameters:	-
Output/Return value:	The RDC discharge time measurement value is available in the respective RAM (84 – 87)
Prerequisites	This function has to be called after a measurement cycle at every resistive port.
Dependency on other header files	None
Function call	<pre>push <msb(ram_startaddress)> push <lsb(ram startaddress)=""> jsb _ROM_rdc_cycle</lsb(ram></msb(ram_startaddress)></pre>
Temporary memory usage	DPTR0 is overwritten in this routine.
Example:	push 1 ; bit6 of starting address push TM0; bit 50 of starting address jsb _ROM_rdc_cycle (not recommended, use _ROM_tdc_dispatch instead)

Page 134ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



### \_ROM\_cdc\_initialize\_\_

Function:	This ROM routine clears all the measurement value RAM registers, Addresses 88-95 to 0.
Input parameters:	The starting address of the RAM registers (88) which are to be cleared, is to be pushed into the RAM address stack before calling this subroutine.
Output/Return value:	-
Prerequisites	-
Dependency on other header files	None
Function call	<pre>push <msb(ram_startaddress)> push <lsb(ram startaddress)=""> jsb _ROM_cdc_initialize</lsb(ram></msb(ram_startaddress)></pre>
Temporary memory usage	The addresses DPTR0 and _at_DPTR0 are overwritten in this ROM routine.
Example:	push 1 ; bit6 of starting address push M0; bit 50 of starting address jsb_ROM_cdc_initialize

## \_ROM\_rdc\_initialize\_\_

Function:	This ROM routine clears all the measurement value RAM registers, Addresses 84-87 to 0.
Input parameters:	The starting address of the RAM registers (84) which are to be cleared, is to be pushed into the RAM address stack before calling this subroutine.
Output/Return value:	-
Prerequisites	None
Dependency on other header files	None
Function call	push <msb(ram_startaddress)> push <lsb(ram startaddress)=""> jsb_ROM_rdc_initialize</lsb(ram></msb(ram_startaddress)>
Temporary memory usage	The addresses DPTR0 and _at_DPTR0 are overwritten in this ROM routine.
Example:	push 1 ; bit6 of starting address push TM0; bit 50 of starting address jsb_ROM_rdc_initialize

ams DatasheetPage 135[v1-03] 2018-Apr-04Document Feedback



## shiftL\_A\_xx; shiftR\_A\_xx; shiftL\_B\_xx; shiftR\_B\_xx

Function:	Function to call a fixed number xx of shift steps of the A-Accu or B-Accu to the left or right
Input parameters:	A-Accu or B-Accu : Value to shift xx times
Output/Return value:	shiftL_A_01
Prerequisites	None
Dependency on other header files	None
Function call	jsb shiftL_A_01
	jsb shiftL_A_32
	jsb shiftL_B_01 jsb shiftR_B_01
	jsb shiftL_B_32
Temporary memory usage	
Example:	load b, dp_const_m jsb shiftL_B_08

#### $mult\_xx$

Function:	Function to call a variable no of multiplication steps
Input parameters:	B-Accu : Multiplier 1 R-Accu : Multiplier 2
Output/Return value:	A-Accu : Result of multiplication
Prerequisites	A-Accu: 0 B >= 0 R >= 0
Dependency on other header files	None
Function call	jsb mult_01 jsb mult_32
Temporary memory usage	
Example:	sign b; Store sign of multiplier b; take absolute value from b clear a radsub_standard_multiplier jsb mult_15; a2 * theta in A-Akku sign a; Restoring sign of the multiplier to the result

Page 136ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



#### div\_xx

Function:	div_00 to div_33: Function to call a fixed no of division steps
Input parameters:	A-Accu : Dividend r : Divisor
Output/Return value:	B-Accu : Dividend / divisor
Prerequisites	B-Accu : 0 $0 < a' < 2*'r'$ respectively result b needs to be $0 < b < 2$
Dependency on other header files	None
Function call	jsb div_xx
Temporary memory usage	
Example:	rad M_internal_ref move b, r shiftL b shiftL b; b:b+4, to make sure dividend > 2*a rad 0 move r, b rad M0 move a, r; a = M0 clear b rad 0; r = M_internal_ref jsb div_29; b = a/r = M0/M_internal_ref

ams Datasheet [v1-03] 2018-Apr-04



# \_ROM\_div\_variable\_\_

Function:	Function to call a variable no of division steps
Input parameters:	B-Accu: No of division steps A-Accu: Dividend arguments - 0: Divisor (RAM-address 82)
Output/Return value:	B-Accu : Dividend / divisor
Prerequisites	0<'a'<2*'r' respectively result b needs to be 0 < b < 2
Dependency on other header files	None
Function call	jsb _ROM_div_variable
Temporary memory usage	
Example:	load a, 3; divisor = 3 rad _arguments; hand over via ramaddress 82 move r, a load a, 4; dividend = 4 load b, 23; 23 division steps jsb _ROM_div_variable; rad RES00 move r, b ; B: 0x555555; B: 4/3 = 1.333333 (fpp22)

Page 138ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



### \_ROM\_mult\_variable\_\_

Function:	Function to call a variable no of multiplication steps
Input parameters:	B-Accu : Multiplier 1 A-Accu : Number of multiplication steps arguments - 0 : Multiplier 2 (RAM-address 82)
Output/Return value:	A-Accu : Result of multiplication
Prerequisites	Multiplier 1 > 0 Multiplier 2 > 0
Dependency on other header files	None
Function call	jsb _ROM_mult_variable
Temporary memory usage	
Example:	load b, 3; multiplier 1 = 3 rad _arguments; hand over via ramaddress 82 move r, b load b, 4; multiplier 2 = 4 load a, 32; 32 muliplication steps jsb _ROM_mult_variable; rad RES00 move r, b ; B: 12; B: 4*3 = 12 (fpp22)



### \_ROM\_shift\_a\_variable\_\_

Function:	Function to call a variable no of	shift A-Accu steps
Input parameters:	A-Accu: Value to shift B-Accu: Number of shift sto B > 0: Left shift B < 0: Right shift	eps
Output/Return value:	A:A*2^(B)	
Prerequisites	None	
Dependency on other header files	None	
Function call	jsb _ROM_shift_a_variable	
Temporary memory usage		
Example:	move a, r	; a : MyVar; ; set up 4fold right shift

## \_ROM\_shift\_b\_variable\_\_

Function:	Function to call a variable no of shift B-Accu steps
Input parameters:	B-Accu : Value to shift A-Accu : Number of shift steps A > 0 : Left shift A < 0 : Right shift
Output/Return value:	B:B*2^(A)
Prerequisites	None
Dependency on other header files	None
Function call	jsb _ROM_shift_b_variable
Temporary memory usage	
Example:	rad MyVar ; b : MyVar; move b, r load a, 13 ; set up 13fold left shift jsb _ROM_shift_b_variable rad RES00 move r, b

Page 140ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



## \_ROM\_dma\_\_

Function:	"Direct Memory Access" – This routine copies sequential RAM-content from one address-space to another. The number of RAM values to be copied can be specified.
Input parameters:	B-Accu :Number of values to be copied DPTR1 :Source RAM block address DPTR0 :Destination RAM block address
Output/Return value:	The contents, i.e. the specified number of values are copied from the source RAM block to the destination RAM block.
Prerequisites	-
Function call	jsbROM_dma
Temporary memory usage	-
RAM permanently changed?	Yes, the destination RAM block
Example	; Copying the Cratio results to the persistent bank ; in RAM (cellssub_cdc_C0_Ratio_temp tosub_cdc_C0_Ratio_temp +5 into cels C0_Ratio_RAM to C0_Ratio_RAM + 5)  load b, 6  load a,sub_cdc_C0_Ratio_temp  rad DPTR1  move r, a  load a, C0_Ratio_RAM  rad DPTR0  move r, a  jsbROM_dma

ams Datasheet Page 141
[v1-03] 2018-Apr-04 Document Feedback



# \_ROM\_In\_\_, \_ROM\_log10\_\_, \_ROM\_Id\_\_

Function:	Calculation of logarithm log10 (logarithm to base 10) In (logarithm naturalis) Id (logarithm dualis, to base 2) AccuA = Id( AccuA ) for all logarithms, first Id(x) is determined. For log10 and In afterwards the return value is divided by Id(e(1)) or Id(10) formula for Id(x) of http://de.wikipedia.org/wiki/Logarithmus#Nat.C3.BCrlicher_Logarithmus
Input parameters:	A-Accu: Containing parameter for logarithm dualis with 10fpp
Output/Return value:	A-Accu : Signed 16bit Value
Prerequisites	
Function call	jsbROM_ld jsbROM_ln jsbROM_log10
Temporary memory usage	temporary_variables 3 totemporary_variables
RAM permanently changed?	
Example	load a, 0xA01; A: 2.500977 (=2561*2^-10) jsbROM_ld rad RES00 move r, a; A: 1.322492 (0x1528E*2^-16)

## \_ROM\_signed24\_to\_signed32\_\_

Function:	Type cast from 24bit signed to 32bit signed. This function is to cast a 24bit signed value e to a 32 bit signed value.
Input parameters:	Accu B: Signed 24 bit value
Output/Return value:	Accu B : Signed 32bit value
Prerequisites	None
Dependency on other header files	None
Function call	_ROM_signed24_to_signed32
Temporary memory usage	1
Example:	jsb _ROM_signed24_to_signed32

Page 142ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



## \_ROM\_median\_\_

Function:	Median-filter: this is a quasi-median-filter. The depth of filter is defined by arguments via stack. Each new Value (X) will be compared with the current median value. Is the new value smaller or equal to the median value the last value at the list will be replaced by X. Otherwise the first value at the list will be replaced by X. Afterwards the complete list is sorted. The value at the very middle of the list is returned as new median.
Input parameters:	B-Accu : Filter input (and output) Stack - 2 : Start address of filter memory Stack - 1 : Middle section of filter memory Stack - 0 : Last address of filter memory The filter order is defined by last address - start address. The necessary memory section has to be reserved for and must not be used otherwise
Output/Return value:	B-Accu : Filter output (and input)
Prerequisites	None
Dependency on other header files	None
Function call	jsb _ROM_median
Temporary memory usage	temporary_variables 4 totemporary_variables FILTER_START to FILTER_STOP
Example:	CONST FILTER_ORDER 5 CONST FILTER_START 12 CONST FILTER_MIDDLE 12 + (FILTER_ORDER/2) CONST FILTER_STOP 12 + FILTER_ORER rad Filter_input_value move b, r push FILTER_START push FILTER_MIDDLE push FILTER_MIDDLE jsb_ROM_median

Page 143 ams Datasheet **Document Feedback** 



## \_ROM\_cdc\_\_

Function:	This routine contains the subroutine to determine the capacitor ratios (or inverse ratios); depending on the measurement scheme and compensation modes
Input parameters:	Stack 1 : CDC_FPP number of fractional digits in the result.  Stack 0 : C_REF_PORT_NUMBER reference port number (0 to 6 for grounded, 0 to 2 for floating).  A-Accu :sub_cdc_gain_corr factor for gain correction, applied on Mi, 8fpp 0 0 : gain corr = 1  else 1+ (A-Accu)  FLAG_CDC_INV (Bit 5) of FLAGREG: 0 : inverse capacitance ration, 1 : capacitance rations
Output/Return value:	The addressessub_cdc_C0_Ratio_temp tosub_cdc_C5_Ratio_temp are updated with relevant capacitance ratios (or inverse ones)
Prerequisites	
Function call	jsb _ROM_cdc
Temporary memory usage	Addresses 58 to 72
Example:	load2exp a, FLAG_CDC_INV not a ; Clearing FLAG_CDC_INV (Bit 5) of FLAGREG rad FLAGREG and r, a  load a, 0x40; default gain_corr 1.25  rad 27 ; Stack - 1> Number of fpp in the result rad 0; Stack - 0 -> Ref. port number  jsb _ROM_cdc; Calling ROM routine for Ratio calculation radsub_cdc_C1_Ratio_temp move a, r; save Ratio from CDC

Page 144ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



### \_ROM\_rdc\_\_; \_ROM\_rdc\_inverse\_\_

Function:	Subroutine to calculate the resistance ratios or inverse ratios for the temperature measurement ports TM0 -> Internal Reference Resistance Port; TM1 -> External Resistance Port, PT0 TM2 -> External Resistance Port, PT1 TM3 -> Internal Sensor Resistance Port			
Input parameters:	Stack 0 : FPP_RRATIO fixed point position of result A-Accu :REF_PORT_NUMBER reference, 0 = internal 1=external			
Output/Return value:	sub_rdc_R0_Ratio_temp TM0/Ref or Ref/TM0sub_rdc_R1_Ratio_temp TM1/Ref or Ref/TM1sub_rdc_R2_Ratio_temp TM2/Ref or Ref/TM2sub_rdc_R3_Ratio_temp TM3/Ref or Ref/TM3			
Prerequisites	None			
Dependency on other header files	#include <memory.h></memory.h>			
Function call	jsb _ROM_rdc jsb _ROM_rdc_inverse			
Temporary memory usage	temporary_variables 8 totemporary_variables			
Example:	load a, 0 ; Reference Port Number = 0  rad 25 ; Number of fpp in the result			

ams DatasheetPage 145[v1-03] 2018-Apr-04Document Feedback



### \_ROM\_memory\_ (read/write volatile memory)

Function:	Functions for memory NVRAM access read functions: * signed/unsinged, 8/16/24/32bit RAM into Accu A or B write functions: * 8/16/24/32 bit (write data from RAM cell mem_data) The address in RAM cell mem_add is automatically incremented with read/write operations.	
Input parameters:	-	
Output/Return value:	Accu-A or Accu-B contains the specified value from the NVRAM	
Prerequisites	None	
Dependency on other header files	#include <memory.h></memory.h>	
Function call	jsb _ROM_memory_rd_a_32b jsb _ROM_memory_rd_a_u24b; jsb _ROM_memory_rd_a_s24b jsb _ROM_memory_rd_a_u16b; jsb _ROM_memory_rd_a_s16b jsb _ROM_memory_rd_a_u08b; jsb _ROM_memory_rd_a_s08b jsb _ROM_memory_rd_b_32b jsb _ROM_memory_rd_b_u24b;  _ROM_memory_wr_32b; _ROM_memory_wr_24bROM_memory_wr_16b; _ROM_memory_wr_08b	
Temporary memory usage		

Page 146ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



```
Example:
                            Single read:
                            load a, <read_mem_add> ; mem_add : <read_mem_add>
                           rad mem_add
                            move r, a
                           jsb _ROM_memory_rd_a_u24b__
                            Single write:
                            load a, MEM_WE; enable memory writing
                                                    ;(disable write protection)
                           rad mem_ctrl
                            move r, a
                           load a, <write_address> ; mem_add : <write_mem_add>
                            rad mem_add
                           move r, a
                           load a, <data to store> ; mem_data : <data to store>
                           rad mem_data
                            move r, a
                           jsb_ROM_memory_wr_32b__
                           ; optional: set write protection
                           load a, MEM_WR_PROTECT
                           rad mem_ctrl
                           move r, a
                            Autoincrement:
                           load a, 900 ; address (decimal) 900
                           rad mem_add
                            move r, a
                           load a, 0x012345; data: 0x012345
                            rad mem_data
                            move r, a
                           jsb_ROM_memory_wr_24b__
                                   ; add 900: 0x45
                                    ; add 901: 0x23
                                    ; add 902: 0x01
                                    ; mem_add after this operation: 903
```

ams Datasheet Page 147
[v1-03] 2018-Apr-04 Document Feedback



### \_ROM\_MEMORY\_RECALL/STORE

Function:	Functions for nonvolatile memory access All nonvolatile accesses are secured by RAM cell mem_ctrl. If a store or a recall should be activated this has to be enabled by dedicated codes to mem_ctrl to prevent such actions by accident.  Store: mem_ctrl: MEM_STORE (0x2d00)  Recall: mem_ctrl: MEM_RECALL (0x5900)	
Input parameters:		
Output/Return value:		
Prerequisites	None	
Dependency on other header files	<memory.h></memory.h>	
Function call	jsb _ROM_memory_store jsb _ROM_memory_recall	
Temporary memory usage		
Example	Store: load a, MEM_STORE rad mem_ctrl move r, a jsb_ROM_memory_store  Recall: load a, MEM_RECALL rad mem_ctrl move r, a jsb_ROM_memory_recall	

Page 148ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



#### \_ROM\_2pt\_calibration

Function:	This function performs a two point calibration with the given set of input values.  The mathematical formula of the function is given below (calculation of xi):  (xi_at_ccp1 - xi_at_ccp2)  xi = (ci - ci_at_ccp1) + xi_at_ccp1  (ci_at_ccp1 - ci_at_ccp2)  The input values, i.e., xi_at_ccp1, xi_at_ccp2, ci_at_ccp1, ci_at_ccp2 are defined in the calibration data		
Input parameters:	A-Accu :  FPP_ci  -  FPP_ccp   FPP_ci : No. of fractional digits in the input capacitance ratio  FPP_ccp : No. of fractional digits in the calibration value of capacitance ratio  DPTR0 : Start address of the RAM containing the constants in 4 consecutive addresses in the following order:  xi_at_ccp1, xi_at_ccp2, ci_at_ccp1, ci_at_ccp2  Stack-0 : RAM address of Input Capacitance Ratio ci  NOTE: It is a must that ALL the 4 calibration values have the same fpp !!!		
Output/Return value:	A-Accu :xi with FPP_ccp fractional digits		
Prerequisites	All the four calibration values must have the same fpp.		
Function call	_ROM_2pt_calibration		
Temporary memory usage	temporary_variables 8 totemporary_variables		
	load a, FPP_difference; A Accu : ( FPP_ci  -  FPP_ccp )		
	rad xi_at_ccp1; Start address containing the list of ; calibration values		
	move b, r		
	rad DPTR0 ; DPTR0 now contains starting address ; of the calibration values		
	move r, b		
	rad C1_ratio		
	; Inputs :		
Example:	; A Accu : (FPP_ci - FPP_ccp)		
	; DPTR0 : Start address of the Calibration values in RAM		
	; Stack-0 : RAM address of Input Capacitance		
	Ratio ci		
	; Output :		
	; A Accu : xi with FPP_ccp fractional digits		
	jsb _ROM_2PT_Calibration		
	rad 2pt_result; Storing the returned value in RAM		
	move r, a		

ams DatasheetPage 149[v1-03] 2018-Apr-04Document Feedback



### \_ROM\_polynomial\_3rd\_degree

Function:	This function calculates the third degree polynomial for a given input value, with known coefficients. The mathematical formula of the function is given below: $an = ((cc3n/xi + cc2n)/xi + cc1n)/xi + cc0n$ where cc3n, cc2n, cc1n and cc0n are the coefficients of the third degree polynomial. xi is the given input value which can be a capacitance or resistance ratio for example. This can be used for capacitance and resistance polynomials of this form.		
Input parameters:	DPTR0: start address of the memory containing the following : cc3n: 3rd degree coefficient cn_div3n: division steps for cc3n cc2n: 2nd degree coefficient cn_div2n: division steps for cc2n cc1n: 1st degree coefficient cn_div1n: division steps for cc1n cc0n: constant coefficient A-Accu: Input Capacitance or Resistance Ratio (or Inverse Ratio)		
Output/Return value:	A-Accu: Result of the polynomial		
Prerequisites	None		
Dependency on other header files	None		
Function call	jsb _ROM_polynomial_3rd_degree		
Temporary memory usage	temporary_variables		
Example:	temporary_variables  The following example calculated temperature using the temperature polynomial  rad Ratio_temp; Resistance ratio  move a, r; A-Akku contains R_ratio  load b, cc3n_address; Start address containing the list		

Page 150ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



### \_ROM\_polynomial\_4th\_degree

Function:	This function calculates the third degree polynomial for a given input value, with known coefficients. The mathematical formula of the function is given below: $an = (((cc4n / xi + cc3n)/xi + cc2n)/xi + cc1n)/xi + cc0n \\ where cc4n, cc3n, cc2n, cc1n and cc0n are the coefficients of the third degree polynomial. xi is the given input value which can be a capacitance or resistance ratio for example. This can be used for capacitance and resistance polynomials of this form.$		
Input parameters:	DPTR0: start address of the memory containing the following: cc4n: 4th degree coefficient cn_div4n: division steps for cc4n cc3n: 3rd degree coefficient cn_div3n: division steps for cc3n cc2n: 2nd degree coefficient cn_div2n: division steps for cc2n cc1n: 1st degree coefficient cn_div1n: division steps for cc1n cc0n: constant coefficient A-Accu: Input Capacitance or Resistance Ratio (or Inverse Ratio)		
Output/Return value:	A-Accu: Result of the polynomial		
Prerequisites	None		
Dependency on other header files	None		
Function call	jsb _ROM_polynomial_4th_degree		
Temporary memory usage	temporary_variables3 totemporary_variables		
	The following example calculated temperature using the temperature polynomial		
	rad Ratio_temp ; Resistance ratio		
	move a, r ; A-Akku contains R_ratio		
	load b, cc4n_address; Start address containing the list; of calibration values		
Example:	rad DPTR0 ; DPTR0 now contains starting address		
Example.	move r, b ; of the coefficient and steps list		
	; Input : DPTR0: start address of the list memory		
	; A-Akku: Input Capacitance or Resistance Ratio		
	; (or Inverse Ratio)		
	jsb _ROM_polynomial_4th_degree; A = theta		
	rad theta		
	move r, a		

ams DatasheetPage 151[v1-03] 2018-Apr-04Document Feedback



### \_ROM\_pulse\_\_

Function:	This function determines the pulse output, given two input co-ordinates (result 1, pulse_out_1) and (result_2, pulse_out_2) and the current result_n. The input coordinates are copied from the NVRAM, given the address and must fulfill the pre-requisite.  The result_n, result_1 and result_2 can be the result from the capacitance measurement (like Humidity, Pressure etc) or the temperature measurement (theta). The "result_n" is converted into "Pulse_out" which can then be assigned.		
	(theta). The "result_n" is converted into "Pulse_out" which can then be assigned to PULSE0 or PULSE1 output.  The mathematical formula of the function is given below:		
	Pulse_out = ( pulse_out_1 - pulse_out_2 ) * (result_n - result_1) + (pulse_out_1) ( result_1 - result_2 )		
	Additionally Pulse_out is limited to the range between pulse_out_min and pulse_out_max.  The constants pulse_out_1, pulse_out_2, result_1, result_2, pulse_out_min and pulse_out_min are defined in the calibration memoryand have to be copied to the RAM before calling this function.  !!! NOTE: result_n and result_1 must have the same format.		
Input parameters:	A-Accu: Value of result_n B-Accu: 10-bit NVRAM Start Address containing the list of calibration values		
Output/Return value:	A-Accu: Pulse_out value as integer		
Prerequisites	result_1: 4 bytes (Same fpp as result_2 and result_n) result_2: 4 bytes (Same fpp as result_1 and result_n) pulse_out_1: 2 bytes (Integer) pulse_out_2: 2 bytes (Integer) pulse_out_max: 2 bytes (Integer) pulse_out_min: 2 bytes (Integer)		
Dependency on other header files	-		
Function call	jsb _ROM_pulse		
Temporary memory usage	temporary_variables 8 totemporary_variables		
Example:	rad Z_result ; Value to be given as pulse output move a, r		
	load b, result1_NVaddress; Starting address in NVRAM ; containing constants		
	; Input: B-Accu: 10 bit NVRAM Address ; A-Accu: Value of result_n jsb _ROM_pulse; Output in A-Accu is an integer rad PULSEO; Pulse output on PULSEO move r, a		

Page 152ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



### \_ROM\_pulse\_loaded\_cal\_vals

Function:	This ROM routine has the same functionality as the _ROM_pulse routine. Only difference is that the constant values have to be copied from the calibration NVRAM memory to the RAM by the firmware, before this routine is called.			
Input parameters:	A-Akku: Value of result_n DPTR0: Start address of the RAM containing the constant values in 6 consecutive addresses in the following order: result_1 (Same fpp as result_2 and result_n) result_2 Same fpp as result_1 and result_n) pulse_out_1 (Integer) pulse_out_2 (Integer) pulse_out_max (Integer) pulse_out_min (Integer)			
Output/Return value:	A-Akku: Pulse_out value as integer			
Prerequisites	The coordinate values must be copied from the NVRAM to a RAM space by the firmware.			
Dependency on other header files	-			
Function call	jsb _ROM_ pulse_loaded_cal_vals			
Temporary memory usage	temporary_variables 8 totemporary_variables			
	rad Z_result; Value to be given as pulse output move a, r  load b, result1_RAMaddress; Starting address in RAM ; containing constants			
Example:	<pre>rad DPTR0 move r, b ; Input : DPTR0: Starting RAM Address ; A-Accu : Value of result_n jsb    _ROM_pulse_loaded_cal_vals</pre>			

ams DatasheetPage 153[v1-03] 2018-Apr-04Document Feedback



### \_ROM\_NVblock\_copy\_\_

Function:	Copy a block of data from NVRAM to RAM		
Input parameters:	DPTR0: Start address of the RAM B-Accu: Starting address of the NVRAM A-Accu: Count of the number of values to be copied SIGNED_VALUE_NV in FLAGREG must be set (for reading signed values)or cleared (for reading unsigned values) - relevant only for 24/16/08 bit values		
Output/Return value:	RAM contains a copy of the specified number of values from the NVRAM		
Prerequisites	None		
Dependency on other header files	None		
Function call	jsb_ROM_NVblock_copy_32b_; jsb_ROM_NVblock_copy_24b_; jsb_ROM_NVblock_copy_16b_; jsb_ROM_NVblock_copy_08b_;		
Temporary memory usage	temporary_variables		
Example:	temporary_variables  This example copies 4 values, 32 bits each from the NVRAM to the RAM address starting at xi_at_ccp1:  load		

Page 154ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



### \_ROM\_capacitance\_polynomial

Function:	This function calculates the value of the capacitance polynomial,		
	Z_result = (((a2 * theta)+ a1) * theta )+a0		
	given the capacitance ratio or inverse (Cratio) and temperature (theta). a2, a1 and a0 are 3rd degree polynomials of the Cratio value		
	an = $((cc3n / xi + cc2n)/xi + cc1n)/xi + cc0n$ where cc3n cc0n are the coefficients of the third degree polynomial in the NVRAM		
	NVRAM		
Input parameters:	DPTR0: Address of the capacitance ratio or inverse(Cratio) DPTR1: Address of the temperature (theta)		
	B-Accu Starting address of coefficient values in NVRAM		
	Arg_6: Z_min		
	Arg_7 : Z_max FLAGREG, Bit 7 (LIN_3BYTE_COEFF) :		
	1 -> 3 bytes in each of the coefficients		
	0 -> 4 bytes in each of the coefficients		
Output/Return value:	A-Accu: Z_result = result of the polynomial		
Prerequisites	-		
Function call	_ROM_capacitance_polynomial		
Temporary memory usage	temporary_variables 8 totemporary_variables Arg_0 to Arg_7		
Example:	; Copying Z_min and Z_max to Arg_6 and Arg_7		
	load a, Arg_6 ; DPTR0 < starting argument ; memory address (RAM)		
	rad DPTR0		
	move r, a		
	load2exp a, 1 ; Count = 2		
	load2exp a, 1 ; Count = 2 load b, NV_Cal_vals; Starting address of Calibration ; values in NVRAM		
	load2exp a, 1 ; Count = 2 load b, NV_Cal_vals; Starting address of Calibration; values in NVRAM jsb _ROM_NVblock_copy_32b_; Subroutine to copy Z_min; and Z_max values		
	load2exp a, 1 ; Count = 2 load b, NV_Cal_vals; Starting address of Calibration; values in NVRAM jsb _ROM_NVblock_copy_32b_; Subroutine to copy Z_min; and Z_max values		
	load2exp a, 1 ; Count = 2 load b, NV_Cal_vals; Starting address of Calibration; values in NVRAM jsb _ROM_NVblock_copy_32b_; Subroutine to copy Z_min; and Z_max values		
	load2exp a, 1 ; Count = 2 load b, NV_Cal_vals; Starting address of Calibration ; values in NVRAM jsb _ROM_NVblock_copy_32b_; Subroutine to copy Z_min ; and Z_max values from NVRAM -> argument RAM ;		
	load2exp a, 1 ; Count = 2 load b, NV_Cal_vals; Starting address of Calibration; values in NVRAM jsb _ROM_NVblock_copy_32b_; Subroutine to copy Z_min; and Z_max values from NVRAM -> argument RAM ;		
	load2exp a, 1 ; Count = 2 load b, NV_Cal_vals; Starting address of Calibration; values in NVRAM jsb _ROM_NVblock_copy_32b_; Subroutine to copy Z_min; and Z_max values from NVRAM -> argument RAM  ; load a, C1_ratio  rad DPTR0 ; DPTR0: Address of the capacitance ; ratio or inverse(Cratio) move r, a load a, theta ; DPTR1: Address of the temperature		
	load2exp a, 1 ; Count = 2 load b, NV_Cal_vals; Starting address of Calibration; values in NVRAM jsb _ROM_NVblock_copy_32b_; Subroutine to copy Z_min; and Z_max values from NVRAM -> argument RAM  ; load a, C1_ratio  rad DPTR0 ; DPTR0: Address of the capacitance ; ratio or inverse(Cratio) move r, a load a, theta ; DPTR1: Address of the temperature rad DPTR1		
	load2exp a, 1 ; Count = 2 load b, NV_Cal_vals; Starting address of Calibration; values in NVRAM jsb _ROM_NVblock_copy_32b_; Subroutine to copy Z_min; and Z_max values from NVRAM -> argument RAM  ; load a, C1_ratio  rad DPTR0 ; DPTR0: Address of the capacitance ; ratio or inverse(Cratio) move r, a load a, theta ; DPTR1: Address of the temperature rad DPTR1 move r, a		
	load2exp a, 1 ; Count = 2 load b, NV_Cal_vals; Starting address of Calibration; values in NVRAM jsb _ROM_NVblock_copy_32b_; Subroutine to copy Z_min; and Z_max values from NVRAM -> argument RAM  ; load a, C1_ratio  rad DPTR0 ; DPTR0: Address of the capacitance ; ratio or inverse(Cratio) move r, a load a, theta ; DPTR1: Address of the temperature rad DPTR1 move r, a load b, NV_QUADRATIC_COEFFS; Address of the coefficients; in NVRAM in B-Accu		
	load2exp a, 1 ; Count = 2 load b, NV_Cal_vals; Starting address of Calibration; values in NVRAM jsb _ROM_NVblock_copy_32b_; Subroutine to copy Z_min; and Z_max values from NVRAM -> argument RAM  ; load a, C1_ratio  rad DPTR0 ; DPTR0: Address of the capacitance ; ratio or inverse(Cratio) move r, a load a, theta ; DPTR1: Address of the temperature rad DPTR1 move r, a load b, NV_QUADRATIC_COEFFS; Address of the coefficients ;in NVRAM in B-Accu		

ams DatasheetPage 155[v1-03] 2018-Apr-04Document Feedback



### \_ROM\_capacitance\_polynomial\_4d

Function:	This function calculates the value of the capacitance polynomial, Z_result = $(((a2 * theta) + a1) * theta) + a0$ given the capacitance ratio or inverse (Cratio) and temperature (theta). a2, a1 and a0 are 4th degree polynomials of the Cratio value an = $(((cc4n / xi + cc3n)/xi + cc2n)/xi + cc1n)/xi + cc0n$ where cc4n cc0n are the coefficients of the fourth degree polynomial in the NVRAM		
Input parameters:	DPTR0: Address of the capacitance ratio or inverse(Cratio) DPTR1: Address of the temperature (theta) B-Accu Starting address of coefficient values in NVRAM Arg_6: Z_min Arg_7: Z_max		
Output/Return value:	A-Accu: Z_result = result of the polynomial		
Prerequisites	-		
Function call	_ROM_capacitance_polynomial		
Temporary memory usage	temporary_variables 8 totemporary_variables Arg_0 to Arg_7		
Example:	Arg_0 to Arg_7		

Page 156ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



#### **Assembly Programs**

The PCap04 assembler is a multi-pass assembler that translates assembly language files into HEX files as they will be downloaded into the device. For convenience, the assembler can include header files. The user can write his own header files but also integrate the library files as they are provided by **ams**. The assembly program is made of many statements which contain instructions and directives. In the former section we explained the instructions in detail. In the following sections we describe the directives and some sample code.

Each line of the assembly program can contain only one directive or instruction statement. Statements must be contained in exactly one line.

#### **Symbols**

A symbol is a name that represents a value. Symbols are composed of up to 31 characters from the following list:

Symbols are not allowed to start with numbers. The assembler is case sensitive, so care has to be taken for this.

#### **Numbers**

Numbers can be specified in hexadecimal or decimal. Decimal have no additional specifier. Hexadecimals are specified by leading "0x".

#### **Expressions and Operators**

An expression is a combination of symbols, numbers and operators. Expressions are evaluated at assembly time and can be used to calculate values that otherwise would be difficult to be determined.

The following operators are available with the given precedence:

Level	Operator	Description
1	0	Brackets, specify order of execution
2	*/	Multiplication, Division
3	+	Addition, Subtraction

#### Example:

CONST value 1 equal ((value + 3)/2)

ams Datasheet Page 157
[v1-03] 2018-Apr-04 Document Feedback



#### **Directives**

The assembler directives define the way the assembly language instructions are processed. They also provide the possibility to define constants, to reserve memory space and to control the placement of the code. Directives do not produce executable code.

The following table provides an overview of the assembler directives.

Figure 134:
Overview of Assembler Directives

Directive	Description	Example		
CONST	Constant definition, CONST [name] [value] value might be a number, a constant, a sum of both	CONST Slope 42 CONST Slope constant + 1		
LABEL:	Label for target address of jump instructions. Labels end with a colon. All rules that apply to symbol names also apply to labels.	jsb LABEL1 LABEL1: 		
;	Comment, lines of text that might be implemented to explain the code. It begins with a semicolon character. The semicolon and all subsequent characters in this line will be ignored by the assembler. A comment can appear on a line itself or follow an instruction.	; this is a comment		
org	Sets a new origin in program memory for subsequent statements.	org 0x23 equal 0x332211		
equal	Insert three bytes of user defined data in program memory, starting at the address as defined by org.	; write 0x11 to address 0x23, ; 0x22 to address 0x24		
	Directive definition, #device [dev_name] might be the name of the used device.			
#device	Defines which Library is used for the assembler and defines the subdirectory \lib\[dev_name] for the included header or library file.	#device PCap03-Z		
	Include the header or library file named in the brackets < > or quotation marks " ". The code will be added at the line of the include command.			
#include	Names in brackets refer to the <b>ams</b> library with the defined subdirectory \lib\[dev_name]. Without using #device directive it refers to the fixed subdirectory \lib.	#include <rdc.h> #include "rdc.h"</rdc.h>		
	In quotation marks the might be just the file name in case it is in the same folder as the program, but also the complete path.			

Page 158ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



Directive	Description	Example
#ifdef #elseif #endif	Directive to implement code or not, dependig on the value of the symbol following the #ifdef directive. Use e.g. to include header files only once into a program.	#ifdefstandard_h #else #definestandard_h
#define	Defines a symbol that will be interpreted as true when being analysed by the #ifdef directive	 #endif

ams Datasheet Page 159 **Document Feedback** 



### **Sample Code**

In the following we show some sample code for programming loops in the various kinds, for the use of the load instruction and the rotate instruction.

### "for" Loop

Assembler	C-Equivalent	Comment
load a, max	for(index=-max; index < 0; index++)	max : number of repetitions
not a		2nd complement for max (~max+1)
inc a		
rad index		store (-max) to index
move r, a		
do:		loop body
;{}		
rad index		
inc r		loop increment
jCarC do		repeat while index < 0

### "while" Loop

Assembler	C-Equivalent	Comment
do: rad expression move a, r jEQ done ;{} clear a jEQ do done;	while ( expression ) {}	activate Status Flags for "expression". Jump if expression == 0 loop body unconditional jump without writing to program counter stack

### "do - while" Loop

Assembler	C-Equivalent	Comment
do:	do	
;{}	{}	loop body
rad expression	while ( expression )	
move a, r		activate Status Flags
jNE do		jump if expression != 0

Page 160ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



### "do - while" with 2 pointers

Assembler	C-Equivalent	Comment
load a, MW7	loopLimit = *MW7	load max-address for ptrSource
rad loopLimit		
move r, a		
load a, MW0	ptrSource = *MW0;	load ptrSource with source address
rad DPTR0		
move r, a		
load a, RES0	ptrSink = *Res0;	load ptrSink with sink address
rad DPTR1		
move r, a		
do:		loop body
rad _at_DPTR0	do { *ptrSink++ = *ptrSource++ }	load value from source
move a, r		
rad _at_DPTR1		write value to sink
move r, a		
rad loopLimit		write max-address to a
move a, r		
rad DPTR1		increment sink address
inc r		
rad DPTR0		increment source
inc r sub a, r		address
jCarS do		limitLoop – ptrSource
		repeat loop if ptrSource <= max-address
	while ( ptrSource <= MW7)	

### Rotate Right A to B

To rotate a value right from Akku A to Akku B, Akku B and R must be set to zero. Afterwards with each mult command a single "rotate right from A to B" is done. This function could be used e.g. to shift a 8-bit value to the highest byte in the register.

Assembler	C-Equivalent	Comment
load a, 0xa3	A = <u8bc></u8bc>	
clear b	b = a << 40	
move r, b		
mult ; (8x)		
mult		
mult		

ams Datasheet Page 161
[v1-03] 2018-Apr-04 Document Feedback



#### Libraries

The PICOCAP assembler offers the possibility to implement library files. With these libraries the firmware can be written in a modular manner. Common library files are for definitions of variable and constant names.

When the DSP has to be programmed by the user for a specific application or when the firmware ought to be modified, these library functions can be simply integrated into the application program without any major tailoring. They save programming effort for known, repeatedly used, important functions. Some library files are interdependent on other file(s) from the library.

The library functions are called header files (they have \*.h extension) in the assembler software and have to be included in the main \*.asm program. The path for the library files should be \lib\[dev\_name] in the folder where the assembler is.

The following are the header files that we supply together with the assembler as part of the evaluation kit.

#### **Device Related**

pcap\_standard.h PCap04\_ROM\_addresses\_standard.h pcap\_config.h

The input parameters, output parameters, effect on RAM contents etc. for each of these library functions are explained in the tables below.

**Note(s):** In the standard firmware and in all the library files, the notation "ufdN" is used as a comment. This shows if the parameter is signed or unsigned and the number of fractional digits in the number, N. For e.g. ufd21 indicates that the parameter is an unsigned fixed point number with 21 fractional digits. If the u at the beginning is missing, it is a signed number.

Page 162

Document Feedback

[v1-03] 2018-Apr-04



### pcap\_standard.h

Function:	This is a standard library for PCap04 firmware projects. It contains the major address mappings and constant names for the PCap04.  Note: This file should be always included. It contains no commands, so no program space is wasted				
Definitions (examples):					
	;- Temp. Variables and Arguments Def*/				
	CONSTarguments82				
	CONSTnumber_of_arguments10				
	CONSTtemporary_variablesargumentsnumber_of_arguments				
	CONST Arg_0arguments 8				
	CONST Arg_1arguments 7				
	; - RAM-Addresses OUT (&IN)*/				
	CONST FLAGREG96				
	CONST RES00 97				
	CONST RES01 98				
	CONST RES02 99				

# $PCap 04\_ROM\_addresses\_standard.h$

Function:	This file declares the jump labels for ROM routines		
Definitions (examples):			
	CONST _ROM_dma0x5d1; 1489		
	CONST _ROM_In0x5e1; 1505		
	CONST _ROM_log100x5fc; 1532		
	CONST _ROM_cdc0x7d4; 2004		
	CONSTsub_cdc_C0_Ratio_temp0x3A; 58		
	CONSTsub_cdc_C1_Ratio_temp0x3B; 59		

ams DatasheetPage 163[v1-03] 2018-Apr-04Document Feedback



### pcap\_config.h

Function:	Configuration register addresses and names for pcap04. It is for convenience, contains no commands and so no program space is wasted.
Definitions (examples):	CONST CFG_ADD_OFFSET 960; Start address of config in; NVRAM; Register 13  CONST CFG_ADD_C_TRIG_SEL 13 + CFG_ADD_OFFSET; Register 42  CONST CFG_ADD_EXTERNAL_FLAGS 42+ CFG_ADD_OFFSET  CONST CFG_BM_C_MEDIAN_EN0x01; Bit Mask for C_MEDIAN_EN; Enable median filter for CDC values

Page 164ams DatasheetDocument Feedback[v1-03] 2018-Apr-04




### **Application Information**

#### Schematic

Pcap04 needs only a few external components for operation. Of importance is a sufficient buffering of the supply voltage. We recommend  $10\mu F$  for VDD33 and  $4.7\mu F$  for VDD18. A simple RC network may be used for integration of the PDM outputs to generate analog output signal.

Figure 135: Typical Schematics with I<sup>2</sup>C Interface and PDM Analog Outputs



ams Datasheet Page 165 **Document Feedback** 




### **Minimized Bonding**

Pcap04 is designed that for compact one-sensor applications the die may be bonded on two sides only.

Minimum: GND: #3, 4, 21,22, VDD33: #7, 24, VDD18: #5, 6 have to be connected.

Figure 136: 2-Side Bonding




Page 166ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



### **Package Drawings & Markings**

Figure 137: Package Drawing (QFN24)



#### Note(s):

- 1. Dimensioning and tolerancing conform to ASME Y14.5M-1994
- 2. All dimensions are in millimeters (angles are in degrees).
- 3. Dimension b applies to metallized terminal and is measured between 0.25mm and 0.30mm from terminal tip. Dimension L1 represents terminal full back from package edge up to 0.15mm is acceptable.
- 4. Coplanarity applies to the exposed heat slug as well as the terminal.
- ${\bf 5.}\ {\bf Radius\ on\ terminal\ is\ optional.}$
- 6. N id the total number of terminals.

ams Datasheet Page 167
[v1-03] 2018-Apr-04 Document Feedback



Figure 138: Package Marking




Figure 139: Package Code

PCAP04	Т	PP	v1	YY	ww	Х	Z
Part	Temperature A:-40°C to 125°C B:-40°C to 85°C	Package QF : QFN24	Silicon revision	Year	Week	Assembly Plant Identifier	Assembly Traceability Code

Page 168ams DatasheetDocument Feedback[v1-03] 2018-Apr-04




# **PCB Pad Layout**

**Caution:** The center pad is internally connected to GND. No wires other than GND are allowed underneath.

It is recommended to not solder the center pad. Too much solder paste could reduce solder quality.

Suitable socket: e.g. Plastronics 32QN50S15050D

Figure 140: Landing Pattern



#### Note(s):

1. All dimensions are in mm.

ams DatasheetPage 169[v1-03] 2018-Apr-04Document Feedback




### **Tape & Reel Information**

Figure 141: Package Overview (only QFN)

Package	Device	Devices per Reel			
i ackage	Device	7" Reel 13" Reel			
QFN24	PCap04	1000	6000		

The tape-and-reel configuration is used for transport and storage from the manufacturer (ams AG) to the customer, and for use in the customer manufacturing plant. The configuration is designed for feeding components to automatic-placement machines for surface mounting on board assemblies. The complete configuration consists of a carrier tape with sequential individual cavities that hold individual components, and a cover tape that seals the carrier tape to retain the components in the cavities. Single reels are packed into dry-pack and inserted into intermediate boxes before shipping.


Figure 142: Reel



Page 170ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



Figure 143: Single Reel in Dry Bag




Carrier tape is widely used for presenting devices to pick-and-place machines for automatic placement onto printed circuit boards.

ams DatasheetPage 171[v1-03] 2018-Apr-04Document Feedback



Figure 144: Carrier Tape QFN24 (32)



#### Note(s):

- 1. Sprocket hole pitch cumulative tolerance  $\pm 0.2$
- 2. Camber in Compliance with EIA 481
- ${\it 3. Pocket position relative to sprocket hole measured as true position of pocket, not pocket hole}\\$
- 4. All dimensions in mm

Page 172ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



# Soldering & Storage Information

#### IPC/JEDEC J-STD-020

The reflow peak soldering temperature (body temperature) is specified according to IPC/JEDEC J-STD-020 "Moisture/Reflow Sensitivity Classification for Non-hermetic Solid State Surface Mount Devices." The lead finish for Pb-free leaded packages is "Matte Tin" (100% Sn)



# **Ordering & Contact Information**

Figure 145: Ordering Information

Ordering Code	Package	Marking	Delivery Form	Delivery Quantity
PCap04-AQFT-24	QFN24	PCAP04 AQF V1 YYWWXZZ	13"Tape & Reel in dry pack	6000 pcs/reel
PCap04-AQFM-24	QTNZŦ		7"Tape & Reel in dry pack	1000 pcs/reel
PCap04-BQFT-24	OFN24	PCAP04 BOF V1	13"Tape & Reel in dry pack	6000 pcs/reel
PCap04-BQFM-24	QINZT	YYWWXZZ	7"Tape & Reel in dry pack	1000 pcs/reel
PCap04-ASWB	n.a.	n.a.	Sorted wafer in box	1 wafer = ~10000 die
PCap04-ASDF	n.a.	n.a.	Sorted wafer on blue foil	1 wafer = ~10000 die
PCap04-BSWB	n.a.	n.a.	Sorted wafer in box	1 wafer = ~10000 die

Buy our products or get free samples online at:

www.ams.com/ICdirect

Technical Support is available at:

www.ams.com/Technical-Support

Provide feedback about this document at:

www.ams.com/Document-Feedback

For further information and requests, e-mail us at:

ams\_sales@ams.com

For sales offices, distributors and representatives, please visit: www.ams.com/contact

#### Headquarters

ams AG Tobelbader Strasse 30 8141 Premstaetten Austria, Europe

Tel: +43 (0) 3136 500 0 Website: www.ams.com

Page 174ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



### **RoHS Compliant & ams Green** Statement

**RoHS:** The term RoHS compliant means that ams AG products fully comply with current RoHS directives. Our semiconductor products do not contain any chemicals for all 6 substance categories, including the requirement that lead not exceed 0.1% by weight in homogeneous materials. Where designed to be soldered at high temperatures, RoHS compliant products are suitable for use in specified lead-free processes.

ams Green (RoHS compliant and no Sb/Br): ams Green defines that in addition to RoHS compliance, our products are free of Bromine (Br) and Antimony (Sb) based flame retardants (Br or Sb do not exceed 0.1% by weight in homogeneous material).

**Important Information:** The information provided in this statement represents ams AG knowledge and belief as of the date that it is provided. ams AG bases its knowledge and belief on information provided by third parties, and makes no representation or warranty as to the accuracy of such information. Efforts are underway to better integrate information from third parties. ams AG has taken and continues to take reasonable steps to provide representative and accurate information but may not have conducted destructive testing or chemical analysis on incoming materials and chemicals. ams AG and ams AG suppliers consider certain information to be proprietary, and thus CAS numbers and other limited information may not be available for release.

ams Datasheet **Page 175 Document Feedback** 



#### **Copyrights & Disclaimer**

Copyright ams AG, Tobelbader Strasse 30, 8141 Premstaetten, Austria-Europe. Trademarks Registered. All rights reserved. The material herein may not be reproduced, adapted, merged, translated, stored, or used without the prior written consent of the copyright owner.

Devices sold by ams AG are covered by the warranty and patent indemnification provisions appearing in its General Terms of Trade. ams AG makes no warranty, express, statutory, implied, or by description regarding the information set forth herein. ams AG reserves the right to change specifications and prices at any time and without notice. Therefore, prior to designing this product into a system, it is necessary to check with ams AG for current information. This product is intended for use in commercial applications. Applications requiring extended temperature range, unusual environmental requirements, or high reliability applications, such as military, medical life-support or life-sustaining equipment are specifically not recommended without additional processing by ams AG for each application. This product is provided by ams AG "AS IS" and any express or implied warranties, including, but not limited to the implied warranties of merchantability and fitness for a particular purpose are disclaimed.

ams AG shall not be liable to recipient or any third party for any damages, including but not limited to personal injury, property damage, loss of profits, loss of use, interruption of business or indirect, special, incidental or consequential damages, of any kind, in connection with or arising out of the furnishing, performance or use of the technical data herein. No obligation or liability to recipient or any third party shall arise or flow out of ams AG rendering of technical or other services.

ams Datasheet **Page 176** [v1-03] 2018-Apr-04



### **Document Status**

Document Status	Product Status	Definition
Product Preview	Pre-Development	Information in this datasheet is based on product ideas in the planning phase of development. All specifications are design goals without any warranty and are subject to change without notice
Preliminary Datasheet	Pre-Production	Information in this datasheet is based on products in the design, validation or qualification phase of development. The performance and parameters shown in this document are preliminary without any warranty and are subject to change without notice
Datasheet	Production	Information in this datasheet is based on products in ramp-up to full production or full production which conform to specifications in accordance with the terms of ams AG standard warranty as given in the General Terms of Trade
Datasheet (discontinued)	Discontinued	Information in this datasheet is based on products which conform to specifications in accordance with the terms of ams AG standard warranty as given in the General Terms of Trade, but these products have been superseded and should not be used for new designs

Page 177 ams Datasheet [v1-03] 2018-Apr-04 **Document Feedback** 



#### **Revision Information**

Changes from 1-02 (2017-Nov-08) to current revision 1-03 (2018-Apr-04)	Page
Updated Figure 1	1
Updated Figure 8	10
Updated notes under Figure 10	13
Updated text under Figure 77	53
Updated Figure 78	54
Updated text under Figure 80	56
Updated text under Figure 89	62
Updated text under Trigger	66
Updated text under NVRAM Access	94

#### Note(s):

- 1. Page and figure numbers for the previous version may differ from page and figure numbers in the current revision.
- $2. \, Correction \, of \, typographical \, errors \, is \, not \, explicitly \, mentioned.$

Page 178  $ams\, Datasheet$ [v1-03] 2018-Apr-04



#### **Content Guide**

#### 1 **General Description**

- 1 **Key Benefits & Features**
- 2 **Applications MEMS Sensors**
- 2 **Block Diagram**

#### 3 **Pin Assignments**

- 4 Pin Description
- **Pad Coordinates** 6

#### **Absolute Maximum Ratings** 8

#### 10 Electrical Characteristics

- 13 CDC Characteristics
- **RDC Characteristics**

#### 16 Timing Characteristics

#### **Detailed Description**

#### 19 Register Description

- **Configuration Registers**
- Register Overview 19

#### **Detailed Configuration Register Description**

- Configuration Register 0 (Address 0x0)
- 24 Configuration Register 1 (Address 0x1)
- 25 Configuration Register 2 (Address 0x2)
- Configuration Register 3 (Address 0x3) 25
- 26 Configuration Register 4 (Address 0x4)
- 26 Configuration Register 5 (Address 0x5)
- Configuration Register 6 (Address 0x6) 27 27
- Configuration Register 7:8 (Address 0x7, 0x8) 27 Configuration Register 11:9 (Address 0x9;0xA;0xB)
- Configuration Register 12 (Address 0xC) 28
- 28 Configuration Register 13 (Address 0xD)
- 28 Configuration Register 14 (Address 0xE)
- Configuration Register 15 (Address 0xF)
- 29 Configuration Register 16 (Address 0x10)
- Configuration Register 17 (Address 0x11) 29
- Configuration Register 18 (Address 0x12) 30
- 31 Configuration Register 19 (Address 0x13)
- Configuration Register 20 (Address 0x14) 31
- 32 Configuration Register 21 (Address 0x15)
- Configuration Register 22(Address 0x16) 32
- Configuration Register 23 (Address 0x17) 33
- Configuration Register 24 (Address 0x18)
- Configuration Register 25 (Address 0x19) 34
- Configuration Register 26 (Address 0x1A) 34
- Configuration Register 27 (Address 0x1B)
- Configuration Register 28 (Address 0x1C) 35
- Configuration Register 29 (Address 0x1D) Configuration Register 30 (Address 0x1E) 35
- 36 Configuration Register 31 (Address 0x1F)
- Configuration Register 32 (Address 0x20)
- Configuration Register 33 (Address 0x21) 37

Configuration Register 34 (Address 0x22)



- 38 Configuration Register 35 (Address 0x23)
- 38 Configuration Register 36 (Address 0x24)
- 39 Configuration Register 37 (Address 0x25)
- 39 Configuration Register 38 (Address 0x26)
- 39 Configuration Register 39 (Address 0x27)
- 39 Configuration Register 40 (Address 0x28)
- 40 Configuration Register 41 (Address 0x29)
- 40 Configuration Register 42 (Address 0x30)
- 40 Configuration Register 47 (Address 0x2F)
- 41 Configuration Register 48 (Address 0x30)
- 41 Configuration Register 49 (Address 0x31)
- 41 Configuration Register 50 (Address 0x32)
- 42 Configuration Register 51 to 53: ams internal Registers, 0x00 mandatory
- 42 Configuration Register 54 (Address 0x36)
- 42 Configuration Register 55 to 61: ams internal Registers, 0x00 mandatory
- 42 Configuration Register 62 (Address 0x3e)
- 42 Configuration Register 63 (Address 0x3f)
- 43 Read Registers
- 45 Result Registers
- 45 Status Registers

#### 47 Principles of Operation

- 47 Converter Frontend
- 47 Capacitance-to-Digital Converter (CDC)
- 47 Measuring Principle
- 47 Connecting Sensors
- 48 Discharge Resistors
- 49 Cycle
- 51 Sequence
- 52 Conversion
- 55 CDC Compensation Options
- 55 Internal Compensation
- 55 External Compensation
- 56 DC Balance
- *57 Gain Correction*
- 57 CDC Important Parameters
- 57 Cycle Clock
- 58 Cycle Time
- 59 Sequence
- 60 Conversion
- 61 Guarding
- 64 RDC Resistance-to-Digital Converter
- 64 Measuring Principle
- 64 Connecting Sensors
- 65 Cycle & Conversion
- 66 Trigger
- 67 RDC Important Parameters
- 67 Cycle Clock
- 68 Sequence
- 68 Conversion
- 68 RDC Results, Ratios
- 69 Interfaces (Serial & PDM/PWM)

Page 180ams DatasheetDocument Feedback[v1-03] 2018-Apr-04



- 69 Serial Interfaces (SIF)
- 70 Opcodes
- 71 I<sup>2</sup>C Compatible Interface
- 72 I<sup>2</sup>C Timing
- 72 I<sup>2</sup>C Write
- 73 I<sup>2</sup>C Read
- 73 SPI Interface
- 74 SPI Timing
- 76 GPIO and PDM/PWM
- 78 Debouncing Filter
- 78 PDM and PWM
- 82 Oscillators
- 83 DSP & Memory
- 84 DSP & Environment
- 85 RAM Structure
- 87 Registers 0 to 95, User RAM
- 88 Register 96, Flags & Internal Control Signals
- 88 DSP Read Register 97
- 89 DSP Read Registers 98 to 103
- 89 DSP Read/Write Registers 105 to 108, Data Pointer
- 90 DSP Read Register 126, PORTINFO (PORTERR<7...0>, PORTMASK<7...0>)
- 90 DSP Write Registers 97 to 104, RES00...RES07
- 90 DSP Write Registers 109, 110, PIO\_REF...PI1\_REF
- 90 DSP Write Register 111, TIMER0
- 91 DSP Read/Write Registers 112 to 120, MEM\_CTRL, MEM\_ADD, MEM\_DATA
- DSP Read Registers 121 to 124, TDC\_START, TDC\_STOP, C\_ADD\_PTR, R\_ADD\_PTR
- 93 NVRAM and ROM
- 93 NVRAM Structure
- 94 NVRAM Access
- 94 ROM Structure
- 94 DSP Inputs & Outputs
- 99 ALU Flags
- 100 DSPOUT GPIO Assignment
- 104 DSP Configuration
- 105 DSP Start
- 105 Watchdog
- 106 Instruction Set
- 107 Instructions
- 125 Instruction Details
- 125 Pointer
- 126 Transfer Constants with Push and Pop
- 126 mult
- 127 Handover of Constants by Push & Pop
- 127 div
- 130 ROM Routines
- 132 \_ROM\_Version\_\_
- 132 \_ROM\_tdc\_dispatch\_\_
- 133 \_ROM\_cdc\_cycle\_
- 134 \_ROM\_Rdc\_cycle\_\_
- 135 \_ROM\_cdc\_initialize\_\_
- 135 \_ROM\_rdc\_initialize\_\_



- 136 shiftL\_A\_xx; shiftR\_A\_xx; shiftL\_B\_xx; shiftR\_B\_xx 136 mult xx 137 div\_xx 138 \_ROM\_div\_variable\_\_ 139 ROM mult variable 140 \_ROM\_shift\_a\_variable\_\_ 140 ROM shift b variable 141 \_ROM\_dma\_\_ 142 \_ROM\_ln\_\_, \_ROM\_log10\_\_, \_ROM\_ld\_\_ 142 ROM signed24 to signed32 143 ROM median 144 \_ROM\_cdc\_\_ 145 \_ROM\_rdc\_\_; \_ROM\_rdc\_inverse\_\_ 146 \_ROM\_memory\_ (read/write volatile memory) 148 \_ROM\_MEMORY\_RECALL/STORE 149 ROM 2pt calibration 150 \_ROM\_polynomial\_3rd\_degree 151 \_ROM\_polynomial\_4th\_degree 152 \_ROM\_pulse\_\_ 153 \_ROM\_pulse\_loaded\_cal\_vals 154 \_ROM\_NVblock\_copy\_ 155 \_ROM\_capacitance\_polynomial 156 \_ROM\_capacitance\_polynomial\_4d 157 Assembly Programs 158 Directives 160 Sample Code 160 "for" Loop 160 "while" Loop 160 "do - while" Loop 161 "do - while" with 2 pointers 161 Rotate Right A to B
- 162 Libraries
- 163 pcap\_standard.h
- 163 PCap04\_ROM\_addresses\_standard.h
- 164 pcap\_config.h

### **165 Application Information**

- 165 Schematic
- 166 Minimized Bonding
- 167 Package Drawings & Markings
- 169 PCB Pad Layout
- 170 Tape & Reel Information
- 173 Soldering & Storage Information
- 174 Ordering & Contact Information
- 175 RoHS Compliant & ams Green Statement
- 176 Copyrights & Disclaimer
- 177 Document Status
- 178 Revision Information

Page 182

Document Feedback

[v1-03] 2018-Apr-04