



CAN bus supply voltage to 5V SMPS



DCDC_IN chosen as input in to stay alive if solar goes down for boost mode



Raspberry Pi HAT connector











Libre Solar

Libre Solar	CAN interface for Raspberry Pi (Zero	W)
Libre Solar		LIBRE SOLAR
Sheet: / File: CAN_RPi-Z	eroW.sch	
Author: Martin J	iger	
Size: A3	Date: 2017-11-20	Rev: 0.1
KiCad E.D.A. kicad (2017—11—18 revision ff5ee05de)—makepkg		Page: 1/1