
## **ACRAEA 2.0 ASSEMBLY MANUAL**

#### Step by Step Instructions



ASSEMBLY MANUAL BY JC and the Turtles

MACHINE HARDWARE BY Turtles

# **INDEX**

| Step 1 Get the Backframe Ready             |   |
|--|---|
| Step 2 Add the first layer                 |   |
| Step 3.1 Add the wick                      |   |
| Step 3.2 Add the feed spacer               |   |
| Step 3.3 Add drainage and sealing          |   |
| Step 3.4 Add the plate                     |   |
| Step 4 Repeat step 3 Twice                 |   |
| Step 5.1 Add the last wick and drainage    | 1 |
| Step 5.2 Add the top feed spacer and plate | 1 |
| Step 6 Add the sidewall and the top frame  | 1 |
| Step 7 Close the module                    | 1 |

#### STEP 1 GET THE BACKFRAME READY

Step 1/7

1 min



1x Casing back wall



3x Washer



JA Washi



3x Thumbscrew



3x Threaded rod




**R1.** The inner cutouts in the Casing back wall are customised for the used heating elements

R2. Mind the orientation of the frame

**R3.** Insert the threaded rods with the washers and thumbscrews

**R4.** Lay it flat down on a table with the thumbscrews pointing down

**R5.** Add a piece of material on the bottom corner for more stability during assembly stabilisation



### STEP 2 ADD THE FIRST LAYER

Step 2/7

1 min



1x Feed Backwall



3x Heating Pad







1x Heating Spacer



1x Plate



- **R7.** Slide the feed backwall onto the rods
- **R8.** Align the top corners of the heating module with the feed backwall
- **R9.** Align the triangular heating spacer on the bottom corner of the heating module



### STEP 3.1 ADD THE WICK

Step 3/7

(\) 1 min Correction: Skip this step - see next step




1x Wick

R10. Add the wick

**R11.** Ensure it is pointing about 1cm above the bottom corner of the feed backwall

R12. Ensure equal spacing to both side corners of the plate



### STEP 3.2 ADD THE FEED SPACER

Step 3/7

1 min



1x Feed Sealing






**R13.** Slide the feed sealing onto the rods R14. Make sure the material is pushed fully down on the threads

R15. Add the feed spacer



2x Feed Spacer



#### STEP 3.3 ADD DRAINAGE AND SEALING

Step 3/7

1 min



1x Drainage



1x Sealing Drainage




**R16.** Add the drainage and align it parallel to the plate corner

**R17.** Ensure the noses of the drainage are on top of the clot

**R18.** Sealing option (A) clip 3d-printed sealing onto drainage

**R19.** Sealing option (B) add small amount of food-grade silicone on the indentation for the plate



## **STEP 3.4 ADD THE PLATE**

Step 3/7

1 min




1x Plate

**R20.** Align the plate in the corners of the feed spacer

**R21.** for option (A) align the plate on the sealing on the drainage

**R22.** for option (B) align the plate on the indentation



## **STEP 4 REPEAT STEP 3 TWICE**



1 min



2x Sealing Drainage



2x Feed Sealing



2x Plate




2x Drainage



2x Wick



2x Feed Spacer



### STEP 5.1 ADD THE LAST WICK AND DRAINAGE

Step 5/7

1 min



1x Drainage




**R23.** Add the wick,drainage and drainage sealing as before



1x Wick



1x Sealing Drainage



### STEP 5.2 ADD THE TOP FEED SPACER AND PLATE

Step 5/7

1 min



1x Feed Sealing

**R24.** Add the feed front wall with the flat side up


R25. Add the last plate



1x Plate



1x Feed Frontwall



### STEP 6 ADD THE SIDEWALL AND THE TOP FRAME

Step 6/7

1 min




**1x** Casing right wall

R26. Add the right side wall R27. Add the casing front wall



1x Casing front wall



#### STEP 7 CLOSE THE MODULE

Finally: Tighten all the thumbscrews on both sides well.

