
# M472 · RTO-144 CONNECTIONS

M472 - Equalizer

## REAR CONNECTOR

### REAR VIEW · CARD EDGE · CONTACTS 1-6 SHOWN




Input Output

## INPUTS AND OUTPUTS




## AUDIO CONNECTIONS · RTO-144 A / B

| PORT | SIGNAL | DIR | PIN + | PIN – | PAD + | PAD – |
|---|---|---|---|---|---|---|
| A1 | EQ(unbalanced) IN | in | 4 | — | 4.A.1.P | .A.1.N |
| A2 | EQ(unbalanced) OUT | out | 6 | — | 6.A.2.P | .A.2.N |

Source: Ward-Beck Systems - Module RTO-144 Jumper calculator.xlsx (Database tab). Pin direction is inferred from the signal name. Verify against the module schematic before wiring.

| WBS | WARD-BECK SYSTEMS LTD. | | |
|---|---|---|---|
| TITLE | M472 RTO-144 CONNECTIONS | | |
| DRN. | MAKE_RTO144.PY | DATE | OCT 17 2026 |