POS: PC POS

Check Condition Till, BOP and Drive-Thru systems

Frequency Weekly

Model PC POS - Panasonic JS 935

Estimated Time to complete 30 minutes

Health & Safety Hazards

Electrical

240 volt

Food Safety




Wash and dry hands after performing this task



Ensure nuts, bolts & screws are tight



Inspect equipment. Do not use if damaged




General:

Unless instructed to do so by iTSC, do not remove any cables or connectors

Visually check each till on front counter and in Drive-Thru / Walk-Up / Walk-Thru






Check that the screen is clean and undamaged. Clean screen with Probe wipe if required and call iTSC if screen is damaged.



POS are clean and clear of any obstructions. Clean vent with probe wipe and remove any obstructions by hand.



Greek that the screen does not flicker when being used and retaining screws are tight. Tighten screws using driver FAISDPZ1 available from www.odemastore.co.uk









CC013 - Till to Card Reader (Short)

Check each cash drawer on front counter and in Drive-Thru / Walk-Up / Walk-Thru











Check each till socket under front counter and in Drive-Thru / Walk-Up / Walk-Thru





Check each Bump Bar on BOP Line, Drive-Thru / Walk-Up / Walk-Thru





Check each BOP Drive-Thru / Walk-Up / Walk-Thru monitor



