
Software Libraries



<u>Note</u>: Various options available as real-time/embedded OS kernel if needed, although not provided as part of imiFrog software package at this time.

Software Structure

-- Idocumentation


```
/LimiFrog-SW
     -- /libraries
           -- /LimiFrog-Lib
              # Board init and controls - LimiFrog specific
              # Adaptation Layers for Middlewares (USBD, FatFS, emWin)
           -- /CMSIS L4xx
           --/STM32L4xx HAL Driver
           -- /STM32L4 USB-Device Library
           -- /FatFS Lib
           --/StemWin Lib
          -/Sensors APIs
     -- /projects
           -- /Project-A
                -- /inc
                -- /src
                -- Makefile
                -- /obj
           -- /Project-B
           -- /Project-X
           -- /STARTUP
                -- startup stm32l476xx.s
                -- STM32L476RE FLASH.ld
                - sysmem.c
                - system stm32l4xx.c
```

LimiFrog libraries


ST- and 3rd-party supplied libraries

Typically, user would customize these files


Software: LimiFrog-Lib Contents



Software: User Project Contents



Software: Include Model - HAL



_ppp = peripheral name

.../STM32L4xx HAL Driver/Inc

.../CMSIS_L4xx/Device/ ST/STM32L4xx/Include

(*) .../libraries/LimiFrog-Lib/inc

(**) .../CMSIS_L4xx/Include

Software: Include Model - Others

- main.c
- stm32_it.c
- Other user's application source files

<application-specific header files>
LBF Global.h

stm32l4xx hal.h

Header files of : LimiFrog BSP and Libs

- + Utilities
- + Sensor APIs
- + Middlewares (USB, FatFs, emWin)

Header files located under : .../LimiFrog_Lib/inc/...

Under:
.../STM32L4xx_HAL
Driver/Inc

Some C files in LimiFrog-Lib:
- LBF_User_Conf.c
- LBF_Board_Selective_Inits.c
- LBF_BTLE_Inits.c

C files involving
IT set-up in
LimiFrog-Lib/src

User_Configuration.h

IT_Priorities_User_Defined.h

Header files located under .../projects///project_name

Software: Include Model - Others

main.c, stm32 it.c. other user's application source files <application-specific header files> LBF Global.h Top-level board inits stm32l4xx hal.h LBF Board Fixed Inits.h LBF Board Selective Inits.h API to LimiFrog BSP and libs LBF lowlev API.h Debug utilities Debug Utilities.h Sensor APIs LBF lsm6ds3.h LBF lps25h.h Middleware APIs arm math.h (USB) LBF USB MassStorage.h #define (emWIn Graphics) LBF emWin Init.h ARM MATH CM4 WM.h Gui.h (FAT File System) LBF FatFS Init.h ff gen drv.h

Under: .../LimiFrog Lib/inc/...

Header files of : LimiFrog BSP and Libs + Utilities + Sensor APIs

+ Middlewares (USB, FatFs, emWin)

<stdbool.h>
stm32l4xx_hal.h
LBF_global_variables.h
LBF_custom_types.h
LBF_pin_aliases.h
LBF_OnBoard_chip_aliases.h
LBF_services.h
LBF_xxx_lowlevAPI.h