

HandControlSchematic-v1.2

2

Description: the purple red words mean that the module contains the external interface, and the blue words mean that the module has no external interface. PCB shows the annotation of the device, not the value of the device.