TIWSNE – Wireless Sensor Networks and Electronics – (2015-Q4)

Lecture


Link Layer Protocols in WSNs

Qi Zhang

(Email: qz@eng.au.dk; Edison 314)



Relevant topics in WSN





Objective of this lecture

- The link layer has a task of ensuring a reliable communication link between neighbor nodes
 - Reliability in single hop link
- To achieve reliability over the time-variable wireless link, there are many mechanisms with different performance and energy consumption
- We will learn the relationship between reliability, error rate and energy consumption.



Outline

- Error control
- Framing
- Link management



Error control

- Error control has to ensure that data transport is
 - Error-free deliver exactly the sent bits/packets
 - In-sequence deliver them in the original order
 - Duplicate-free and at most once
 - Loss-free and at least once
- Causes: fading, interference, loss of bit synchronization,

•••

- Results in bit errors, burst error
- In wireless, even for stationary transmitter and receiver, bit error rate is time variable, average BER can be high 10⁻² ... 10⁻⁴ possible!
- Approaches
 - ARQ: Reactive
 - Forward error control FEC: Proactive




ARQ

- Basic procedure
 - Put header information around the payload
 - Compute a checksum and add it to the packet
 - Typically: Cyclic redundancy check (CRC), easy to implement,
 - Provide feedback from receiver to sender
 - Send positive or negative acknowledgement
 - Sender uses timer to detect that ACKs have not arrived
 - Assumes packet has not arrived
 - Optimal timer setting?
 - If sender infers that a packet has not been received correctly, sender can retransmit it
 - What is maximum number of retransmission attempts?
 - If bounded, at best a semi-reliable protocols results



Standard ARQ protocols

- Stop-and-Wait (Alternating bit): at most one packet outstanding, single bit sequence number
- Go-back-N:
 - The transmitter sends up to N packets, keep buffer for op to N packets
 - The receiver accepts frame only in the sequence and drops frames that even are correctly received but do not have the expected sequence number.
 - The receiver acknowledges the last received packet in sequence and only needs to buffer this packet.
 - If a packet has not been acknowledged when timer goes off, transmitter retransmits all unacknowledged packets
- Selective Repeat: when timer goes off, only send that particular packet



How to use acknowledgements


- Be careful about ACKs from different layers
 - A link layer ACK means
 - Correctly receive the packet
 - II. Has sufficient buffer space to process it further
 - III. The accepted packet is in sequence or out-of-sequence
 - A MAC ACK (e.g., S-MAC) only indicates condition (I) and for stop-and-wait or selective repeat (II) and (III) are often implied.
 - Depending on the implementation, if all three conditions are met, the MAC layer ACK can be used simultaneously as link layer ACK. Otherwise, extra link layer ACK are required.
- Do not (necessarily) acknowledge every packet use cumulative ACKs
 - E.g. windowed feedback with selective repeat and instantaneous feedback with selective repeat
 - Tradeoff: throughput, delay, energy, buffer size

When to retransmit

- Assuming sender has decided to retransmit a packet when to do so?
 - In a BSC channel, any time is as good as any
 - In fading channels, try to avoid bad channel states postpone transmissions
- How long to wait?
 - Example solution: Probing protocol
 - Idea: reflect channel state by two protocol modes, "normal" and "probing"
 - When error occurs, go from normal to probing mode
 - In probing mode, periodically send short packets (acknowledged by receiver) - when successful, go to normal mode

Forward error control

- Idea: add additional redundancy in a packet to withstand a limited amount of random permutations
 - Additionally: interleaving change order of symbols to withstand burst errors



Block-coded FEC

- Level of redundancy: blocks of symbols
 - Block: k p-ary source symbols (not necessarily just bits)
 - Encoded into n q-ary channel symbols
- Injective mapping (code) of p^k source symbols into qⁿ channel symbols
- Code rate: (k log₂(p)) / (n log₂(q))
 - When p=q=2: k/n is code rate



Popular block codes

- Popular examples
 - Reed-Solomon codes (RS)
 - Bose-Chaudhuri-Hocquenghem codes (BCH)
- Energy consumption
 - E.g., BCH encoding: negligible overhead (linear-feedback shift register)
 - BCH decoding: depends on block length n, and the number of correctable bits t, as

$$E_{\text{dec}} = (2nt + 2t^2) \cdot (E_{\text{add}} + E_{\text{mult}})$$


- E_{dec:} Energy Consumption for Decoding
- E_{add:} Energy Consumption for Addition
- E_{mult:} Energy Consumption for Multiplication
- Similar for RS codes



Error Resiliency

 Packet Error Rate (PER) is a function of signal to noise ratio (SNR), i.e., channel quality


 As error correction capability (t) increases, error resiliency improves





Error Resiliency

- How can error resiliency be exploited in multi-hop WSN?
 - Hop-length Extension (increase hop length for FEC)
 - $P_{tx,FEC} = P_{tx,ARQ}, d_{FEC} > d_{ARQ}$
 - Transmit Power Control (decrease transmit power)
 - $P_{tx,FEC} < P_{tx,ARQ}, d_{FEC} = d_{ARQ}$



FEC Cost


- FEC codes improve error resiliency at the cost of
 - Encoding/Decoding (energy + latency)
 - Tx/Rx longer packets (energy + latency)

Header	Payload	Redundant		
		bits		



Comparison: FEC vs. ARQ

- FEC
 - Constant overhead for each packet
 - Not (easily) possible to adapt to changing channel characteristics
- ARQ
 - Overhead only when errors occurred (expect for ACK, always needed)
- Both schemes have their uses hybrid schemes



Very good

Error Control through Power Control

- Further controllable parameter: transmission power
 - Higher power, lower error rates by improving SNR
 - Results in less FEC/ARQ necessary
 - Lower power, higher error rates higher FEC necessary
- Problem:
 - Higher power: energy consumption and interference are increased
- Tradeoff!



Outline

- Error control
- Framing
- Link management





Frame, packet size

- Small packets:
 - low packet error rate,
 - high overhead
- Large packets:
 - high packet error rate,
 - low overhead

Depends on bit error rate, energy consumption per successfully

transmitted bit





Dynamically adapt frame length

- For known bit error rate (BER), optimal frame length is easy to determine
- Problem: how to estimate BER?
 - Collect channel state information at the receiver (RSSI, FEC decoder information, ...)
 - Example: Use number of attempts T required to transmit the last M packets as an estimator of the packet error rate (assuming a BSC)
- Second problem: how long are observations?
 - If the period is too short, not enough data to obtain an accurate estimate of bit error probability
 - If the period is too long, it takes too much time
 - Try to use the estimation as a short-term prediction



Intermediate checksum schemes

- Basic idea: Retransmitting whole packet is waste resource. Can we only retransmit those parts of a packet where errors actually occurred?
 - User data is partitioned into a number of chunks
 - Append checksum for each individual chunk and also for frame header
 - If receiver detects error in the frame header, it discards the whole frame
 - If the header is correct, the receiver checks each chunk and buffers the correct ones. The faulty chunks need to be retransmitted.

Traditional framing

DLL/MAC header	User data		FCS			
Intermediate checksum framing						
DLL/MAC header	FCS	FCS			FCS	

Outline

- Error control
- Framing
- Link management



Link management


- Goal: a link should be established to decide to which neighbors that are more or less reachable
 - Quality of a link is time variable.
 - The quality can only be estimated,
 - either actively by sending probe packets and evaluating the responses
 - or passively by overhearing and judging neighbors' transmissions.
- Neighborhood table of each node cannot only store neighboring nodes but also the associated link qualities
 - Partially automatically constructed by MAC protocols
 - Cheap Sensor node might not have enough memory to store neighborhood table.

Link quality characteristics *

 Expected: simple, circular shape of "region of communication" - not realistic

Instead:


- Correlation between distance and loss rate is weak; iso-losslines are not circular but irregular
- Asymmetric links are relatively frequent (up to 15%)
- Significant short-term PER variations even for stationary nodes



Three regions of communication

Effective region:PER consistently< 10%

- Transitional region: anything in between, with large variation for nodes at same distance
- Poor region: PER well beyond 90%




Link quality estimation

- How to estimate, on-line, in the field, the actual link quality?
- Requirements
 - Precision estimator should give the statistically correct result
 - Agility estimator should react quickly to changes
 - Stability estimator should not be influenced by short/transient fluctuations
 - Efficiency Active or passive estimator



Cont...

- Active estimator: The node sends out special measurement packets and collect response from its neighbors.
- Passive estimator: the node overhears the transmission of its neighbors and estimates the loss rates from observing the neighbor's sequence numbers, packet loss are detected from gaps in the received numbers.
 - If neighbors generates sufficient traffic within a certain amount of time, i.e., with a minimum generated message rate, passive estimator is feasible.
 - Specially when transmission cost much more energy than receiving, passive estimator is preferable.



An illustration of a passive estimator



WMEWMA (Window Mean with EWMA)

- Best compromise between stability and agility
- It has two tuning parameters, $\alpha \in (0,1)$ and observation period T
- \widehat{P}_n is predictions at time $t_n = t + n \cdot T$
- Here the number of received packets in interval $(t_{n-1}, t_n]: r_n$
- The number of lost packets during interval $(t_{n-1}, t_n]: f_n$

$$\mu_n = \frac{r_n}{r_n + f_n}; \ \hat{P}_n = \alpha \mu_n + (1 - \alpha)\hat{P}_{n-1}$$



Summary

- In WSNs, Link layer needs to deal with the relatively specific issues
 - Careful choice of error control mechanisms tradeoffs between FEC & ARQ & transmission power & packet size ...
 - Link estimation and characterization

