Signal	Wire ID	Wire Status	Pattern A	Edge A	Cursor A	-3.5us -3us -2.5us	-2us -1.5us -1 A	us -500r	ns T+6.11us +500ns	+1us +1.5us +2us +2.5us	+3us +3.5us
- SPI Example			•	•			(00h) (15h) (00h) (00h)	-	(00h)-(15h)-(00h)-(00h)-	(00h) (15h) (00h) (00h)	(00h)-(15h)-(
MOSI	D2	L	×		0						
CLK	DO	L	×	t	0			1			
L_CS	D3	Н	0		0						
CLK	DO	L	×	t	0						
MISO	D1	L	×		0						
MOSI	D2	L	×		0						
L_CS	D3	Н	0		0						
T_CS	D4	L	X		1						Hij (
IRQ	D5	Н	×		1						

D0 Freq: 0Hz D0 Freq: 0Hz In

Interval A->B: 1.68us

D1 Transitions A->B: 16

KeDei Kernel Driver Timing

24,03,2018 10:16:56