Signal	Wire ID	Wire Status	Pattern A	Edge A	Cursor A	. T	 140us	-1. - 1. 1	20us	-100us	0 0 0	-80us	-60us	n a n	-40us	-2	20us	T+153.4us	+20	ıs	+40us	1 11 11 1	+60us	+80us	+	100us	+120us	+14	Ous
SPI Example					15h							_		1		- 1	-	-		-	-1		_	1	-1		-1-		
MOSI	D2	L	×		0										1				- 1	Ĭ	1		1		ĺ				
CLK	DO	L	X	t	1		ij.							1		-	1	1	1		1		- 1			1		1	
L_CS	D3	Н	0		0														1							1			
CLK	DO	L	X	t	1		9			I.							1	1	1					1 1					
MISO	D1	L	X		0														- 1		1								
MOSI	D2	L	×		0					1									- 1							1			
L_CS	D3	Н	0		0		7								- 1				1							1			
T_CS	D4	L	X		1		d					U	10					f			- 0							ĺ	
IRQ	D5	Н	X		1			-											- 1				- 1						
						D0 Freq: 0Hz			D0 Freq: 0Hz			Inter	Interval A->B: 46.91us			D1	D1 Transitions A->B: 0												

WiringPi Timing

24,03,2018 10:20:56