TerraCross Maintenance Guide

"The TerraCross is your ultimate companion for off-road adventures and challenging terrains. To ensure its longevity and optimal performance in demanding conditions, regular maintenance and care are essential. This guide provides you with all the necessary information to keep your TerraCross adventure-ready at all times."

Regular Maintenance Schedule

- Every 10,000 Miles or Biannually: Check and rotate tires, inspect brake pads, and suspension components.
- Every 20,000 Miles: Full vehicle inspection, including undercarriage, shock absorbers, and all-terrain-specific components.

Specific Maintenance Tips for TerraCross

- Suspension and Alignment: Regular checks are crucial due to the impact of off-road driving.
- Undercarriage Care: After off-road trips, inspect the undercarriage for any damage or debris.
- Tire Health: Frequently check for tire wear, tears, or damage essential for safe off-road driving.

Seasonal Care

- Preparing for Winter: Ensure that your TerraCross is equipped with winter tires if you're
 in a snowy area. Check the antifreeze levels and battery health.
- Summer Maintenance: Inspect the cooling system to manage engine temperatures during hot weather adventures.

Battery Care and Longevity

- As an electric vehicle designed for challenging conditions, ensure the battery is regularly checked for any signs of wear, especially after intensive off-road use.
- Adhere to recommended charging practices; avoid frequent deep discharges.

Troubleshooting Common Issues

- Reduced Performance on Rough Terrain: If you notice decreased performance, inspect suspension components and tire condition.
- Unusual Noises or Vibrations: This could indicate issues with alignment or shock absorbers, which are critical in off-road vehicles.

Warranty and Service Information

- TerraCross is backed by a 6-year/75,000-mile comprehensive warranty.
- Additional warranty for the electric drivetrain and battery is provided for 10 years/100,000 miles.