## UrbanGlide Maintenance Guide

"UrbanGlide, your reliable partner for city driving, combines urban practicality with cutting-edge electric vehicle technology. Regular maintenance ensures that your UrbanGlide continues to provide a seamless and efficient driving experience. This guide covers everything you need to keep your UrbanGlide in top condition."

## Regular Maintenance Schedule

- Every 7,500 Miles or Annually: Tire rotation and inspection, brake pad check, battery health assessment.
- Every 15,000 Miles: Suspension check, alignment, and software updates.

# Specific Maintenance Tips for UrbanGlide

- Battery Care: Avoid frequent deep discharges; it's best to keep the battery level between 20% and 80%.
- Tire Maintenance: Given the stop-start nature of city driving, check your tire pressure monthly to ensure optimal efficiency.
- Brakes: Due to frequent stopping in urban environments, keep an eye on brake pad wear and tear.

#### Seasonal Care

- Winter Care: Use winter tires if you're in a snowy area, and ensure your heating system is functioning optimally.
- Summer Care: Maintain fluid levels and ensure the cabin's cooling system is effective to combat higher temperatures.

### Battery Care and Longevity

- Regularly monitor your battery's state of charge and health via the UrbanGlide's interactive dashboard.
- Limit fast charging to when it's necessary, as regular use can shorten battery life.

## **Troubleshooting Common Issues**

- Reduced Range: If you notice a drop in range, check tire pressures and battery health first.
- In-Cabin Noise: Unusual noises during driving could indicate suspension or alignment issues, common in city navigation.

## Warranty and Service Information

- UrbanGlide comes with a 5-year/60,000-mile comprehensive warranty.
- Battery coverage is extended for 7 years/80,000 miles, ensuring your peace of mind.