Soniquam

SONIQCAM TECHNICAL DEVICES

Soniquam Sprint EL52E Simplified User Manual

Simple User Manual

SONIQCAM TECHNICAL DEVICES

Soniqcam Sprint EL52E Simplified User Manual

© Soniquam Technical Devices 12345 Main Street • Suite 100 Spokane, WA 56503 Phone 203.555.0167 • Fax 203.555.0168

Table of Contents

Introduction to Soniqcam Sprint EL52E	1
View Live Feed	1
Gallery & Screenshots	1
Administration Panel Login	
More Help	

SONIQCAM SPRINT EL52E



Introduction to Soniqcam Sprint EL52E

hankyou for purchasing your Soniqeam Sprint EL52E. This manual will provide you with a brief overview of your software, which should help you in managing your product day-to-day. Please note that this document is designed only as a simple introductory outline, and does not include the full scope of instructions necessary to fully manage your device further. For more assistance in setting up your device, please consult your Advanced User Manual.

View Live Feed

Once setup, your IPCam may be accessed in a browser via the given URL. The home page will display your live camera feed. If you have multiple cameras attached to the same portal, you will be able to switch between camera feeds using the drop-down source box, under the navigation menu. If the display window reads 'Offline', then your camera is either disabled, or misconfigured. Please consult Advanced User Manual for more specific troubleshooting and setup information.

Gallery & Screenshots

Your Sonique Sprint EL52E includes a simple-to-use screen capturing function, which allows logged in users to manually take a snapshot of a live camera feed, which is saved to the screenshot Gallery. This page may be accessed by clicking the "Gallery" button in your navigation section, or by navigating to "[your camera URL]/gallery.php". These images may be saved by anybody, and deleted by the user that created them.

Administration Panel Login

Your Sonique Sprint EL52E online module comes configured with an administrative page, which allows you to manage a number of settings pertaining to the management of your device. This panel may be accessed by clicking the "Administrator" button in

your navigation section, or by navigating to "[your camera URL]/admin.php". Once you have reached this page, you will be prompted to input your login credentials. All Soniquam Sprint EL52E devices come with the following preconfigured credentials, which you should change after first accessing the administrator panel:

Username: soniq
Password: admin123

More Help

For further, more in-depth help, please consult your provided Advanced User Manual. This simplified version only covers the most basic of functionality, and may not include the solution you require. This manual may be downloaded from the URL included on your packaging.