TRISC Control Signals

Control Signal Definitions (Active High) C0 - Clear Program Counter (PC) C1 - Load PC C2 - Increment PC C3 - Select Memory Address Register (MAR) source (C3=0: PC, C3=1: MDO) C4 - Execute RAM READ/WRITE cycle C5 - Enable RAM WRITE cycle C7 - Load Instruction Regiser (IR) C8 - Clear Accumulator (ACC) C9 - Increment ACC C10 - Select ACC source (C10=0: ALU, C10=1:MDO) C11 - Load ACC C12,C13 - Arithmetic Logic Unit (ALU) Function Code (00:ADD, 10:SUB, 01:AND, 11:XOR)

C14 - Load Buffer Register (BR)

C15 – Load Flag Register (FR)