


Industrial PC

PPC-CM4-236




PN: CS19108RA4236

Contents

I. PPC-CM4-236	3
1.1. Product Overview	5
1.2. Ordering Options	6
1.2.1. Pi [®] CM4 Module	6
1.2.2. Operating System	6
1.2.3. Optional Features	6
1.3. Specifications	7
1.4. Power Input	9
1.5. Touch Screen	10
1.6. Connectivity	11
1.6.1. RS232/RS485/CAN	11
1.6.2. GPIO Port	12
1.6.3. USB Connectors	14
1.6.4. LAN Connectors	15
1.6.5. WiFi & BT Module	16
1.6.6. 3G/4G/LTE Module	16
1.6.7. Zigbee Module	17
1.7. TF Card Slot	20
1.8. Audio Connectors	21
1.9. PROG Button	22
1.10. Mounting Procedure	23
1.11. Mechanical Specifications	24
1.11.1. CS19108RA4236P	24
1.12. Disclaimer	25
1.13. Technical Support	25

PPC-CM4-236



Front View



Rear View



Side View 1



Side View 2

PPC-CM4-236 Product Overview

Product Overview

The Cortex[®]-A72 Raspberry Pi[®] series PPC-CM4-236 (PN: CS19108RA4236) is a high-quality industrial Pi PC. It features a 23.6" Ten-point capacitive touch screen with a resolution of 1920 x 1080 pixels and brightness of 250 cd/m².

Key Applications

- Human Machine Interface HMI
- Process Control
- Process Monitoring
- HMI
- IIoT node
- Environmental Monitoring
- PLC
- Automotive applications
- ATM...

It is available both as an embedded solution and as a device hosed in a casing with bezels, thus facilitating different installation options:

- Installation on an industrial cabinet
- Integration with the existing equipment

The PPC-CM4-236 industrial Pi PC is based around the powerful Raspberry Pi[®] Compute Module 4, powered by the Quad Cortex[®]-A72 processor with a processor speed of 1.5GHz.

PPC-CM4-236 Ordering Options

Ordering Options

Chipsee products can be customized during the ordering process. The product will be shipped with the pre-installed factory defaults if no extra requirements are specified. The table in the Specifications section provides information about the default options bundled with the product.



Note

You can order PPC-CM4-236 from the official **Chipsee Store** or from your nearest distributor.

Pi® CM4 Module

The Pi[®] Compute Module 4 appears in different versions depending on the size of the DDR4 and eMMC.

The PPC-CM4-236 industrial Pi PC does not include the CM4 Raspberry Pi[®] module by default. If you would like to purchase it with a CM4, you can select it at the Chipsee store during the ordering process.

Operating System

This product comes with a pre-installed Debian OS. Chipsee software engineers have created all the drivers, so every hardware feature is readily available for any standard development tool.

If your project requires a different OS, please **Contact us**, and we'll make a customized version that suits your needs.

Optional Features

The PPC-CM4-236 industrial Pi PC does not include the 3G/4G/LTE modules by default. These modules are optional and can be selected at the Chipsee store during the ordering process.



Warning

Installation, repair, and maintenance tasks should be performed by trained personnel only. Chipsee does not bear any responsibility for damage caused by inadequate handling of the product.

PPC-CM4-236 Specifications

Specifications

The PPC-CM4-236 industrial Pi PC offers a broad range of performance and connectivity options for scalable integration, providing expandability according to future needs. Some of the key features are listed in the table below.

PPC-CM4-236					
СРИ	Raspberry Pi [®] CM4, CM4 Lite; Quad Cortex-A72 at 1.5GHz				
Storage	Support for 1 x TF Card3				
RAM	2/4/8 GB, Based on CM4				
еММС	16/32 GB, Based on CM4				
Display	23.6" IPS LCD, 1920 x 1080 resolution px, brightness 250 cd/m ²				
Touch	10-point capacitive touch with 1mm Armored Glass				
USB	2 x USB 3.0 Host, 1 x USB OTG				
LAN	1 x Channel Giga LAN				
Audio	3.5mm Audio Out Connector, 2W Speaker Internal				
Buzzer	Onboard Buzzer, driven by GPIO				
RTC	Yes, High Accuracy RTC with Lithium Button Coin battery (lithium battery not included)				
RS232	Default to 2 x RS232, up to 4 x RS232				
RS485	Default to 2 x RS4851, these 2 x RS485 can be configured as 2 x RS232				
CAN	1 x CAN-BUS				
GPIO	8 Channels, 4 Input, 4 Output				
I2C	Not Supported				
WiFi/BT	Supported but depending on the CM4 selected2				
ZIGBEE	Onboard Zigbee module, not mounted by default				
НДМІ	Not Supported				
SATA II	Not Supported				
3G/4G/LTE	Supported, not mounted by default				
Camera	No				
Power Input	From 12V to 36V				
Current at 12V	1500mA Max				
Power Consumption	20W Typical				
Working Temperature	From 0°C to +50°C				

PPC-CM4-236 Specifications

PPC-CM4-236				
OS	Debian			
Dimensions	CS19108RA4236P: 600 x 400 x 60mm			
Weight CS19108RA4236P: 6000g				


Table 274 Key Features

- 1 The RS485 circuit controls the Input and Output direction automatically, there's no need to control it from within the software.
- 2 The default product without the CM4 does not include a Wi-Fi/BT module. You can include a CM4 that has the Wi-Fi/BT module at the Chipsee store during the ordering process.
- 3 This TF card is designed for storage expansion, as the TF card uses the same pins with WiFi, it can't be used with WiFi at the same time

PPC-CM4-236 Power Input

Power Input

The PPC-CM4-236 industrial Pi PC can be powered by a wide range of input voltages: From 12V to 36V DC. It is a **3 Pin, 3.81mm screw terminal** connector. As shown in the figure below.



Power Input

Note that the "+" sign represents the positive power input, and it is printed both at the casing and as a silk-screen on the board of the embedded version. The "-" terminal is shorted to the ground.

Power Input Definition				
Pin Number	Definition	Description		
Pin 1	Positive Input	DC Power Positive Terminal		
Pin 2	Negative Input	DC Power Negative Terminal		
Pin 3	Ground	Power System Ground		

Table 275 Power Connector



The system ground "**G**" is connected to power negative "-" on board.

PPC-CM4-236 Touch Screen

Touch Screen

The PPC-CM4-236 industrial Pi PC uses a 10-point capacitive touch screen. However, the Debian OS supports only One-Point touch.

The figure below shows the capacitive touch screen connected to the motherboard via the USB connector.



Capacitive Touch Connector



Attention

A capacitive touch screen is susceptible to power noise and Electromagnetic Radiation (EMR). It may cause LCD ripples or even capacitive touch malfunction. If using a capacitive multi-touch test application, you might notice the touch points float erratically across the display. There are several solutions to this problem:

- 1. Use a high-quality Power Adapter Unit (PSU) with low EMR. You can also provide power from a battery.
- 2. Make sure that the PPC-CM4-236 Power Input connector (pin 3) is properly connected to the Power System Ground to provide sufficient EMI shielding and eliminate the problem entirely.
- 3. Bad GND problems can also be confirmed by touching pin 3 of the Power Input connector with one hand while operating the capacitive touch screen with the other hand. In this case, the operator's body acts as the Power System Ground.


PPC-CM4-236 Connectivity

Connectivity

There are many connectivity options available on the PPC-CM4-236 industrial Pi PC. It has 2 x USB 3.0 Host, 1 x USB OTG, 1 x Channel Giga LAN (RJ45) Ethernet connector supporting up to 1 Gbps, and 4×1000 x CAN terminals (RS232/RS485/CAN).

RS232/RS485/CAN

The serial communication interfaces (RS485, RS232, and CAN) are routed to a phoenix terminal, as illustrated in the figure below.



RS232-RS485-CAN on the PPC-CM4-236 Industrial PC



Attention

- 1. RS485_3 and RS485_5 can control the input and output direction automatically. There's no need to control it from within the software.
- 2. The 120Ω match resistor for RS485 is **already** mounted by default.
- 3. The 120Ω match resistor for CAN is **NOT** mounted by default. Be sure to mount the match resistor when testing CAN.
- 4. The 2 x RS485 can be configured to 2 x RS232, if you want a custom configuration, you can contact us when placing an order.

The table below offers more detailed description of every pin and its definition:

RS232 / RS485 / CAN Pin Definition:				
Pin Number	Definition	Description		
Pin 1	CAN_H	CAN BUS "H" signal		

PPC-CM4-236 GPIO Port

RS232 / RS485 / CAN Pin Definition:				
Pin 2	CAN_L	CAN BUS "L" signal		
Pin 3	RS485_5-	CPU UART5, RS485 –(B) signal		
Pin 4	RS485_5+	CPU UART5, RS485 +(A) signal		
Pin 5	RS485_3-	CPU UART3, RS485 –(B) signal		
Pin 6	RS485_3+	CPU UART3, RS485 +(A) signal		
Pin 7	RS232_2_RXD	CPU UART2, RS232 RXD signal		
Pin 8	RS232_2_TXD	CPU UART2, RS232 TXD signal		
Pin 9	RS232_0_RXD	CPU UARTO, RS232 RXD signal		
Pin 10	RS232_0_TXD	CPU UART0, RS232 TXD signal		
Pin 11	GND	System Ground		
Pin 12	+5V	System +5V Power Output, No more than 1A Current output		

Table 276 Connectivity Section

GPIO Port

The PPC-CM4-236 industrial Pi PC has a **phoenix connector**, as shown in the figure below. The table below gives details about the definition of every Pin.



Attention

- 1. In order to use the Isolated Output, you need to add an external Isolated Power to the VDD_ISO and GND_ISO. The power voltage should not exceed 24V.
- 2. The output current can achieve 500mA for every channel, but it also depends on the isolated power that is connected.
- 3. In order to use the Isolated Input, you need to add a signal to the ISO_InputX and GND_ISO. A $2.4 \mathrm{K}\Omega$ resistor, as R6, can be added to limit the input current, as shown in the figure above. This resistor should work well for the 5-24V input signal. If your input signal is less than 5V, please change this input resistor.

PPC-CM4-236 GPIO Port



Isolated GPIO reduced schematic

PIN1	PIN2	PIN3	PIN4	PIN5	PIN6	PIN7	PIN8	PIN9	PIN10	PIN11	PIN12
		IN4	IN3	IN2	IN1	OUT4	ОПТЗ	OUT2	OUT1	GND_ISO	24V_ISC
		,		2)				io i	25		
1											
										REAL PROPERTY.	
		(Inner less			STATE STATES						
		96	0			a a	9				
	0	0		00	00	00	00				
	1	00	000		0 0 ==	00 ==	00				
					EE			10	4		
	0 - 0							Ó		0	

GPIO Connector

GPIO Connector Pin Definition:				
Pin Number	Definition	Description		
Pin 12 24V_ISO		Isolated Power +24V Input		
Pin 11 GND_ISO		Isolated Ground		

PPC-CM4-236 USB Connectors

GPIO Connector Pin Definition:					
Pin 10	OUT1	Isolated Output 1			
Pin 9	OUT2	Isolated Output 2			
Pin 8	OUT3	Isolated Output 3			
Pin 7	OUT4	Isolated Output 4			
Pin 6	IN1	Isolated Input 1			
Pin 5	IN2	Isolated Input 2			
Pin 4	IN3	Isolated Input 3			
Pin 3	IN4	Isolated Input 4			

Table 277 GPIO Connector Pin-out

USB Connectors

There are 2 x USB 3.0 Host, 1 x USB OTG onboard, as shown in the figure below.



USB HOST Connectors




Attention

1. These two USB host connectors can drive 500mA for each channel at most.

The product has one USB Type-C OTG connector that works as a slave by default. You can use it to establish a connection with the host PC and for downloading the system to the eMMC of CM4 module.

PPC-CM4-236 LAN Connectors



USB Type-C OTG Connector




Warning

- 1. Be careful not to touch surrounding electronic components accidentally while plugging in USB devices into the embedded Industrial PC version.
- 2. Remember to unplug the Type-C cable after flashing OS, otherwise the USB hosts won't work.

LAN Connectors

LAN (RJ45) connector provides Ethernet connectivity over standardized Ethernet cables as shown in the figure below. The integrated Ethernet interface supports up to 1 Gbps data throughput. These Giga LAN signals come from the CM4 module directly.



RJ45 LAN Connector



Note

Use CAT5 or better cables to achieve full data throughput over maximum distance defined by the 1000BASE-T standard (100m).

PPC-CM4-236 WiFi & BT Module

WiFi & BT Module

The default PPC-CM4-236 without the CM4 does not include a Wi-Fi/BT module. If you include a CM4 that has the Wi-Fi/BT module, the product will have Wi-Fi/BT feature. The enclosed (CS19108RA4236P) variant of the product also includes an SMA connector for an external WiFi/BT antenna, as illustrated in the figure below.



WiFi+BT Antenna



Attention

The product does not come shipped with the Wi-Fi/BT module by default.

3G/4G/LTE Module

The PPC-CM4-236 industrial Pi PC is equipped with a **mini-PCle connector** that can connect to a 3G/4G/LTE module. The customer will also need a SIM Card Holder and a 3G/4G/LTE

PPC-CM4-236 Zigbee Module

antenna to ensure 3G/4G/LTE works on the PPC-CM4-236. SIM card does **NOT** support hot plug. **Power off** before inserting or removing SIM card.



SIM Card Direction



Figure 940: 3G/4G/LTE Module





Figure 941: SIM Card Holder and 3G/4G/LTE Antenna



Attention

The product does not come shipped with the 3G/4G/LTE module by default. If you need to use 3G/4G/LTE, you can contact us when placing an order, we can install the necessary hardware for you.

Zigbee Module

The PPC-CM4-236 industrial Pi PC supports an onboard Zigbee module. The Zigbee controller is TI CC2531, and the Raspberry Pi forum supports it.

For CS19108RA4236P, there is a connector on the backside of the case that you can use to connect the external Zigbee antenna, as described in the figure below.

PPC-CM4-236 Zigbee Module

Internal Zigbee Antenna



External Zigbee Antenna Connector

Zigbee Controller

Figure 942: Zigbee controller

PPC-CM4-236 Zigbee Module



Zigbee Antenna




Attention

The product does not come with the Zigbee module by default.

TF Card Slot PPC-CM4-236

TF Card Slot

The PPC-CM4-236 industrial Pi PC features 1 x **TF Card (micro SD) slot**. A slot can address up to 128GB of memory.



TF (micro SD) Card Slot



Attention

- 1. The SD is used for memory extension. It can't be used for system boot-up.
- 2. This storage extension SD uses the same pins as WiFi on CM4. SD storage and WiFi **can't** be used at the same
- 3. The product does not come shipped with the TF card by default.

PPC-CM4-236 Audio Connectors

Audio Connectors

The PPC-CM4-236 industrial Pi PC features some audio peripherals. It has 1 x **3.5mm audio output jack**.

Also, the PPC-CM4-236 industrial Pi PC has a miniature 2W internal speaker for audio reproduction, as well as a small buzzer for alarm/notification sounds.



Audio Connector (enclosed PC version)



Attention

By plugging in the headphone cable, the internal speaker will be disabled automatically.


PPC-CM4-236 PROG Button

PROG Button

The PPC-CM4-236 industrial Pi PC has one button for entering usb download mode, as shown in the figure below.

When booting **with** the button being pressed, the Raspberry Pi will boot from the USB connector. You can use this feature to download the OS software to the internal eMMC. When booting **without pressing** the button, the Raspberry Pi will boot from the internal eMMC.

There is no need to press the button during regular operation. However, if you need to reinstall the OS, please refer to the detailed information on how to reflash the OS from the Software Documentation.



PROG Button

PPC-CM4-236 Mounting Procedure

Mounting Procedure

The PPC-CM4-236 industrial Pi PC can be mounted with $4 \times M4$ (6mm) screws using the **VESA** (100x100mm or 75x75mm) mount.

The PPC-CM4-236 industrial Pi PC can be mounted with **panel mount** method, enabling simplified installation onto any standard mounting fixture.



Attention

Please make sure the display is not exposed to high pressure when mounting into an enclosure.

You can find detailed information about mounting in the Mount IPC Guide.

PPC-CM4-236 Mechanical Specifications

Mechanical Specifications

CS19108RA4236P

For CS19108RA4236P, the outer mechanical dimensions are 600 x 400 x 60mm (W x L x H).

PPC-CM4-236 Disclaimer

Disclaimer

This document is provided strictly for informational purposes. Its contents are subject to change without notice. Chipsee assumes no responsibility for any errors that may occur in this document. Furthermore, Chipsee reserves the right to alter the hardware, software, and/or specifications set forth herein at any time without prior notice and undertakes no obligation to update the information contained in this document.

While every effort has been made to ensure the accuracy of the information contained herein, this document is not guaranteed to be error-free. Further, it does not offer any warranties or conditions, whether expressed orally or implied in law, including implied warranties and conditions of merchantability or fitness for a particular purpose. We specifically disclaim any liability with respect to this document, and no contractual obligations are formed either directly or indirectly by this document.

Despite our best efforts to maintain the accuracy of the information in this document, we assume no responsibility for errors or omissions, nor for damages resulting from the use of the information herein. Please note that Chipsee products are not authorized for use as critical components in life support devices or systems.

Technical Support

If you encounter any difficulties or have questions related to this document, we encourage you to refer to our other documentation for potential solutions. If you cannot find the solution you're looking for, feel free to contact us. Please email Chipsee Technical Support at **support@chipsee.com**, providing all relevant information. We value your queries and suggestions and are committed to providing you with the assistance you require.