

# **X Joint Assembly**



Dept.	Technical reference	Created by		Approve	ed by	
		DutchDude (	09/04/2021			
	-	Document type		Docume	ent status	
		Title		DWG N	0.	
		X Assembly	/			
				Rev.	Date of issue	Sheet
						1/7


# **Top view**




Dept.	Technical reference	Created by	Approved by	
		DutchDude 09/04/202		
		Document type	Document status	
		Title	DWG No.	
		X Assembly		
			Rev. Date of issue	Sheet
				2/7

## **Top view**

Hardware and extra info on last page




### FLANGE STACK



Dept.	Technical reference	Created by		Approve	ed by	
		DutchDude	09/04/2021			
	·	Document type		Docume	ent status	
		Title		DWG N	0.	
		X Assemb	ly			
				Rev.	Date of issue	Sheet
						3/7

### **Bottom View**



Dept.	Technical reference	Created by		Approve	ed by	
		DutchDude 09/04/	2021			
		Document type		Docume	ent status	
		Title		DWG N	0.	
		X Assembly				
				Rev.	Date of issue	Sheet
						4/7


### Right side + X Endstop


Hardware and extra info on last page

#### ADDITIONAL INFO - OPTIONAL

The right side of the X assembly could use a Cable chain bridge, this part is optional.


If you don't plan on using this swap the M5X16 TO M5X10





Dept.	Technical reference	Created by		Approve	ed by	
		DutchDude	09/04/2021			
		Document type		Docume	ent status	
		Title		DWG N	0.	
		X Assemb	ly			
					<del>i</del>	
				Rev.	Date of issue	Sheet
						5/7

### **Cross section extruder**



Dept.	Technical reference	Created by		Approve	ed by	
		DutchDude 09/0	4/2021			
		Document type		Docume	ent status	
		Title		DWG N	0.	
		X Assembly				
				Rev.	Date of issue	Sheet
						6/7

#### HARDWARE

- 3 M3X8 (FOR MGN12H RAILBLOCK)
- 4 M5X25 BOLTS (FOR HEX NUTS)
- 5 M5X10 (FOR EXTRUSION READ OPTIONAL)
- 2 M5X16 (FOR CABLE CHAIN BRIDGE)(OPTIONAL, NO? = M5X10)
- 1 M5X20 (FOR X ENDSTOP)
- 4 M5 HEX NUTS
- 6 M5 T-NUTS (FOR EXTRUSION)
- 4 M5X30 Dowel Pins
- **5** M5 1MM SPACER (BETWEEN FLANGE BEARINGS + ENDSTOP)
- 4 F695-2RS 5\*13\*4mm (FLANGE BEARING)
- 2 GT2 20T Idler
- 1 KW10 ENDSTOP

#### **EXTRA INFO**

The cable chain mount is optional. Don't want to use the Cable Chain Mount > Swap the 2 M5X16 for M5X10.

Don't want to use an X endstop? Swap the MX20 FOR M5X10.

Sometimes dowell pins don't fit perfectly. To fix this issue you'll need a drill that fits the dowell pin and then using sandpaper, sand them down a little at a time testing fiting until they are a snug fit.

#### OPTIONAL

Sometimes the M3X8 bolts for the MGN12H railblock are too short, if this is the case use M3X10.

_				
١	10	$\sim$	ra	•
J	15	CO	LU	١

https://discord.com/invite/gzJP2s8

### X Joints are inpsired by VORON DESIGN

Dept.	Technical reference	Created by		Approve	ed by		
		DutchDude	09/04/2021				
		Document type		Docume	ent status		
		Title		DWG N	0.		
		X Assembl	У				
				D	D. C. C.	1	01
				Rev.	Date of issue		Sheet
							7/7