




## Stepper mount Left & Right













Dept.	Technical reference	Created by		Approve	ed by	
		DutchDude	21/03/2021			
		Document type		Docume	ent status	
		Title		DWG N	0.	
		Stepper m	ounts			
				Rev.	Date of issue	Sheet
						1/7

### Stepper mount LEFT top view




Dept.	Technical reference	Technical reference Created by Approved by	
		DutchDude 21/03/202	21
	•	Document type	Document status
		Title	DWG No.
		Stepper mounts	
			Day Date of January Chart
			Rev. Date of issue Sheet
			2/7

# Stepper mount LEFT Back view




Dept.	Technical reference	Created by		Approv	ed by	
		DutchDude	21/03/2021			
	•	Document type		Docum	ent status	
		Title		DWG N	Jo.	
				DWG	NO.	
		Stepper n	nounts			
					T	F
				Rev.	Date of issue	Sheet
						3/7

## Stepper mount LEFT SIDE view



Dept.	Technical reference	Created by		Approve	ed by	
		DutchDude	21/03/2021			
		Document type		Docume	ent status	
		Title		DWG N	0.	
		Stepper mo	ounts			
				Rev.	Date of issue	Sheet
				Rev.	Date of issue	A /-
						4//

### Stepper mount LEFT bottom view



Dept.	Technical reference	Created by		Approve	ed by	
		DutchDude	21/03/2021			
	-	Document type		Docume	ent status	
		Title		DWG N	0.	
		Stepper m	ounts			
					la	01 /
				Rev.	Date of issue	Sheet
						5/7

### Stepper mount Right


Hardware and extra info on last page

#### ADDITIONAL INFO - MUST READ

The right stepper mount uses the exact same hardware as the left stepper mount.

#### OPTIONAL

Installation of the cable chain mount onto the NEMA17 stepper is fully optional.



Dept.	Technical reference	Created by	Approv	ed by	
		DutchDude 21/03/202	21		
	•	Document type	Docum	ent status	
		Title	DWG N	No.	
		Stepper mounts			
			Davi	Data at innue	Ch4
			Rev.	Date of issue	Sheet
					6/7


#### HARDWARE

- 8 M5X50 BOLTS (INTO T-NUTS)
- 8 T-NUTS (FOR EXTRUSION)
- 6 M3X20 (ATTACHES STEPPER)
- 4 M5X30 Dowell Pins (FOR FLANGE BEARINGS)
- 12 M5 1MM SPACER (BETWEEN FLANGE BEARINGS)
- **12** 625RS 5\*16\*5mm (FLANGE BEARING)

#### EXTRA INFO

Sometimes dowell pins don't fit perfectly. To fix this issue you'll need a drill that fits the dowell pin and then using sandpaper, sand them down a little at a time testing fiting until they are a snug fit.

#### The image below shows a flange stack



### Discord: https://discord.com/invite/gzJP2s8

Dept.	Technical reference	Created by		Approve	ed by		
		DutchDude	21/03/2021				
	•	Document type		Docume	ent status		
		Title		DWG N	lo.		
		Stepper m	nounts				
				Davi	Date of issue	l Oh	
				Rev.	Date of issue	Sheet	
						7/	/7