




Stepper mount Left & Right













Dept.	Technical reference	Created by		Approve	ed by	
		DutchDude	21/03/2021			
	-	Document type		Docume	ent status	
		Title		DWG N	0.	
		Stepper m	ounts			
					1	•
				Rev.	Date of issue	Sheet
						1/7

Stepper mount LEFT top view




Dept.	Technical reference	Created by		Approve	ed by	
		DutchDude	21/03/2021			
	-	Document type		Docume	ent status	
		Title		DWG N	0.	
		Stepper mo	ounts			
				Davi	D-46:	 Oh4
				Rev.	Date of issue	Sheet
						2/7

Stepper mount LEFT Back view




Dept.	Technical reference	Created by		Approv	red by	
		DutchDude	21/03/2021			
		Document type		Docum	ent status	
		Title		DWG N	No.	
		Stepper n	nounts			
				Rev.	Date of issue	Sheet
						3/7

Stepper mount LEFT SIDE view



Dept.	Technical reference	Created by		Approve	ed by	
		DutchDude	21/03/2021			
		Document type		Docume	ent status	
		Title		DWG N	0.	
		Stepper mo	ounts			
					ln	lo.
				Rev.	Date of issue	Sheet
						4/7

Stepper mount LEFT bottom view



Dept.	Technical reference	Created by		Approve	ed by	
		DutchDude	21/03/2021			
		Document type		Docume	ent status	
		Title		DWG N	0.	
		Stepper m	ounts			
				Rev.	Date of issue	Sheet
				Rev.	Date of issue	
						5/7

Stepper mount Right


Hardware and extra info on last page

ADDITIONAL INFO - MUST READ

The right stepper mount uses the exact same hardware as the left stepper mount.

OPTIONAL

Installation of the cable chain mount onto the NEMA17 stepper is fully optional.



Dept.	Technical reference	Created by	Approved by
		DutchDude 21/03/202	<u>:</u> 1
	•	Document type	Document status
		Title	DWG No.
		Stepper mounts	
			Rev. Date of issue Sheet
			6/7


HARDWARE

- 8 M5X50 BOLTS (INTO T-NUTS)
- 8 T-NUTS (FOR EXTRUSION)
- 6 M3X20 (ATTACHES STEPPER)
- 4 M5X30 Dowel Pins (FOR FLANGE BEARINGS)
- 12 M5 1MM SPACER (BETWEEN FLANGE BEARINGS)
- **12** F695-2RS 5*13*4mm (FLANGE BEARING)

EXTRA INFO

Sometimes dowell pins don't fit perfectly. To fix this issue you'll need a drill that fits the dowell pin and then using sandpaper, sand them down a little at a time testing fiting until they are a snug fit.

The image below shows a flange stack



Discord: https://discord.com/invite/gzJP2s8

Dept.	Technical reference	Created by		Approv	red by	
		DutchDude	21/03/2021			
	•	Document type		Docum	ent status	
		Title		DWG N	No.	
		Stepper m	nounts			
				Rev.	Date of issue	Sheet
						7/7