
Legend
Other Functions
ESP-IDF-FreeRTOS
STAR Functions
Entry Point
app_main
internal_unregister_config_pins
internal_unregister_bus_pin
star_bus_config_deinit
gpio_reset_pin
i2c_driver_delete
spi_bus_remove_device
uart_driver_free
ESP_LOGW
spi_bus_free
gpio_isr_handler_remove
esp_err_to_name
ESP_GOTO_ON_ERROR
star_bus_config_destroy
star_bus_manager_deinit
ESP_RETURN_ON_FALSE
star_sensor_hcsr04_get_result
star_sensor_hcsr04_calculate_distance
i2c_master_read
i2c_master_read_byte
i2c_cmd_link_delete
internal_star_bus_i2c_read
internal_i2c_execute_with_retry
i2c_master_cmd_begin
internal_star_bus_i2c_read_raw
i2c_master_start
internal_star_bus_i2c_write_command
i2c_master_stop
star_bus_i2c_init_default_cps
internal_star_bus_i2c_write
i2c_master_write_byte
i2c_cmd_link_create
i2c_master_write
esp_err_t
esp_rom_delay_us
gpio_set_intr_type
gpio_set_interrupt_default
gpio_install_isr_service
gpio_read_default
strdup
gpio_isr_handler_add
star_bus_gpio_init_default_cps
star_sensor_pca9685_set_duty_cycle
star_sensor_pca9685_set_pwm
ESP_LOGV
gpio_write_default
ESP_RETURN_ON_ERROR
star_sensor_pca9685_set_channel_off
gpio_configure_default
star_sensor_hcsr04_read_distance
vTaskDelay
star_bus_i2c_write
pca9685_write_reg
pdMS_TO_TICKS
internal_pca9685_set_frequency
vSemaphoreDelete
star_sensor_hcsr04_trigger
pca9685_read_reg
star_bus_gpio_write
star_bus_i2c_read
error_handler_record_error
uxprintf
read_fs_total
star_bus_config_create_i2c
ESP_LOGE
star_bus_gpio_set_interrupt
star_bus_gpio_configure
internal_star_bus_config_cleanup
internal_iface_record_error
star_bus_manager_init
star_bus_config_create_gpio
internal_star_bus_config_create_common
free
star_sensor_pca9685_init
star_sensor_hcsr04_init
star_sensor_pca9685_calculate_prescale
roundf
malloc
error_handler_create_default
error_handler_create_custom
ESP_LOGE
error_handler_get_interface
star_error_interface_create_default
error_handler_destroy_default
error_handler_destroi
star_error_interface_destroy
sprintf
internal_register_bus_pin
star_bus_manager_add_bus
internal_register_config_pins
star_bus_manager_find_bus
error_handler_init
ESP_LOGD
STAR_DHT22_CONFIG_DEFAULT
star_validate_pins
iface_validate
error_handler_reset_state
internal_iface_reset_state
i2c_driver_install
i2c_param_config
spi_bus_add_device
star_bus_initialize
spi_slave_initialize
star_bus_config_init
star_bus_type_to_string
gpio_config
star_bus_dht22_init
xSemaphoreTake
internal_iface_can_retry
error_handler_can_retry
xSemaphoreGive
pin_validator_get_interface
star_register_pin
strnlen
strnpy
star_unregister_pin
init_mutex
xSemaphoreCreateMutex
realloc
strcmp
iface_register_pin
memcpy
iface_unregister_pin
get_dht22_state
memset
gpio_set_level
internal_init_dht22_mutex
portENTER_CRITICAL
internal_get_dht22_state
portEXIT_CRITICAL
strncpy
gpio_high
star_bus_dht22_read
read_raw_data
gpio_low
star_bus_dht22_calculate_checksum
star_bus_dht22_raw_to_humidity
gpio_set_output
gpio_set_direction
gpio_set_input
wait_for_level
gpio_read
gpio_get_level
star_bus_dht22_raw_to_celsius
esp_timer_get_time
hcsr04_echo_isr_handler
delay_us
rtc_delay_us