Choosing an Engine
black queen

a6	Stockfish 8 ('081017')	DEFAULT
b6	Texel 1.07	
c6	Arasan 20.3.0	
d6	Rodent III 0.233	
e6	Zurichess neuchatel ('master')	
f6	WyldChess 10062017	
g6	Galjoen 0.37.2	
h6	Sayuri 2017.12.16	

Example: Arasan 20.3.0

Choosing a Level
black queen

a5	Level 0 (= weakest)
b5	Level 3
c5	Level 6
d5	Level 9
e5	Level 12
f5	Level 15
g5	Level 18
h5	Level 20 (= strongest) DEFAULT

* Not all engines support levels: Rodent III has
'personalities' and Zurichess has 'handicaps'.

Example: Level 9

Choosing an Opening Book
black queen

a3	No book
b3	ECO A: flank openings
c3	ECO B: semiopen games
d3	ECO C: open games + French
e3	ECO D: closed games
f3	ECO E: Indian games
g3	Fun
h3	Varied DEFAULT
a4	GM 1950
b4	Performance
c4	Stockfish
d4	Anand
e4	Korchnoi
f4	Larsen
g4	Pro
h4	GM 2001

Example: Opening Book 'Fun'

Choosing a Time Control
white queen

a6	Fixed: 1 s / move
b6	3 s / move
c6	5 s / move
d6	10 s / move
e6	15 s / move
f6	30 s / move
g6	60 s / move
h6	90 s / move
a4	Blitz: 1 min / game
b4	3 min / game
c4	5 min / game `DEFAULT`
d4	10 min / game
e4	15 min / game
f4	30 min / game
g4	60 min / game
h4	90 min / game
a3	Fischer: 1 min + 1 s / move
b3	3 min + 2 s / move
c3	5 min + 3 s / move
d3	10 min + 5 s / move
e3	15 min + 10 s / move
f3	30 min + 15 s / move
g3	60 min + 20 s / move
h3	90 min + 30 s / move

Example: Blitz 15 min / game

Example: Fischer 1 min + 1 s / move

Choosing a Play Mode
white queen

|	
a5	Play against computer `DEFAULT`
b5	Brain mode
c5	Analysis mode
d5	Kibitz mode
e5	Observe mode
f5	Ponder mode
h5	Remote mode

Example: Play against computer

Adjudicating a Game

both kings

First, clear the fourth and
fifth ranks.
Then, place both kings:
- on **e4** and **d5** = White wins
- on **d4** and **e5** = Black wins
- on **d4** and **e4** = draw
- on **d5** and **e5** = draw

Example: Black wins

Shut Down the Computer

white queen

In starting position,
replace the white king
with the spare white queen
to power off the computer.

Also works with empty board
and both white queens on
d1 and e1.

Example: Shut down computer

Reboot the Computer

black queen

In starting position,
replace the black king
with the spare black queen
to reboot the computer.

Also works with empty board
and both black queens on
d8 and e8.

Example: Reboot computer