

Updating your box


The system can be updated to receive the latest improvements and training content.

Updates are managed through the **Launcher**, which opens automatically when the box starts.

Downloading the update

Before an update can be installed, the new version must first be **downloaded**. This download happens **automatically in the background** when the case is connected to the internet.


Depending on the internet connection, downloading the update can take **up to one hour**. You can only install the update **after the download has finished**.



Installing the update

Once the update has finished downloading:

1. Click on the **Update** button in the Launcher.
2. Make sure the **VR headset is turned on**.
3. Connect the headset to the case using the **USB-C cable inside the case**.



1. Press **Update**.

The system will update both the **VR headset** and the **Spectator software**.

Installation time

Installing the update usually takes **around 5 minutes**.

Make sure the headset stays connected during the update process.

