USB Convert to **UART** Power CON3 U2 PL_2303HXD_SOP VCC_3.3_PL2303 VCC_3.3_PL2303 WH-GN100 12P ANT VCC_RF1 **KEY**